auteco motocicletas bajaj

NXT

Catálogo de Partes

INDEX

PLATE No.	DESCRIPTION	PAGE No.
1	ENGINE & CRANKCASE	1
2	CRANKCASE MAGNETO SIDE	2
3	CRANKCASE COVER ASSLY	3
4	CYLINDER / PISTON ASSLY	4
5	CRANK SHAFT ASSLY	5
6	CYLINDER HEAD	6
7	VALVE	7
8	CAMSHAFT AND CHAIN TENSIONER	8
9	CLUTCH ASSLY	9
10	CLUTH HOUSING COMP.	10
11	CLUTH LEVER ASSLY	11
12	MAIN SHAFT	12
13	GEAR TRANSMISSION	13
14	GEAR SHIFTER ASSLY	14
15	KICK SHAFT ASSLY	15
16	COWLING & SILENCER ASSEMBLY	16
17	MAGNETO ASSLY	17
18	STATOR ASSLY	18
19	SPARK PLUG AND H.T. COIL	19
20	CARBURETTOR	20
21	AIR FILTER ASSEMBLY	21
22	PUMP ASSLY OIL	22
23	PETROL TANK ASSLY	23
24	FUEL COCK ASSLY	24
25	FRONT BRAKE DRUM ASSLY	25
26	FRONT BRAKE ASSLY	26
27	REAR BRAKE DRUM ASSLY	27
28	REAR BRAKE ASSLY	28
29	REAR BRAKE PEDAL ASSLY	29
30	WHEEL RIM / COVERS / SPARE WHEEL	30
31	CHASSIS AND GROMMETS	31
32	SHIELDS, SIDE RAIL, FR. SIDE INDICATORS...	32
33	GRAB HANDLE ASSLY	33
34	MUDGUARD / BONNETS / REAR No. PLATE / TAIL PIECE	34
35	STAND / MATTINGS	35
36	ENGINE LINK ASSLY	36
37	FRONT HUB ASSEMBLY / FRONT SHOCK ABSORBER	37
38	ANTIDIVE LINK ASSLY	38
39	REAR SHOCK ABSORBER	39
40	STEERING COLUMN ASSLY	40
41	HANDLE BAR / COVERS	41
42	HANDLE BAR CONTROLS	42
43	CONTROL CABLES	43
44	STEERING LOCK	44
45	HEAD LAMP / INSTRUMENT PANEL	45
46	TAIL LAMP / SWITCHES	46
47	ELECTRICALS	47
48	ELECTRICAL EQUIPMENTS	48
49	DUAL SEAT ASSLY	49
50	LUGGAGE HOOK / FOOT REST ASSLY	50
51	MIRROR / TOOL KIT	51

PICTORIAL INDEX




PLATE Nº 1: ENGINE & CRANKCASE (CLUTCH SIDE)	PAGE No. 1




PLATE Nº 2: CRANKCASE MAGNETO SIDE	PAGE No. 2




PLATE Nº 3: CRANKCASE COVER ASSLY	PAGE No. 3




PLATE Nº 4: CYLINDER / PISTON ASSLY	PAGE No. 4




PLATE Nº 5: CRANK SHAFT ASSLY	PAGE No. 5




PLATE Nº 6: CYLINDER HEAD	PAGE No. 6

PICTORIAL INDEX




PLATE Nº 7: VALVE	PAGE No. 7




PLATE Nº 8: CAMSHAFT AND CHAIN TENSIONER	PAGE No. 8




PLATE Nº 9: CLUTCH ASSLY	PAGE No. 9




PLATE Nº 10: CLUTH HOUSING COMP.	PAGE No. 10




PLATE Nº 11: CLUTCH LEVER ASSLY	PAGE No. 11




PLATE Nº 12: MAIN SHAFT	PAGE No. 12

PICTORIAL INDEX




PLATE Nº 13: GEAR TRANSMISSION	PAGE No. 13




PLATE Nº 14: GEAR SHIFTER ASSLY	PAGE No. 14




PLATE Nº 15 : KICK SHAFT ASSLY	PAGE No. 15




PLATE Nº 16 : COWLING & SILENCER ASSEMBLY	PAGE No. 16




PLATE Nº 17 : MAGNETO ASSLY	PAGE No. 17




PLATE Nº 18: STATOR ASSLY	PAGE No. 18

PICTORIAL INDEX




PLATE Nº 19 : SPARK PLUG AND H.T. COIL	PAGE No. 19




PLATE Nº 20 : CARBURETTOR	PAGE No. 20




PLATE Nº 21 : AIR FILTER ASSEMBLY	PAGE No. 21




PLATE Nº 22 : PUMP ASSLY OIL	PAGE No. 22




PLATE Nº 23 : PETROL TANK ASSLY	PAGE No. 23




PLATE Nº 24 : FUEL COCK ASSLY	PAGE No. 24

PICTORIAL INDEX




PLATE Nº 25 : FRONT BRAKE DRUM ASSLY	PAGE No. 25




PLATE Nº 26 : FRONT BRAKE ASSLY	PAGE No. 26




PLATE Nº 27 : REAR BRAKE DRUM ASSLY	PAGE No. 27




PLATE Nº 28 : REAR BRAKE ASSLY	PAGE No. 28




PLATE Nº 29 : REAR BRAKE PEDAL ASSLY	PAGE No. 29




PLATE Nº 30 : WHEEL RIM / COVERS / SPARE WHEEL	PAGE No. 30

PICTORIAL INDEX




PLATE Nº 31 : CHASSIS AND GROMMETS	PAGE No. 31




PLATE Nº 32 : SHIELDS, SIDE RAIL, FR. SIDE INDICATORS & LEGGAGE BOX	PAGE No. 32




PLATE Nº 33 : GRAB HANDLE ASSLY	PAGE No. 33




PLATE Nº 34 : MUDGUARD /BONNETS / REAR No. PLATE / TAIL PIECE	PAGE No. 34




PLATE Nº 35 : STAND / MATTINGS	PAGE No. 35




PLATE Nº 36: ENGINE LINK ASSLY	PAGE No. 36

PICTORIAL INDEX




PLATE Nº 37 : FRONT HUB ASSEMBLY / FRONT SHOCK ABSORBER	PAGE No. 37




PLATE Nº 38 : ANTIDIVE LINK ASSLY	PAGE No. 38




PLATE Nº 39 : REAR SHOCK ABSORBER	PAGE No. 39




PLATE Nº 40 : STEERING COLUMN ASSLY	PAGE No. 40




PLATE Nº 41 : HANDLE BAR / COVERS	PAGE No. 41




PLATE Nº 42 : HANDLE BAR CONTROLS	PAGE No. 42

PICTORIAL INDEX




PLATE Nº 43 : CONTROL CABLES	PAGE No. 43




PLATE Nº 44 : STEERING LOCK	PAGE No. 44




PLATE Nº 45 : HEAD LAMP / INSTRUMENT PANEL	PAGE No. 45




PLATE Nº 46 : TAIL LAMP / SWITCHES	PAGE No. 46




PLATE Nº 47 : ELECTRICALS	PAGE No. 47






PLATE Nº 48 : ELECTRICAL EQUIPMENTS (FOR SELF START VEHICLE)	PAGE No. 48

PICTORIAL INDEX








PLATE Nº 49 : DUAL SEAT ASSLY	PAGE No. 49	PLATE Nº 50 : LUGGAGE HOOK / FOOT REST ASSLY	PAGE No. 50	PLATE Nº 51 : MIRROR / TOOL KIT	PAGE No. 51

PLATE No. 1: ENGINE & CRANKCASE (CLUTCH SIDE)




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1011-81	Crankcase comp.	1	Crankcase LH & RH
2	39-1654-05	Stud	2	For Joining Crankcase
3	39-1658-05	Stud	1	For Joining Crankcase
4	39-1653-05	Stud	4	For Crankcase Cover
5	39-1652-05	Stud	2	For Cylinder
6	28-1011-46	Bush Assly	1	For R S A Mounting
7	28-1011-15	Tube assly	1	Oil tube
8	39-0746-01	Screw Pan Cross	1	
9	28-1011-68	Collar (Inner bush)	2	
10	28-1010-06	Outer bush	2	
11	28-1010-05	Inner bush	1	
12	28-1011-80	Shim	1	
13	01-1701-11	Ball Bearing	1	Shaft Intermediate
14	05-1510-12	Adjuster with nut	1	
15	28-1011-41	Oil Plug		
16	39-1796-11	Plain Washer	1	
17	28-1012-46	Breather Tube assly	1	
18	28-1011-74	Clip	1	
19	39-0999-06	Hollow dowel pin	1	For oil pump
20	28-1010-12	Baffle	1	
21	39-1414-02	Cross rec.Ch.Hd. Screw	2	
22	28-1010-80	Rubber bush	1	
23	39-1922-06	Hollow Dowel	4	On crankase
24	28-1011-45	Arm cover	1	
25	28-1011-73	Clamp breather pipe	1	
26	28-1010-92	Breather pipe	1	

PLATE N°2: CRANKCASE MAGNETO SIDE




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	39-1658-05	Stud	2	Gear shifter
2	03-1003-35	Neddle roddle roller bearing	1	Manin Shaft
3	39-2133-19	Oil seal	1	
4	39-1265-19	Oil seal	1	
5	28-1011-09	Guide kick	1	
6	39-0892-04	Hex bolt	2	
7	39-1652-05	Stud	2	Cylinder
8	39-0119-04	Bolt	3	For Without Self Start Vehicle
9	39-0200-11	Plain washer	3	
10	39-0265-12	Spring washer	3	
11	28-1011-70	Plate	1	
12	28-1010-14	Cap Oil Filler	1	
13	39-1656-21	O´Ring	1	
14	39-0444-04	´D´Bolt	2	
15	39-1338-04	´D´Bolt	5	
16	39-0293-15	Nut	10	
17	39-0199-11	Plain Washer	10	
18	39-0264-12	Spring Washer	10	
19	28-1010-22	Cap strainer	1	
20	39-1657-21	O´ring	1	
21	28-1010-89	Oil strainer	1	
22	39-1574-21	O´ring	1	
23	01-1701-10	Ball bearing	1	Shaft intermediate
24	28-1010-48	Gasket (crankcase)	1	

PLATE N°3: CRANKCASE COVER ASSLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1012-36	Cover Crankcase/pin	1	
2	05-1510-12	Adjuster with nut	1	
3	39-1450-20	Ball bearing	1	For Main Shaft
4	39-0342-17	Circlip	1	
5	39-1722-19	Oil seal	1	For Main Shaft
6	30-1510-38	Ring ´O´	1	
7	39-1583-04	Flanged bolt	6	
8	28-1011-03	Gasket (cover)	1	
9	39-0199-11	Plain washer	4	
10	39-0264-12	Spring Washer	4	
11	39-0293-15	Nut	4	

PLATE N°4: CYLINDER / PISTON ASSLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1010-86	Cylinder Comp.	1	
2	28-1011-18	Bush	1	
3	28-1010-17	Gasket Cylinder Block	1	
4	39-1000-06	Hollow Dowel Pin	4	
5	28-1010-23	Piston assly Std	1	
6	28-1012-07	Cylinder block piston assly	1	
7	AA-1013-34	Piston ring set	1	
8	39-1543-21	´O´ring	1	
9	39-0985-17	Wire circlip	2	
10	AA-1010-25	Pin Piston	1	
11	28-1010-24	Piston	1	

PLATE N°5: CRANK SHAFT ASSLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1010-25	Crank Shaft Assly	1	
2	28-1012-21	Primary spur	1	
3	28-1011-07	Parallel key	1	
4	01-1006-10	Woodruff key	1	
5	28-1010-11	Nut special	1	
6	28-1010-58	Plunger oil	1	
7	28-1010-49	Spring	1	
8	39-0142-07	Parallel pin	1	
9	28-1011-10	Damper spring	1	
10	39-1358-15	Hex Nut with Flange	1	
11	39-0737-12	Spring washer	1	

PLATE N°6: CYLINDER HEAD




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1012-06	Cylinder head assly	1	
2	39-1660-05	Stud	2	
3	28-1011-28	Head gasket	1	
4	28-1011-19	Cam shaft cover	1	
5	39-1264-21	´O´ring	1	
6	39-0739-04	Bolt Flanged	2	
7	13-1010-31	Cap	2	
8	39-1263-21	´O´ring	2	
9	39-1651-15	Domed cap nut	4	
10	28-1011-78	Gasket	4	
11	39-1845-04	Hex Bolt with flange	2	
12	28-1012-41	Manifold	1	
13	28-1011-30	Insulator	1	
14	39-1283-21	´O´ring	2	
15	39-1712-04	Flanged bolt	3	

PLATE N°7: VALVE




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1012-42	Valve - Intake	1	
2	28-1012-43	Valve - Exhaust	1	
3	39-1035-19	Seal oil	2	
4	31-1010-22	Spring Engine Valve	2	
5	31-1010-18	Retainer Valve Spring	2	
6	31-1010-19	Collet	4	
7	28-1011-29	Seat Spring	2	
8	28-1010-32	Arm Rocker	2	
9	39-1024-01	Screw	2	
10	39-0973-15	Nut	2	
11	28-1010-13	Rocker Arm Shaft (in)	1	
12	13-1010-24	Rocker Arm Shaft	1	
13	28-1010-57	Stopper	1	
14	39-0746-01	Screw Pan cros.	1	

PLATE N° 8: CAMSHAFT AND CHAIN TENSIONER




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1010-19	Camshaft Assly	1	
2	13-1010-29	Camshaft sprocket	1	
3	22-1504-51	Screw	2	
4	28-1010-21	Guide chain (slack)	1	
5	28-1010-91	Bolt Special	1	
6	39-1655-11	Plain Washer	1	
7	39-1591-11	Plain Washer	1	
8	28-1010-18	Guide chain (Tight)	1	
9	31-1011-70	Tensioner Assly	1	Alt. To 28-1012-20
12	31-1010-30	Spring	1	
13	31-1011-20	Retainer	1	
14	39-1049-04	Bolt	1	
15	30-1011-41	Washer	1	
16	39-1014-21	Ring´O´	1	
17	39-1553-04	Flanged bolt	2	
18	13-1010-35	Timing Chain	1	

PLATE N°9: CLUTCH PLATE ASSLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1012-34	Clutch Comp.	1	
2	28-1012-35	Clutch plate assly	1	
3	28-1011-31	Wheel Clutch	1	
4	DD-1010-99	Plate Friction	5	
5	28-1011-34	Plate Clutch	4	
6	28-1011-32	Hub Clutch	1	
7	28-1012-14	Spring	6	
8	31-1011-37	Holder (Clutch spring)	1	
9	39-0980-04	Hex bolt	6	

PLATE N°10: CLUTCH HOUSING COMP.




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1012-33	Housing Comp Clutch	1	
2	28-1012-32	Primary Gear Assly	1	
3	28-1010-52	Housing Clutch	1	
4	28-1011-37	Holder	1	
5	39-1057-11	Plain Washer	1	
6	DD-1010-68	Spring (Beleville Washer)	1	
7	28-1010-87	Spring	3	
8	28-1010-63	Spring	2	
9	39-1710-09	Flat heard rivets	3	
10	28-1010-54	Collar	1	
11	28-1011-65	Spacer	1	

PLATE N°11: CLUTCH LEVER ASSLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1010-59	Clutch spindle assly	1	
2	39-2137-19	Oil seal	1	
3	39-2136-11	Plain washer	1	
4	28-1012-37	Clutch lever return spring	1	
5	28-1012-13	Internal lever	1	
6	28-1011-94	Plunger	1	
7	39-1034-20	Bearing	1	
8	28-1011-95	Holder	1	

PLATE N°12: MAIN SHAFT




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1012-17	Main shaft	1	
2	28-1010-35	Cross	1	
3	28-1012-18	Stem	1	
4	28-1010-37	Selecter Gear	1	
5	39-0213-11	Plain washer	1	
6	28-1010-38	Spring	2	
7	01-1801-23	Steel ball	2	
8	28-1010-39	Cup	1	
9	28-1012-50	Spacer	1	
10	39-2263-15	Hex Nut	1	
11	39-0154-08	Split pin	1	
12	28-1012-51	Cap	1	

PLATE N°13: GEAR TRANSMISSION




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1012-24	4th speed gear	1	
2	28-1012-44	3rd speed gear	1	
3	28-1012-26	2nd speed gear	1	
4	28-1012-27	1st speed gear	1	
5	21-1007-11	Circlip	2	
6	19-1010-16	Shoulder ring	2	
	19-1010-17	Shoulder ring N° 2	1	
	19-1010-18	Shoulder ring N° 2	1	
	19-1010-19	Shoulder ring N° 4	1	
	19-1010-20	Shoulder ring N° 5	1	
7	28-1012-29	Shaft intermediate	1	
8	28-1012-30	4th driver gear	1	
9	28-1012-45	Cluster gear	1	
10	28-1010-93	Kick driven gear	1	
11	39-1786-15	Hexagon nut/flange	1	

PLATE N°14: GEAR SHIFTER ASSLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1011-82	Gear shifter assly	1	
2	28-1010-70	Lever & Sector comp.	1	
3	28-1010-72	Gasket (G.S. Housing)	1	
4	39-0293-15	Nut	2	
5	39-1825-12	Spring washer	2	
6	39-0199-11	Plain washer	2	
7	28-1010-73	Gear shifter cover assly	1	
8	01-1011-31	Screw	1	
9	39-1826-12	Spring washer	1	
10	28-1011-76	Plug	1	For Vehicle without Self Start
11	20-1010-20	Gasket	1	
12	05-1010-83	Adjuster with nut	2	
13	06-1112-66	Switch Neutral	1	For Self Start Vehicle
14	06-1112-67	Cap Switch Neutral	1	(To be user in place of
15	BA-1321-41	Slider block	1	Plug 28-1011-76)

PLATE N°15: KICK SHAFT ASSLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1010-76	Kick shaft assly	1	
2	28-1010-77	Shast kick	1	
3	28-1010-78	Gear kick	1	
4	28-1010-79	Spring kick return	1	
5	28-1010-94	Ratchet kick	1	
6	28-1010-95	Guide spring(Nylon)	1	
7	28-1010-96	Spring Coil	1	
8	28-1010-97	Cup kick shaft	1	
9	39-0995-11	Plain washer	2	
10	39-0738-17	Circlip type C	4	
11	28-1010-81	Kick Starter	1	
12	28-1011-79	Rubber Sleeve	1	
13	39-1426-04	´D´ Bolt	1	
14	39-1874-11	Plain washer	1	
15	39-1875-11	Plain washer	1	
16	39-0694-15	Hex nut	1	
17	39-0200-11	Plain washer	1	
18	39-0265-12	Spring washer	1	

PLATE N°16: COWLINGS & SILENCER ASSEMBLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1010-84	Fan cover assly	1	
2	28-1011-36	Cowling	1	
3	39-0748-01	Screw Pan cross	5	
4	39-0747-01	Screw Pan cross	1	
5	28-1012-59	Silencer Assly	1	
6	39-0694-15	Hex nut	2	
7	39-0200-11	Plain washer	2	
8	39-0265-12	Washer Spring	2	
9	13-1011-65	Gasket	1	
10	39-0080-04	Hex head bolt	1	
11	39-0201-11	Plain washer	1	
12	39-0267-12	Spring washer	1	

PLATE N°17: MAGNETO ASSLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	CH-1110-04	Magneto assly	1	For Self Start Vehicle
2	CH-1110-05	Rotor assly	1	For Self Start Vehicle
3	CH-1110-06	Stator assly comp	1	For Self Start Vehicle
4	39-0197-11	Plain washer	3	
5	39-0262-12	Spring washer	3	
6	39-0757-01	Screw pan cros	3	
7	28-1110-20	Fan	1	
8	39-0198-11	Plain washer	4	
9	39-0263-12	Spring washer	4	
10	22-1504-51	Screw	4	

PLATE N°18: STATOR ASSLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	CH-1110-06	Stator Assly comp	1	For Self Start Vehicle
2	28-1110-07	Stator plate	1	
3	06-1110-58	Coil assly	1	
5	39-1601-01	Screw pan cross	4	For coil assly mtg
6	28-1110-12	Pulser coil Assly	1	
7	39-0900-12	Washer spring	7	
8	39-0840-01	Screw pan cross	2	
9	CH-1110-16	Stator Harness	1	For Self Start Vehucle
10	28-1110-14	Clamp	1	
11	39-1242-01	Screw pan cross	1	
12	28-1110-52	Clamp Pulser coil	1	
13	06-1112-47	Coil (Battery Chargin)	2	
14	06-1110-58	Lighting Coil N° II	3	
15	06-1112-51	Charging Coil	1	

PLATE N°19: SPARK PLUG AND H.T.COIL




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1110-21	Spark plug	1	
2	39-0745-01	Screw pan cros	2	
3	TE-0062-01	H.T. Coil	1	
4	28-1110-48	Cap spark plug	1	
5	31-1110-14	Grommet	1	
6	39-0198-11	Plain washer	2	
7	39-0263-12	Spring washer	2	

PLATE N°20: CARBURETTOR




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1210-01	Carburettor	1	
2	28-1210-28	Spring Compression	1	
3	28-1210-29	Valve Throttle	1	
4	28-1210-32	Plate Needle Clip	1	
5	28-1210-31	Needle Jet	1	
6	28-1210-30	Clip Bar	1	
7	28-1210-33	Top Complete	1	
8	28-1210-34	Spring Compression	1	
9	AB-1210-25	Screw Adjust	1	
10	28-1210-36	Screw Stop	1	
11	28-1210-37	Spring Compression	1	
12	28-1210-38	Jet Complete Slow	1	
13	28-1210-39	Float Complete	1	
14	28-1210-40	Pin Arm	1	
15	28-1210-41	Holder Needle Jet	1	
16	28-1210-42	Jet Main	1	
17	28-1210-43	Screw Washer	2	
18	28-1210-44	Valve Comp. Float	1	
	15-1210-39	Clip	1	N.I.
	28-1012-47	Clip	1	N.I.

PLATE N°21: AIR FILTER ASSEMBLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1210-12	Air filter Assly comp	1	
2	39-1583-04	Flanget bolt	2	
3	28-1210-09	Clamp (Intake Duct)	2	
4	28-1210-15	Cartridge Assly	1	
5	CL-1210-20	Cartridge half (Outlet)	1	
6	28-1210-17	Foam	1	
7	28-1210-18	Seal (Rubber)	1	
8	28-1210-20	Cartridge half (Inlet)	1	
9	28-1210-21	Bellow	1	
10	28-1210-02	Duct	1	
11	29-1210-19	Guide (Duct)	1	
12	28-1210-22	Spring	1	
13	28-1210-25	Sleeve (Carburettor)	1	
14	28-1210-27	Spring (Bellow to duct)	1	
15	28-1210-61	Flame arrestor	1	

PLATE N° 22: PUMP ASSLY OIL




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1210-63	Pump Oil Assly	1	
2	28-1210-62	Gear oil pump	1	
3	39-1575-11	Plain Washer	1	
4	39-0855-17	Circlip Type E	1	
5	39-0730-01	Screw Pan Cross	1	
6	39-0748-01	Screw Pan Cross	2	
7	39-1013-21	´O´Ring	2	

PLATE N° 23: PETROL TANK ASSLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1410-25	Petrol Tank Assly	1	
2	19-1410-14	Petrol Tank Cap assly	1	
3	15-1410-07	Gasket	1	
4	CH-2010-48	Tank Unit	1	
5	30-1410-28	Gasket	1	
6	30-1410-32	Bolt	4	
7	28-1410-22	Gasket for Petrol Tank	1	
8	28-1410-12	Clip for harness	1	
9	28-1410-21	Label	1	
10	35-1410-22	Beading petrol tank	1	

PLATE N° 24: FUEL COCK ASSLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	CH-1410-02	Fuel cock assly complete	1	
2	28-1410-31	Fuel pipe	1	
3	BA-1220-03	Pipe clip	2	
4	CH-1410-05	Knob for fuel cock	1	
5	39-1472-01	Screw WSP	1	
7	01-1402-28	Spring clip	1	
8	28-1410-28	Fuel cock assly	2	
10	28-1410-33	Cup filter	1	
11	15-1410-20	Gasket	1	
13	16-1410-07	Valve packing	1	
14	16-1410-18	Control valve	1	
15	01-1402-22	Pressure plate	1	
16	39-0005-01	Screw	2	
17	01-1402-23	Gasket	1	
18	39-0206-11	Plain washer	1	
19	01-1402-24	Nut	1	

PLATE N° 25: FRONT BRAKE DRUM ASSLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	35-1510-03	Fr. brake drum Assly / stud	1	
2	06-1501-12	Stud	5	
3	19-1510-05	Spacer	1	
4	35-1510-04	Speedo gear	1	
5	19-1510-08	Needle roller brg	1	
6	39-1274-20	Ball bearing	1	
7	39-0935-17	Circlip	1	
8	39-0265-12	Spring washer	5	
9	39-0694-15	Hex lock nut	2	
10	06-1510-23	Special nut	3	
11	19-1510-22	Cup for brake drum	1	
12	39-0201-11	Plain washer	1	
13	39-0422-15	Nylock nut	1	

PLATE N° 26: FRONT BRAKE ASSLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	06-1510-13	Front brake shoe assly	2	
2	01-1501-05	Return spring	1	
3	01-1502-09	Spring lock	1	
4	35-1510-01	Fr. brak Actualing shaft assly	1	
5	30-1510-38	Ring´O´	1	
6	30-1510-05	Indicator	1	
7	06-1510-12	Fr.brake Actualing lever	1	
8	39-0775-04	Bolt	1	
9	39-0798-15	Nut	1	
10	01-1501-09	Front brake Link	1	
11	05-1510-13	Front brake Link	1	
12	03-1501-11	Pin	1	
13	39-0151-08	Split pin	1	
14	01-1501-12	Bolt	1	
15	39-0299-15	Nut	1	
16	05-1010-83	Adjunter with nut	1	
17	35-1910-02	Speedo pinion	1	
18	35-1910-30	Support	1	
19	03-1801-16	´O´ring	1	
20	39-0842-11	Plain washer	1	
21	39-0900-12	Spring washer	1	
22	39-1545-01	Slotted cheese head screw	1	
23	35-1710-40	Grease nipple	1	
24	39-1452-20	Needle bearing	2	
25	19-1710-10	Grease seal	1	
26	35-1710-07	Front brake panel	1	
27	06-1501-04	Wear pad	2	
28	39-0740-11	Washer	1	

PLATE N° 27: REAR BRAKE DRUM ASSLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1510-01	Rear brake drum assly	1	
2	06-1501-12	Stud	5	
3	39-0265-12	Spring washer	5	
4	39-0694-15	Hex lock nut	2	
5	06-1510-23	Special nut	3	
6	28-1510-03	Back plate	1	
7	39-1286-01	Slotted cheede head Screw	3	
8	39-0263-12	Spring washer	3	
9	03-1502-24	´O´ring	1	
10	03-1502-25	´O´ring	2	

PLATE N° 28: REAR BRAKE ASSLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1510-04	Rr. brake shoe assly	2	
2	30-1510-69	Spring	2	
3	28-1510-13	Cam brake rear	1	
4	30-1510-38	Ring´O´	1	
5	39-0526-11	Washer	1	
6	28-1510-10	Rear brake lever	1	
7	39-1856-04	Hex bolt	1	
8	39-0198-11	Plain washer	1	
9	39-0263-12	Spring washer	1	
10	28-1510-25	Spring	1	
11	28-1510-20	Rear brake link	1	
12	28-1510-21	Rear brake link	1	
13	28-1510-14	Pin	1	
14	39-0146-08	Split pin	1	
15	39-0827-04	Bolt	1	
16	39-0276-14	Star washer	1	
17	39-0295-15	Hex nut	1	

PLATE N° 29: REAR BRAKE PEDAL ASSLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	35-1510-12	Brake Pedal	1	
2	12-1510-04	Spring	1	
3	39-0949-09	Snap head rivet	1	
4	12-1510-03	Brake Support	1	
5	12-1510-11	Pin for brake pedal	1	
6	24-1011-09	´O´Ring	2	
7	12-1510-12	Packing for brake pedal	1	
8	12-1510-05	Pin for cable	1	
9	39-0151-08	Split pin	1	
10	28-1510-23	Sleeve brake pedal	1	
11	39-1797-01	Hex Screw	3	
12	39-0198-11	Plain washer	3	
13	39-0265-12	Spring washer	3	
14	39-0292-15	Hex nut	2	
15	39-1205-01	Cheese head screw	1	
16	39-0261-12	Spring washer	1	
17	39-0375-11	Plain washer	1	
18	12-2010-03	Stop switch	1	

PLATE N° 30: WHEEL RIM/ COVERS / SPARE WHEEL




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	06-1503-03	Wheel rim	3	
2	06-1503-04	Wheel flange assly	3	
3	39-0087-04	Bolt (Round heard)	15	
4	39-1828-12	Spring washer	15	
5	39-0694-15	Hex lock nut	15	
	06-1503-02/00	Wheel rim aasly (Items: 1,2,3,4,5)	3	
6	28-1510-11	Wheel cover	2	
7	41070-3510-27/18	Tyre size 3.50x10 sport (IRC)	3	
	41070-3510-SC2/19	Tyre size 3.50x10 sport (MAXING)		OPTION
	41070-3510-D812/29	Tyre size 3.50x10 sport (DEESTONE)		
	41070-3510-P240/46	Tyre size 3.50x10 sport (WANDA)		
8	41075-3510-VC/18	Tube 3.50X10 VC (IRC)	3	OPTION
	41075-3510-VC/23	Tube 3.50X10 VC (MAXI-ONE)		
9	28-1611-27	Spare Wheel bkt. assly	1	
10	39-0119-04	Bolt	5	
	28-1510-16	Cap for wheel cover	2	N.I.
11	39-0265-12	Spring washer	7	
12	39-1040-11	Plain washer	7	
13	39-0694-15	Hex lock nut	4	
14	28-1510-15	Spare Wheel cover	1	
15	28-1510-17	Sp. bolt, Sp. Wheel cover	1	
	39-1899-21	´O´Ring- Wheel cap	2	N.I.
16	28-1510-19	Special nut Spare Wheel	1	
17	39-0254-11	Plain washer	1	

PLATE N° 31: CHASSIS AND GROMMETS




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	CH-1610-81	Bare chassis comp	1	
2	28-1611-56	Cap.(Upper Terminal)	1	
3	39-1785-23	Cut Grommet	2	
4	28-1611-58	Grommet - Diaphram Bottom	1	
5	28-1610-82	Grommet - Diaphram top	2	
6	28-1611-64	Grommet - Fuel pipe	1	
7	39-2236-23	Blind Grommet	2	
8	28-1611-47	Rubber Plug-A	2	
9	28-1611-48	Rubber Plug-B	3	
10	CL-1610-05	Cover Air Filter Slot	1	
11	28-1610-88	Cap For Rear Shock Absorber	1	
12	CH-1610-75	Seat trim	1	
13	39-0705-01	Screw	4	
14	19-1611-08	Rubber Buffer	2	N.I.
15	22-1902-45	Grommet	1	N.I.

PLATE N° 32: SHIELDS,SIDE RAIL,FR.SIDE INDICATORS & LUGGAGE BOX




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	CH-1610-51	Shield Main	1	
2	CH-2010-10	Fr. side indicator/lamp LH	1	
3	CH-2010-14	Fr. side indicator/lamp RH	1	
4	CH-2010-38	Lamp holder assly LH	1	
5	CH-2010-39	Lamp holder assly RH	1	
6	CD-2010-12	Lamp 12V-10W	2	For Front side indicator
7	39-1836-02	Crs.Rec.pan head tap.screw	18	
8	39-1505-11	Plain washer	28	
9	CB-1611-05	Clip nut	16	
10	39-1698-01	Screw Pan	2	
11	CH-1610-55	Shield Central	1	
12	CH-1610-56	´B´ Monogram	1	
13	CH-1610-74	Packing Central Shield	2	
14	39-0405-04	Bolt hex. head	2	
15	CH-1610-58	Name Plate	1	
16	CH-1610-62	Side Rail LH	1	
17	CH-1610-63	Side Rail RH	1	
18	39-1767-01	Screw Pan Cross	6	
19	39-0262-12	Spring Washer	6	
20	CH-2210-15	Luggage box assly/Lid	1	

PLATE N° 33: GRAB HANDLE ASSLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	CH-1610-65	Grab handle	1	
2	39-1505-11	Plain washer	2	
3	39-0262-12	Spring washer	2	
4	39-1844-01	Screw pan cross	2	
5	CH-1610-68	Sleeve grab handle botton	2	
6	CH-1610-69	Plate grab handle	1	
7	CH-1610-70	Packing grab handle	1	
8	CH-1610-71	Carrier plate assembly	1	
9	39-1540-11	Plain washer	6	
10	39-1181-01	Hex Screw	2	
11	39-1828-12	Spring washer	4	
12	39-1903-15	Hexagon nut	4	
13	39-0390-04	Hexagon screw	3	
14	39-0265-12	Spring washer	3	
15	CH-2010-18	Reflex reflector base	1	
16	CH-2010-19	Reflex reflector lens	1	
17	39-1040-11	Plain washer	3	
18	28-1611-08	Sleeve grab handle top	2	
19	39-2234-04	Hex.Bolt / flange	2	
20	39-0788-12	Spring washer	2	

PLATE N° 34: MUDGUARD / BONNETS /REAR N°.PLATE/TAIL PIECE




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	CH-1610-21	Mudguard Assly	1	
2	39-1902-04	Hex.bolt/flange	2	
3	39-0798-15	Hex nut/flange	2	
4	39-1765-11	Plain washer	1	
5	39-0262-12	Spring washer	1	
6	CH-1610-25	Mudguard side cover	1	
7	39-1767-01	Screw pan cross	1	
8	35-1610-60	Clip nut	1	
9	CH-1610-27	Engine bonnet assly	1	
10	CH-1610-31	Beading for engine bonnet	1	
11	CH-1610-32	Beading for bonnet LH	1	
12	CH-1610-37	Bonnet LH assly	1	
13	CH-1610-73	Tail piece	1	
14	39-1611-01	Cros rec. hex.screw	3	Alt. 39-0944-04
15	39-0263-12	Spring washer	3	
16	39-0292-15	Hexagon nut	3	
17	39-0219-11	Plain washer	3	
18	28-1610-72	Rear number plate	1	
19	39-1505-11	Plain washer	3	
20	39-1836-02	Cros rec. pan head screw	3	
21	CB-1611-05	Nut clip 5mm	3	
22	CH-1610-33	Brand Decal bonnet	2	
23	28-1611-16	Tube for bonnet	2	
24	28-1611-54	Cap for bonnet pin	2	
25	39-1956-04	Hex.bolt/flange small	4	
26	39-1540-11	Plain washer	4	
27	CH-1610-84	Cap for bonnet flange	4	

PLATE N° 35: STAND / MATTINGS




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1610-35	Stand assly	1	
	CH-1610-06	Stand assly	1	
2	02-1608-09	Hook plate	2	
3	28-1611-35	Spring for stand	2	
4	28-1610-94	Clip for Stand LH	1	
5	28-1610-95	Clip for Stand RH	1	
	28-1611-66	Shim for stand	2	
6	39-1797-01	Hex screw	4	
7	39-0263-12	Spring washer	4	
8	39-0292-15	Hex nut	4	
9	396-198-11	Plain washer	4	
10	CH-1610-44	Matting central	1	
11	CH-1610-46	Matting LH	1	
12	CH-1910-45	Matting RH	1	
13	CH-1610-47	Rubber nail matting	8	
14	28-1610-85	Rubber buffer	2	
	CH-1610-07	Damper for stand	2	
15	28-1611-66	Shim for stand	2	N.I.

PLATE N° 36: ENGINE LINK ASSLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1610-26	Engine link assly comp	1	
2	28-1610-27	Engine link assly	1	
3	28-1610-28	Silent bush for link	1	
4	28-1611-15	Silent bush II link	1	
5	28-1610-76	Distance piece assly	1	
6	28-1610-61	Damper for link	2	
7	28-1610-62	Space Tube - Damper	1	
8	39-1840-11	Plain washer	1	
9	39-1841-11	Plain washer	1	
10	39-1846-04	Hex bolt	1	
11	36-0265-12	Spring washer	1	
12	28-1610-30	Bolt for Engine link	1	
13	28-1611-18	Bracket Gear cable	1	
14	29-0422-15	Nylock Nut	1	
15	28-1610-29	Foundation Bolt	1	
16	39-0269-12	Spring washer	1	
17	39-0303-15	Nut	1	
18	39-0240-11	Plain washer	1	

PLATE N° 37: FRONT HUB ASSEMBLY / FRONT SHOCK ABSORBER




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	35-1710-44	Front wheel hub assly	1	
2	35-1710-04	Hub pin	1	
3	35-1710-05	Lock plate	1	
4	35-0263-12	Spring washer	1	
5	39-0062-04	Hex. head screw	1	
6	39-1453-21	´O´ring	1	
7	39-1454-11	Plain washer	1	
8	21-1003-24	Circlip	1	
9	35-1710-14	Shjock absorber Mtg. bracket	1	
10	39-0100-04	Bolt	2	
11	39-0265-12	Spring washer	2	
12	39-0694-15	Hex lock nut	2	
13	CD-1710-05	Fr. Shock Absorber / spring	1	
14	35-1710-17	Fr. Suspension spring	1	
15	03-0801-14	Shoulder washer	2	
16	39-1850-04	Hex.bolt/flange	1	
17	39-0422-15	Nyloc nut	1	
18	39-2058-11	Washer for front brake panel	1	

PLATE N° 38: ANTIDIVE LINK ASSLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	35-1710-09	Link with Bush	1	
2	35-1710-11	Bush for Link big	2	
3	35-1710-12	Bush for Link small	2	
4	23-1613-05	Grease nipple	1	
5	35-1710-33	Grease nipple	1	
6	39-0740-11	Plain washer	1	
7	39-1823-21	Ring´O´	4	
8	35-1710-13	Cap washer	4	
9	39-0267-12	Spring washer	2	
10	39-1456-04	Bolt for panel	1	
11	39-1457-04	Bolt for Link	1	
12	39-0807-08	Pin snap	1	

PLATE N° 39: REAR SHOCK ABSORBER




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1710-05	Rear shock absorber assly	1	
2	28-1710-06	Rear shock absorber	1	
3	28-1710-07	Rear Suspension spring	1	
4	39-1793-04	Hex bolt	1	
5	39-0266-12	Spring washer	2	
6	39-0295-15	Hex nut	1	
7	03-1703-51	Damper bracket assly	1	
8	39-0265-12	Spring washer	1	
9	39-0319-15	Nut	1	

PLATE N° 40: STEERING COLUMN ASSLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	CH-1810-16	Steering column assly	1	
2	03-1810-14	Shoulder washer	2	
3	03-1801-18	Bush	2	
4	03-1801-16	´O´Ring	2	
5	39-1772-20	Shell bearing	2	
6	35-1710-32	Grease nipple	1	
7	07-1810-06	Dust cover	1	
8	07-1810-04	Bearing race	1	
9	06-1810-68	Steel ball with cage	1	
10	06-1801-08	Lower bearing race	1	
11	06-1801-07	Upper bearing race	1	
12	07-1810-07	Steel bal / cage(Upper	1	
13	01-1801-28	Bearing race	1	
14	01-1801-29	Spacer Washer	1	
15	01-1801-30	Lock ring	1	

PLATE N° 41: HANDLE BAR / COVERS




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	CH-1810-18	Handle bar assly	1	
2	35-1910-13	Silent bush assembly	4	
3	35-1810-16	Handle bar bolt	1	
4	CH-1810-10	Cover Mounting btacket	1	
5	39-0262-12	Spring washer	4	
6	39-0071-04	Hex bolt	2	
7	CH-1810-11	Handle bar cover rear	1	
8	CB-1611-05	nut clip 5mm	6	
9	39-1505-11	Plain washer	6	
10	39-1900-02	Cross pan Head screw	4	
11	CH-1810-12	Handle bar cover front	1	
12	39-2235-02	Cr. rec. pan head screw	2	
13	CH-1810-14	Fairing	1	
14	39-1542-11	Plain washer	4	
15	39-0261-12	Spring washer	4	
16	39-0921-01	Screw pan cross	4	
17	39-1910-24	Nylon washer	1	
18	28-1810-25	Grommet Handle bar cover	1	
19	28-1110-59	Throttle sensor	1	
20	39-0886-01	Screw pan cros	2	
21	39-1505-11	Plain washer	2	
22	28-1810-20	Packing	2	N.I.

PLATE N° 42: HANDLE BAR CONTROLS




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1910-56	Gear Contrl Tube Assly	1	
2	28-1910-51	Clutch lever	1	
3	28-1910-53	Lever mounting bolt	1	
4	39-1184-15	Nylock nut	2	
5	28-1910-48	Gear control link	1	
6	39-0942-12	Special washer	1	
7	39-0941-11	Plain washer	1	
8	19-1910-16	Spring clip	2	
9	34-1910-13	Gas control tube assly	1	
10	28-1910-36	Gas control link	1	
11	CH-1910-10	Hand grip	2	
12	CH-1910-05	Holder RH	1	
13	CH-1910-06	Fr. brake lever	1	
14	CH-1910-07	Lever mounting bolt	1	
15	28-1910-13	Choke lever	1	
16	39-0198-11	Plain washer	1	
17	39-0725-04	Hex bolt	1	
18	39-1424-11	Plain washer	2	
19	28-1810-33	Cover for holder LH	1	
20	35-2010-10	Clamp	1	For Front Brake cable
21	39-0745-01	Screw pan cross	1	
22	39-0198-11	Plain washer	1	
23	39-0263-12	Spring washer	1	
24	39-0292-15	Hex nut	1	
25	28-1910-50	Holder LH	1	

PLATE N° 43: CONTROL CABLES




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1910-14	Chaoke cable assly	1	
2	28-1910-30	Accelerater cable comp	1	
3	28-1910-46	Clutch cable comp	1	
4	28-1910-41	Inner cable clutch	1	
5	28-1910-35	Spring for cable	2	
6	16-1910-36	Screw Terminal Assly	2	
	35-1910-28	Screw Terminal Assly	2	For Gear Cable
7	28-1910-04	Gear cable comp (Grey)	1	
8	28-1910-07	Gear cable comp (Black)	1	
9	28-1910-05	Inner cable for gear	2	
10	30-1910-45	Spring	1	
11	28-1910-01	Rear brake cable comp	1	
12	28-1910-02	Inner cable rear brake	1	
13	28-1910-31	Front brake cable comp	1	
14	28-1910-38	Inner cable fr. comp	1	
15	28-1910-33	Speedo cable comp	1	
16	35-1910-52	Speedo cable inner	1	
17	31-1910-32	Boot	1	
18	28-1910-40	Screw Terminal assly	1	
	CR-1910-14	Screw Terminal assly	1	For Clutch cable

PLATE N° 44: STEERING LOCK




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1810-24	Lock barrel assly	1	
2	06-1810-35	Spring plate	1	
3	06-1810-49	Lock cam	1	
4	39-1604-01	Screw pan cross	1	
5	06-2012-46	Ignition switch	1	For Selt Start Vehucle
6	39-1545-01	Slotted Ch. heard screw	1	Alt. to 39-0840-01
7	CH-1610-48	Lock set 4 in 1	1	Not illustrated
	06-1810-34	Rubber racherg -lock	1	Not illustrated

PLATE N° 45: HEAD LAMP / INSTRUMENT PANEL




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	CH-2010-02	Head light /lamp assly	1	
2	CH-2010-03	Head light assly	1	
3	DD-2010-28	Lamp 12V 45/40W (´E´)	1	
4	39-0834-15	Hex. nut	4	
5	39-0732-12	Spring washer	4	
6	39-1506-11	Plain washer	4	
7	CH-1910-17	Instrument cluster/lamp	1	
8	30-2010-84	Lamp 12V/2W	4	
9	39-1505-11	Plain washer	4	
10	39-1837-02	Crs. Hd.Tap screw	4	

PLATE N° 46: TAIL LAMP / SWITCHES




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	CH-2010-06	Tail Light /Lamp assly	1	
2	31-2010-60	Lamp 12V 10/5 W	1	
3	CD-2010-12	Lamp 12V 10W-Amber	2	
4	39-0375-11	Plain washer	2	
5	39-0810-02	Crs Pn. Hd. Tp. Screw	2	
6	CH-2010-41	Control switch LH	1	
7	CH-2010-42	Control switch RH	1	
8	39-0223-11	Plain washer	4	
9	39-2251-02	Crs. Hd.Tp. Screw	4	
10	CH-2010-49	Tail light/blinker lens	1	
12	CH-2010-45	Tail bulb holder	1	
13	28-2010-46	Screw Tail light Glass	2	

PLATE N° 47: ELECTRICALS




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	CH-2010-40	Wiring harness	1	For Self Start Vehicle(Not illustrated)
2	35-2010-10	Clip	2	For Stator Harness & Wiring Harness
	28-2010-56	Clamp	2	For Self Start Vehicle
4	CH-1610-60	Beeper/Flasher bracket	1	
5	35-2011-22	Beeper (DC Operation)	1	For Self Start Vehicle
6	39-0839-02	Slotted pn,Hd,tap screw	2	
7	31-2010-03	Relay Assly	1	For Self Start Vehicle
8	29-2010-32	Holder for Relay	1	For Self Start Vehicle
9	39-0198-11	Plain washer	4	
10	CH-2010-54	Horn 12 V V DC	1	
11	39-0262-12	Spring washer	4	
12	39-1698-01	Screw pan cross	2	
13	CD-2010-30	Regulator assembly	1	
14	39-0263-12	Spring washer	5	
15	39-0745-01	Screw pan cross	5	
16	28-1110-58	C.D.I.	1	
	28-1110-64	C.D.I. with Damper	1	
17	22-1110-54	Damper	1	
18	28-1610-25	Battery bracket	1	For Self Start Vehicle
19	39-1767-01	Screw pan cross	2	

PLATE N° 48: ELECTRICAL EQUIPMENTS(FOR SELF START VEHICLE)




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	28-1110-45	Starter Motor	1	
2	39-0200-11	Plain Washer	3	
3	39-0265-12	Spring Washer	3	
4	39-0294-15	Nut	3	
5	06-2014-02	Battery 12V-9AH/Charged	1	
6	06-2013-14	Rubber Strap	1	
7	06-1612-95	Rubber Pad II	5	
8	28-2010-48	Starter Relay	1	Alt. To. 28-2010-80
9	39-1611-01	Cross rec. hexagon screw	4	
10	39-0263-12	Spring Washer	4	
11	39-0198-11	Plain Washer	6	
12	39-0292-15	Hex. Nut	4	
13	CD-2010-27	Assly Regulator	1	
14	28-2010-55	Insulating cap (BLACK)	1	
15	28-2010-40	Cable Assly	1	Battery to Starter Motor
16	28-2010-39	Cable Assly Red	1	Starter Relay to Battery
17	06-2012-64	Fuse assly	1	
18	06-2012-84	Fuse 10A	1	
19	28-2010-54	Insulating cap (RED)	1	

PLATE N° 49: DUAL SEAT ASSLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	CH-2110-02	Dual seat assembly	1	
2	19-2110-86	Hinge bracket	2	
3	39-0263-12	Spring easher	4	
4	39-0292-15	Hex nut	2	
5	28-2110-11	Hinge bracket assly fixed	1	
6	15-2110-15	Pin	1	
7	39-0200-11	Plain washer	1	
8	39-0146-08	Split pin	1	
9	39-0390-04	Hex screw	3	
10	39-0265-12	Spring washer	3	
11	CH-2110-08	Cable seat lock	1	
12	CH-1610-72	Seat lock mechanism	1	
13	39-0198-11	Plain washer	2	
14	39-0062-04	Hex bolt	2	
15	39-0263-12	Spring washer	2	
16	CH-1610-67	Guide bracket-seat lock	1	
17	CH-2110-09	Seat lock assly	1	
18	29-1611-57	Clip for seat lock	1	
19	19-2110-90	Damper	4	Fitted on seat base
20	CH-2110-11	Damper	2	

PLATE N° 50: LUGGAGE HOOK / FOOT REST ASSLY




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	CH-2110-10	Locable Hook	1	
	CH-1610-48	Lock Set 4 in 1	1	ALTERNATIVE
2	01-1106-09	Plain washer	2	
3	01-1605-09	Hex.bolt	2	
4	28-1610-92	Packing Luggage hook	1	
5	39-0262-12	Spring washer	2	
6	39-0291-15	Hex nut	2	
7	39-0198-11	Plain washer	4	OPTIONAL
8	39-0263-12	Spring washer	4	OPTIONAL
9	39-0078-04	Hex bolt	4	OPTIONAL
10	CH-2210-06	All Round Foot rest	1	OPTIONAL
11	CH-2210-05	Foot rest Bracket	1	OPTIONAL
12	39-0435-01	Screw	1	OPTIONAL
13	39-0119-04	Bolt	2	OPTIONAL
14	39-1540-11	Plain Washer	3	OPTIONAL
15	39-0265-12	Spring washer	3	OPTIONAL
16	CH-1610-47	Matting nail	3	OPTIONAL
17	CH-2210-10	Matting for all round foot rest	1	OPTIONAL

PLATE N° 51: MIRROR / TOOL KIT




FIG. No.	PART. No.	DESCRIPTION	QTY/ VEH.	REMARKS
1	CH-2210-25	Tool kit	1	
2	35-2210-02	Rubber strap	1	For holding tool kit
3	CH-2210-21	Mirror assly LH	1	
4	CH-2210-23	Mirror assly RH	1	
5	CH-2210-22	Adapter LH	1	
6	CH-2210-24	Adapter RH	1	Not Ilustrated
7	39-0200-11	Plain washer	2	
8	39-0265-12	Spring washer	2	
9	39-1247-04	Hex socket head screw	2	

PART INDEX

PART NO.	FIG. NO.	PAGE NO.
01-1006-10	4	5
01-1011-31	8	14
01-1106-09	2	50
01-1402-22	15	24
01-1402-23	17	24
01-1402-24	19	24
01-1402-28	7	24
01-1501-05	2	26
01-1501-09	10	26
01-1501-12	14	26
01-1502-09	3	26
01-1605-09	3	50
01-1701-10	23	2
01-1701-11	13	1
01-1801-23	7	12
01-1801-28	13	40
01-1801-29	14	40
01-1801-30	15	40
02-1608-09	2	35
03-0801-14	15	37
03-1003-35	2	2
03-1501-11	12	26
03-1502-24	9	27
03-1502-25	10	27
03-1703-51	7	39
03-1801-16	19	26
03-1801-16	4	40
03-1801-18	3	40
03-1810-14	2	40
05-1010-83	12	14
05-1010-83	16	26
05-1510-12	14	1
05-1510-12	2	3
05-1510-13	11	26
06-1110-58	3	18
06-1110-58	14	18
06-1112-47	13	18
06-1112-51	15	18
06-1112-66	13	14
06-1112-67	14	14
06-1501-04	27	26
06-1501-12	2	25
06-1501-12	2	27
06-1503-02/00	5	30
06-1503-03	1	30
06-1503-04	2	30
06-1510-12	7	26
06-1510-13	1	26
06-1510-23	10	25
06-1510-23	5	27
06-1612-95	7	48
06-1801-07	11	40
06-1801-08	10	40
06-1810-34	8	44
06-1810-35	2	44
06-1810-49	3	44
06-1810-68	9	40
06-2012-46	5	44
06-2012-64	17	48
06-2012-84	18	48
06-2013-14	6	48
06-2014-02	5	48
07-1810-04	8	40
07-1810-06	7	40
07-1810-07	12	40
12-1510-03	4	29
12-1510-04	2	29
12-1510-05	8	29
12-1510-11	5	29
12-1510-12	7	29
12-2010-03	18	29
13-1010-24	12	7
13-1010-29	2	8
13-1010-31	7	6
13-1010-35	18	8
13-1011-65	9	16
15-1210-39	18	20
15-1410-07	3	23
15-1410-20	11	24
15-2110-15	6	49
16-1410-07	13	24
16-1410-18	14	24
16-1910-36	6	43
19-1010-16	6	13
19-1010-17	6	13
19-1010-18	6	13
19-1010-19	6	13
19-1010-20	6	13
19-1410-14	2	23
19-1510-05	3	25
19-1510-08	5	25
19-1510-22	11	25
19-1611-08	14	31
19-1710-10	25	26
19-1910-16	8	42
19-2110-86	2	49
19-2110-90	19	49
20-1010-20	11	14
21-1003-24	8	37
21-1007-11	5	13
22-1110-54	17	47
22-1504-51	3	8
22-1504-51	10	17
22-1902-45	15	31
23-1613-05	4	38
24-1011-09	6	29
28-1010-05	11	1
28-1010-06	10	1
28-1010-11	5	5
28-1010-12	20	1
28-1010-13	11	7
28-1010-14	12	2
28-1010-17	3	4
28-1010-18	8	8
28-1010-19	1	8
28-1010-21	4	8
28-1010-22	19	2
28-1010-23	5	4
28-1010-24	11	4
28-1010-25	1	5
28-1010-32	8	7
28-1010-35	2	12
28-1010-37	4	12
28-1010-38	6	12
28-1010-39	8	12
28-1010-48	24	2
28-1010-49	7	5
28-1010-52	3	10
28-1010-54	10	10
28-1010-57	13	7
28-1010-58	6	5
28-1010-59	1	11
28-1010-63	8	10
28-1010-70	2	14
28-1010-72	3	14
28-1010-73	7	14
28-1010-76	1	15
28-1010-77	2	15
28-1010-78	3	15
28-1010-79	4	15
28-1010-80	22	1
28-1010-81	11	15
28-1010-84	1	16
28-1010-86	1	4
28-1010-87	7	10
28-1010-89	21	2
28-1010-91	5	8
28-1010-92	26	1
28-1010-93	10	13
28-1010-94	5	15
28-1010-95	6	15
28-1010-96	7	15
28-1010-97	8	15
28-1011-03	8	3
28-1011-07	3	5
28-1011-09	5	2
28-1011-10	9	5
28-1011-15	7	1
28-1011-18	2	4
28-1011-19	4	6

PART INDEX

PART NO.	FIG. NO.	PAGE NO.
28-1011-28	3	6
28-1011-29	7	7
28-1011-30	13	6
28-1011-31	3	9
28-1011-32	6	9
28-1011-34	5	9
28-1011-36	2	16
28-1011-37	4	10
28-1011-41	15	1
28-1011-45	24	1
28-1011-46	6	1
28-1011-65	11	10
28-1011-68	9	1
28-1011-70	11	2
28-1011-73	25	1
28-1011-74	18	1
28-1011-76	10	14
28-1011-78	10	6
28-1011-79	12	15
28-1011-80	12	1
28-1011-81	1	1
28-1011-82	1	14
28-1011-94	6	11
28-1011-95	8	11
28-1012-06	1	6
28-1012-07	6	4
28-1012-13	5	11
28-1012-14	7	9
28-1012-17	1	12
28-1012-18	3	12
28-1012-20	9	8
28-1012-21	2	5
28-1012-24	1	13
28-1012-26	3	13
28-1012-27	4	13
28-1012-29	7	13
28-1012-30	8	13
28-1012-32	2	10
28-1012-33	1	10
28-1012-34	1	9
28-1012-35	2	9
28-1012-36	1	3
28-1012-37	4	11
28-1012-41	12	6
28-1012-42	1	7
28-1012-43	2	7
28-1012-44	2	13
28-1012-45	9	13
28-1012-46	17	1
28-1012-47	18	20
28-1012-50	9	12
28-1012-51	12	12
28-1012-59	5	16
28-1110-07	2	18
28-1110-12	6	18
28-1110-14	10	18
28-1110-20	7	17
28-1110-21	1	19
28-1110-45	1	48
28-1110-48	4	19
28-1110-52	12	18
28-1110-58	16	47
28-1110-59	19	41
28-1110-64	16	47
28-1210-01	1	20
28-1210-02	10	21
28-1210-09	3	21
28-1210-12	1	21
28-1210-15	4	21
28-1210-17	6	21
28-1210-18	7	21
28-1210-20	8	21
28-1210-21	9	21
28-1210-22	12	21
28-1210-25	13	21
28-1210-27	14	21
28-1210-28	2	20
28-1210-29	3	20
28-1210-30	6	20
28-1210-31	5	20
28-1210-32	4	20
28-1210-33	7	20
28-1210-34	8	20
28-1210-36	10	20
28-1210-37	11	20
28-1210-38	12	20
28-1210-39	13	20
28-1210-40	14	20
28-1210-41	15	20
28-1210-42	16	20
28-1210-43	17	20
28-1210-44	18	20
28-1210-61	15	21
28-1210-62	2	22
28-1210-63	1	22
28-1410-12	8	23
28-1410-21	9	23
28-1410-22	7	23
28-1410-25	1	23
28-1410-28	8	24
28-1410-31	2	24
28-1410-33	10	24
28-1510-01	1	27
28-1510-03	6	27
28-1510-04	1	28
28-1510-10	6	28
28-1510-11	6	30
28-1510-13	3	28
28-1510-14	13	28
28-1510-15	14	30
28-1510-16	10	30
28-1510-17	15	30
28-1510-19	16	30
28-1510-20	11	28
28-1510-21	12	28
28-1510-23	10	29
28-1510-25	10	28
28-1610-25	18	47
28-1610-26	1	36
28-1610-27	2	36
28-1610-28	3	36
28-1610-29	15	36
28-1610-30	12	36
28-1610-35	1	35
28-1610-61	6	36
28-1610-62	7	36
28-1610-72	18	34
28-1610-76	5	36
28-1610-82	5	31
28-1610-85	14	35
28-1610-88	11	31
28-1610-92	4	50
28-1610-94	4	35
28-1610-95	5	35
28-1611-08	18	33
28-1611-15	4	36
28-1611-16	23	34
28-1611-18	13	36
28-1611-27	9	30
28-1611-35	3	35
28-1611-47	8	31
28-1611-48	9	31
28-1611-54	24	34
28-1611-56	2	31
28-1611-58	4	31
28-1611-64	6	31
28-1611-66	5	35
28-1611-66	15	35
28-1710-05	1	39
28-1710-06	2	39
28-1710-07	3	39
28-1810-20	22	41
28-1810-24	1	44
28-1810-25	18	41
28-1810-33	19	42
28-1910-01	11	43
28-1910-02	12	43
28-1910-04	7	43
28-1910-05	9	43
28-1910-07	8	43

PART INDEX

PART NO.	FIG. NO.	PAGE NO.
28-1910-13	15	42
28-1910-14	1	43
28-1910-30	2	43
28-1910-31	13	43
28-1910-33	15	43
28-1910-35	5	43
28-1910-36	10	42
28-1910-38	14	43
28-1910-40	18	43
28-1910-41	4	43
28-1910-46	3	43
28-1910-48	5	42
28-1910-50	25	42
28-1910-51	2	42
28-1910-53	3	42
28-1910-56	1	42
28-2010-39	16	48
28-2010-40	15	48
28-2010-46	13	46
28-2010-48	8	48
28-2010-54	19	48
28-2010-55	14	48
28-2010-56	2	47
28-2110-11	5	49
29-0422-15	14	36
29-1210-19	11	21
29-1611-57	18	49
29-2010-32	8	47
30-1011-41	15	8
30-1410-28	5	23
30-1410-32	6	23
30-1510-05	6	26
30-1510-38	6	3
30-1510-38	5	26
30-1510-38	4	28
30-1510-69	2	28
30-1910-45	10	43
30-2010-84	8	45
31-1010-18	5	7
31-1010-19	6	7
31-1010-22	4	7
31-1010-30	12	8
31-1011-20	13	8
31-1011-37	8	9
31-1011-70	9	8
31-1110-14	5	19
31-1910-32	17	43
31-2010-03	7	47
31-2010-60	2	46
34-1910-13	9	42
35-0263-12	4	37
35-1410-22	10	23
35-1510-01	4	26
35-1510-03	1	25
35-1510-04	4	25
35-1510-12	1	29
35-1610-60	8	34
35-1710-04	2	37
35-1710-05	3	37
35-1710-07	26	26
35-1710-09	1	38
35-1710-11	2	38
35-1710-12	3	38
35-1710-13	8	38
35-1710-14	9	37
35-1710-17	14	37
35-1710-32	6	40
35-1710-33	5	38
35-1710-40	23	26
35-1710-44	1	37
35-1810-16	3	41
35-1910-02	17	26
35-1910-13	2	41
35-1910-28	6	43
35-1910-30	18	26
35-1910-52	16	43
35-2010-10	20	42
35-2010-10	2	47
35-2011-22	5	47
35-2210-02	2	51
36-0265-12	11	36
39-0005-01	16	24
39-0062-04	5	37
39-0062-04	14	49
39-0071-04	6	41
39-0078-04	9	50
39-0080-04	10	16
39-0087-04	3	30
39-0100-04	10	37
39-0119-04	8	2
39-0119-04	10	30
39-0119-04	13	50
39-0142-07	8	5
39-0146-08	14	28
39-0146-08	8	49
39-0151-08	13	26
39-0151-08	9	29
39-0154-08	11	12
39-0197-11	4	17
39-0198-11	8	17
39-0198-11	6	19
39-0198-11	8	28
39-0198-11	12	29
39-0198-11	16	42
39-0198-11	22	42
39-0198-11	9	47
39-0198-11	11	48
39-0198-11	13	49
39-0198-11	7	50
39-0199-11	17	2
39-0199-11	9	3
39-0199-11	6	14
39-0200-11	9	2
39-0200-11	17	15
39-0200-11	7	16
39-0200-11	2	48
39-0200-11	7	49
39-0200-11	7	51
39-0201-11	11	16
39-0201-11	12	25
39-0206-11	18	24
39-0213-11	5	12
39-0219-11	17	34
39-0223-11	8	46
39-0240-11	18	36
39-0254-11	17	30
39-0261-12	16	29
39-0261-12	15	41
39-0262-12	5	17
39-0262-12	19	32
39-0262-12	3	33
39-0262-12	5	34
39-0262-12	5	41
39-0262-12	11	47
39-0262-12	5	50
39-0263-12	9	17
39-0263-12	7	19
39-0263-12	8	27
39-0263-12	9	28
39-0263-12	15	34
39-0263-12	7	35
39-0263-12	23	42
39-0263-12	14	47
39-0263-12	10	48
39-0263-12	3	49
39-0263-12	15	49
39-0263-12	8	50
39-0264-12	18	2
39-0264-12	10	3
39-0265-12	10	2
39-0265-12	18	15
39-0265-12	8	16
39-0265-12	8	25
39-0265-12	3	27
39-0265-12	13	29
39-0265-12	11	30
39-0265-12	14	33
39-0265-12	11	37
39-0265-12	8	39
39-0265-12	3	48

PART INDEX

PART NO.	FIG. NO.	PAGE NO.
39-0265-12	10	49
39-0265-12	15	50
39-0265-12	8	51
39-0266-12	5	39
39-0267-12	12	16
39-0267-12	9	38
39-0269-12	16	36
39-0276-14	16	28
39-0291-15	6	50
39-0292-15	14	29
39-0292-15	16	34
39-0292-15	8	35
39-0292-15	24	42
39-0292-15	12	48
39-0292-15	4	49
39-0293-15	16	2
39-0293-15	11	3
39-0293-15	4	14
39-0294-15	4	48
39-0295-15	17	28
39-0295-15	6	39
39-0299-15	15	26
39-0303-15	17	36
39-0319-15	9	39
39-0342-17	4	3
39-0375-11	17	29
39-0375-11	4	46
39-0390-04	13	33
39-0390-04	9	49
39-0405-04	14	32
39-0422-15	13	25
39-0422-15	17	37
39-0435-01	12	50
39-0444-04	14	2
39-0526-11	5	28
39-0694-15	16	15
39-0694-15	6	16
39-0694-15	9	25
39-0694-15	4	27
39-0694-15	5	30
39-0694-15	13	30
39-0694-15	12	37
39-0705-01	13	31
39-0725-04	17	42
39-0730-01	5	22
39-0732-12	5	45
39-0737-12	11	5
39-0738-17	10	15
39-0739-04	6	6
39-0740-11	28	26
39-0740-11	6	38
39-0745-01	2	19
39-0745-01	21	42
39-0745-01	15	47
39-0746-01	8	1
39-0746-01	14	7
39-0747-01	4	16
39-0748-01	3	16
39-0748-01	6	22
39-0757-01	6	17
39-0775-04	8	26
39-0788-12	20	33
39-0798-15	9	26
39-0798-15	3	34
39-0807-08	12	38
39-0810-02	5	46
39-0827-04	15	28
39-0834-15	4	45
39-0839-02	6	47
39-0840-01	8	18
39-0842-11	20	26
39-0855-17	4	22
39-0886-01	20	41
39-0892-04	6	2
39-0900-12	7	18
39-0900-12	21	26
39-0921-01	16	41
39-0935-17	7	25
39-0941-11	7	42
39-0942-12	6	42
39-0949-09	3	29
39-0973-15	10	7
39-0980-04	9	9
39-0985-17	9	4
39-0995-11	9	15
39-0999-06	19	1
39-1000-06	4	4
39-1013-21	7	22
39-1014-21	16	8
39-1024-01	9	7
39-1034-20	7	11
39-1035-19	3	7
39-1040-11	12	30
39-1040-11	17	33
39-1049-04	14	8
39-1057-11	5	10
39-1181-01	10	33
39-1184-15	4	42
39-1205-01	15	29
39-1242-01	11	18
39-1247-04	9	51
39-1263-21	8	6
39-1264-21	5	6
39-1265-19	4	2
39-1274-20	6	25
39-1283-21	14	6
39-1286-01	7	27
39-1338-04	15	2
39-1358-15	10	5
39-1414-02	21	1
39-1424-11	18	42
39-1426-04	13	15
39-1450-20	3	3
39-1452-20	24	26
39-1453-21	6	37
39-1454-11	7	37
39-1456-04	10	38
39-1457-04	11	38
39-1472-01	5	24
39-1505-11	8	32
39-1505-11	2	33
39-1505-11	19	34
39-1505-11	9	41
39-1505-11	21	41
39-1505-11	9	45
39-1506-11	6	45
39-1540-11	9	33
39-1540-11	26	34
39-1540-11	14	50
39-1542-11	14	41
39-1543-21	8	4
39-1545-01	22	26
39-1545-01	6	44
39-1553-04	17	8
39-1574-21	22	2
39-1575-11	3	22
39-1583-04	7	3
39-1583-04	2	21
39-1591-11	7	8
39-1601-01	5	18
39-1604-01	4	44
39-1611-01	14	34
39-1611-01	9	48
39-1651-15	9	6
39-1652-05	5	1
39-1652-05	7	2
39-1653-05	4	1
39-1654-05	2	1
39-1655-11	6	8
39-1656-21	13	2
39-1657-21	20	2
39-1658-05	3	1
39-1658-05	1	2
39-1660-05	2	6
39-1698-01	10	32
39-1698-01	12	47
39-1710-09	9	10
39-1712-04	15	6
39-1722-19	5	3
39-1765-11	4	34

PART INDEX

PART NO.	FIG. NO.	PAGE NO.
39-1767-01	18	32
39-1767-01	7	34
39-1767-01	19	47
39-1772-20	5	40
39-1785-23	3	31
39-1786-15	11	13
39-1793-04	4	39
39-1796-11	16	1
39-1797-01	11	29
39-1797-01	6	35
39-1823-21	7	38
39-1825-12	5	14
39-1826-12	9	14
39-1828-12	4	30
39-1828-12	11	33
39-1836-02	7	32
39-1836-02	20	34
39-1837-02	10	45
39-1840-11	8	36
39-1841-11	9	36
39-1844-01	4	33
39-1845-04	11	6
39-1846-04	10	36
39-1850-04	16	37
39-1856-04	7	28
39-1874-11	14	15
39-1875-11	15	15
39-1899-21	15	30
39-1900-02	10	41
39-1902-04	2	34
39-1903-15	12	33
39-1910-24	17	41
39-1922-06	23	1
39-1956-04	25	34
39-2058-11	18	37
39-2133-19	3	2
39-2136-11	3	11
39-2137-19	2	11
39-2234-04	19	33
39-2235-02	12	41
39-2236-23	7	31
39-2251-02	9	46
39-2263-15	10	12
396-198-11	9	35
41070-3510-27/18	7	30
41070-3510-D812/29	7	30
41070-3510-P240/46	7	30
41070-3510-SC2/19	7	30
41075-3510-VC/18	8	30
41075-3510-VC/23	8	30
AA-1010-25	10	4
AA-1013-34	7	4
AB-1210-25	9	20
BA-1220-03	3	24
BA-1321-41	15	14
CB-1611-05	9	32
CB-1611-05	21	34
CB-1611-05	8	41
CD-1710-05	13	37
CD-2010-12	6	32
CD-2010-12	3	46
CD-2010-27	13	48
CD-2010-30	13	47
CH-1110-04	1	17
CH-1110-05	2	17
CH-1110-06	3	17
CH-1110-06	1	18
CH-1110-16	9	18
CH-1410-02	1	24
CH-1410-05	4	24
CH-1610-06	1	35
CH-1610-07	14	35
CH-1610-21	1	34
CH-1610-25	6	34
CH-1610-27	9	34
CH-1610-31	10	34
CH-1610-32	11	34
CH-1610-33	22	34
CH-1610-37	12	34
CH-1610-44	10	35
CH-1610-46	11	35
CH-1610-47	13	35
CH-1610-47	16	50
CH-1610-48	7	44
CH-1610-48	1	50
CH-1610-51	1	32
CH-1610-55	11	32
CH-1610-56	12	32
CH-1610-58	15	32
CH-1610-60	4	47
CH-1610-62	16	32
CH-1610-63	17	32
CH-1610-65	1	33
CH-1610-67	16	49
CH-1610-68	5	33
CH-1610-69	6	33
CH-1610-70	7	33
CH-1610-71	8	33
CH-1610-72	12	49
CH-1610-73	13	34
CH-1610-74	13	32
CH-1610-75	12	31
CH-1610-81	1	31
CH-1610-84	27	34
CH-1810-10	4	41
CH-1810-11	7	41
CH-1810-12	11	41
CH-1810-14	13	41
CH-1810-16	1	40
CH-1810-18	1	41
CH-1910-05	12	42
CH-1910-06	13	42
CH-1910-07	14	42
CH-1910-10	11	42
CH-1910-17	7	45
CH-1910-45	12	35
CH-2010-02	1	45
CH-2010-03	2	45
CH-2010-06	1	46
CH-2010-10	2	32
CH-2010-14	3	32
CH-2010-18	15	33
CH-2010-19	16	33
CH-2010-38	4	32
CH-2010-39	5	32
CH-2010-40	1	47
CH-2010-41	6	46
CH-2010-42	7	46
CH-2010-45	12	46
CH-2010-48	4	23
CH-2010-49	10	46
CH-2010-54	10	47
CH-2110-02	1	49
CH-2110-08	11	49
CH-2110-09	17	49
CH-2110-10	1	50
CH-2110-11	20	49
CH-2210-05	11	50
CH-2210-06	10	50
CH-2210-10	17	50
CH-2210-15	20	32
CH-2210-21	3	51
CH-2210-22	5	51
CH-2210-23	4	51
CH-2210-24	6	51
CH-2210-25	1	51
CL-1210-20	5	21
CL-1610-05	10	31
CR-1910-14	18	43
DD-1010-68	6	10
DD-1010-99	4	9
DD-2010-28	3	45
TE-0062-01	3	19