


Content

1. Power system
2. Controller system
3. Battery system
4. Transmission system
5. Frame system
6. Cabin system
7. Front suspension system
8. Rear suspension system
9. Steering system
10. Electrical system
11. Cooling system
12. Braking system
13. Tires


Power system



No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	TZ260XSSFZ03-Q	Driving motor	1		
2	10E14-02001-C	Front suspension bracket	2		
3	Q184B1030	Flange bolt	10		
4	Q32010	Flange nut	10		
5	10E14-05001	Connection bracket	2		
6	Q150B1030	Hexagon bolt-to fix connection bracket to motor	8		
7	Q40212	Plain washer-to fix front suspension bracket to motor	8		
8	Q40312	Spring washer-to fix front suspension bracket to motor	8		
9	10E14-02002-L	L. bracket, rear	1		

		suspension			
10	10E14-02003-L	R. bracket, rear suspension	1		
11	Q151C1230	Hexagon bolt-to fix rear suspension bracket to motor	6		
12	Q40212	Plain washer-to fix rear suspension bracket to motor	6		
13	Q40312	Spring washer-to fix rear suspension bracket to motor	6		
14	10D-01050-SH	Suspension cushion	2		
15	1001030-KD100	Suspension cushion	4		
16	Q151B18110-0H1	Hexagon bolt	4		
17	Q341B18	Hexagon nut	8		
18	Q40218	Big plain washer	8		


Driving motor



No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1		Rear end cover plate			
2		Resolving rotor press plate			
3		Resolving stator press plate			
4		Aerial plug			
5		Resolver			
6		Air ventilation valve			
7		Rear end cover			
8		Spring			
9		Bearing			
10		Rotor			
11		Stator			
12		Locking nut sleeve			
13		High voltage alarm sticker			
14		Junction box cover			
15		Seal gasket			
16		Terminal plate			
17		Seat			

18		Inner cover, front bearing			
19		Bearing			
20		Ground screw			
21		Front end cover			
22		Eyebolt			
23		Oil seal			
24		Bearing press sleeve			
25		Front end cover plate			

Transmission assembly




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	9_5G100BGB-T308	Steel ball	4		
2	41201010-4	Transmission rear housing assembly	1		
3	41201025	Input shaft assembly	1		
4	41201040	Input shaft bearing cap	1		


5	41201047	Intermediate shaft assembly	1		
6	41201100	Output shaft assembly	1		
7	41201150	Rear bearing cap assembly	1		
8	41201157	Odometer rotor	1		
9	41201160	Dust cover	1		
10	41201183	Ring flange	1		
11	41201184	Flange plate bolt	4		
12	41201608	Self-locking plug	2		
13	41202015	Shift fork support	1		
14	41202055	Forks of first gear and second gear	1		
15	41202056	Third gear and fourth gear fork	1		
16	41202057	Guides of third gear and fourth gear	1		
17	41202063	Fork shafts of first gear and second gear	1		
18	41202064	Fork shafts of third gear and fourth gear	1		
19	41513014-4	Control device gasket	1		
20	41206015	Transmission front housing	1		
21	GA0000200	Control mechanism assembly	1		
22	5J55T-1701041	Oil seal	1		
23	5J55T-1702026	Self-locking spring	2		
24	5J30T-1701085B-1	Oil drain magnet screw plug subassembly	1		
25	6J30T-1701157	Flat washer	1		
26	6J30T-1701170	Flange nut	1		
27	6J30T-1701171	Rubber O-ring	1		
28	C03054-16	Electronic odometer sensor assembly	1		
29	J100A-1702081-1	Lock washer	2		
30	NJ307E	Cylindrical roller bearing	1		
31	NUP2209EN	Cylindrical roller bearing	1		
32	NUP307ENV	Cylindrical roller bearing	1		
33	Q1400850M	Hex bolt and flat washer assembling unit	2		
34	Q1460825M	Hexagon head bolt c/w spring washer and plain washer cluster	9		
35	Q1460850	Hexagon head bolt c/w spring washer and plain washer cluster	4		
36	Q1460865	Hexagon head bolt c/w spring washer and plain washer cluster	11		
37	Q1461035M	Hexagon bolt, spring washer and	4		

		flat washer assembly with sealant applied in advance			
38	Q218B0825M	Hexagon socket head cap screw	4		
39	Q218B0835M	Hexagon socket head cap screw	6		
40	Q40008	Small washer	10		
41	Q40408	Light spring washer	10		
42	Q43135	Circlip for axle	1		
43	Q43380	Flattened steel wire retainer ring for shaft	1		
44	Q43385	Flattened steel wire retainer ring for shaft	1		
45	Q5210516	Cylindrical pin	2		
46	Q5210824	Cylindrical pin	2		
47	Q5270828	Screw spring pin	3		
48	Q617B18	Hexagon plug	1		
49	Q618B01	TAPERED HEX SCREW PLUG	1		
50	QD40I-4211187	Oil block	1		
51	QD40I-4211188	O-ring	2		
52	Q5270636	Screw spring pin	1		


Transmission rear housing assy.

[illegible]

Input shaft assy.


[illegible]

Output shaft assy.




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	41201105	Output shaft	1		
2	41201111	Output shaft first gear	1		
3	41201112	Output shaft second gear	1		
4	41201113	Output shaft third gear	1		
5	41201117	Sliding sleeves of first gear and second gear	2		
6	41201119	Shock insulator of the 1st gear	1		
7	41201131	Tooth holders of first and second gears	1		
8	41201141	Tooth holders of third and fourth gears	1		
9	41201142	Engagement gear ring	2		
10	5J55T-1701115	Bearing seat of output shaft reverse gear	1		
11	5J55T-1701123	Isolation pad	1		
12	K38×44×40ZW	Needle roller bearing	1		
13	K56×62×34	Needle roller bearing	2		
14	Q43120	Circlip for axle	1		
15	RN2304X2-YA	Output shaft fifth gear	1		



Countershaft assy.

[illegible]

Rear bearing cap assy.

[illegible]


Controlling system



No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	KTZ54X29SSFZ001	5-in-1 controller assy.	1		
2	22E14-05001	Lower bracket, controller	1		
3	22E14-03006-C	Upper bracket, controller	1		
4	Q1841030	Flange bolt	8		
5	Q32010	Flange nut	8		
6	Q1841230	Flange bolt	4		
7	Q32012	Flange nut	4		


8	Q1840830	Flange bolt	8		
9	Q32008	Flange nut	8		
10	EU0100400	VCU	1		
11	22E14-05004	Bracket, VCU	1		

Controller




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1		Fusebox cover plate			
2		Fuse			
3		HV chamber board			
4		Plug			
5		Cover plate, junction box			
6		Water mouth			
7		M25 waterproof plug			
8		M32 waterproof plug			
9		Lower cover plate			
10		Auxiliary case			
11		DCDC			
12		Main case			
13		TM control board			
14		Upper cover plate			

Controller




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1		Fusebox cover plate			
2		Slow charging input			
3		Electric defrosting output			
4		Terminal cover plate			
5		24V output port/DCDC OUTPUT			
6		Drive motor output port (U.V.W)			
7		Battery output port			
8		Fast charging input (2 holes, not used)			
9		EHPS output			
10		Air compressor output			
11		Water inlet			
12		Water outlet			

Controller




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1		8 pin resolver plug-in			
2		Loading plug-in (not used)			
3		Air conditioning plug-in			
4		9 pin commissioning plug-in			
5		35 pin wiring harness plug-in			

Battery system




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	L140T26	Battery pack	4		
2	21F18-01055	Pack frame	2		
3	21F18-01110	Middle support, pack frame	2		
4	Q32012	Hexagon flange nut	40		
5	Q1841235	Hexagon flange bolt	40		
6	Q32010	Hexagon flange nut	8		
7	Q1841030	Hexagon flange bolt	8		

Battery Pack




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1		Housing cover			
2		Air pressure balance valve			
3		Cell isolated batten			
4		Bolt			
5		Aluminum bar			
6		End plate			
7		Battery cell			
8		Fire extinguisher controller			
9		Integrated CSC			
10		Heating film			
11		High and low voltage connector			
12		Controller			
13		Housing tray			

Transmission system



No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	2201H-010-1360	Transmission shaft assy.	1		
2	Q151B1455-0H1-D1	Bolt	8		
3	Q40314-D1	Spring washer	16		
4	Q341B14-D1	Nut	8		


Frame system




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	28FMQ33GYZZ-01021	L. longitudinal beam	1		
2	28FMQ33GZZ-01022	R. longitudinal beam	1		
3	28T3-01112-A	First horizontal beam	1		
4	Q4501232	Semi-tubular rivet	6		
5	28T3-01122-A	Second horizontal beam	1		
6	29Q01-01249	Front bracket, front leafspring	2		
7	Q4501036	Semi-tubular rivet	4		
8	Q4501040	Semi-tubular rivet	4		
9	29Q01-01255	Rear bracket, front leafspring	2		
10	Q4501036	Semi-tubular rivet	10		
11	29Q09-01267	Upper bracket, shock absorber	2		
12	Q4501236	Semi-tubular rivet	8		
13	28T3-01142ZZ-138-A	Third/fourth horizontal beam	2		
14	28T3-01144	Connection plate, horizontal beam	4		
15	Q4501034	Semi-tubular rivet	24		
16	Q4501028	Semi-tubular rivet	24		
17	Q150B1030	Hexagon bolt	8		

18	Q340B10	Hexagon nut	8		
19	Q40310	Spring washer	8		
20	28T3-01172-140-A	Horizontal beam, front suspension	1		
21	28T3-01163	Connection plate, horizontal beam, suspension	4		
22	Q4501028	Semi-tubular rivet	16		
23	Q4501026	Semi-tubular rivet	12		
24	28T3-01172-110	Horizontal beam, rear suspension	1		
25	28T3-01163	Connection plate, horizontal beam, suspension	4		
26	Q4501028	Semi-tubular rivet	16		
27	Q4501026	Semi-tubular rivet	12		
28	28T3-01192-118	Rear horizontal beam	1		
29	Q4501028	Semi-tubular rivet	8		
30	29QT-02249	Front bracket, rear leaf spring	2		
31	Q4501028	Semi-tubular rivet	12		
32	29QT3-02259	Rear bracket, rear leaf spring	2		
33	Q4501038	Semi-tubular rivet	8		
34	29N-01057	Bracket, damping block	2		
35	Q4501236	Semi-tubular rivet	6		
36	10DM-01040-FX	Bracket, motor front suspension	2		
37	Q4501238	Semi-tubular rivet	8		
38	10DD-01010	Bracket, motor rear suspension	2		
39	Q4501238	Semi-tubular rivet	8		
40	85D-00046-A	Angle steel, cargo box	4		
41	Q4501238	Semi-tubular rivet	8		


Acceleration pedal assy.

[illegible]

Brake system pipeline


[illegible]

Electric gearshift handle control unit




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	L9516020030	Gearshift handle assy.	1		
2	L3814030001-F2	Cover, front gearshift operation mechanism	1		
3	L3814040001	Cover, hand brake valve	1		
4	L3814030250-FST	Upper support, gearshift mechanism	1		
5	L3814030150-FST	Lower support, gearshift mechanism	1		
6	L9171060010	Bracket assy. Gearshift mechanism	1		
	L9351020250-X	Air intake tube assy, ϕ 10, hand brake	1		
	L9351020270-X	Air outlet tube assy, ϕ 10, hand brake	1		


Steering transmission mechanism

[illegible]


Brake pedal assy.

[illegible]


Air brake valve assy.

[illegible]


Hand brake valve assy.

[illegible]


Ignition lock assy.

[illegible]


Spraying kettle assy.

[illegible]


Footrest pedal assy.

[illegible]


Front brand label assy.

[illegible]


Plugging piece

[illegible]


Cabin tilting system

[illegible]


Cabin rear locking mechanism

[illegible]


Floor decorative pieces

[illegible]


Glove box assy. Driver side

[illegible]


Little seat

[illegible]


Steering column assy.

[illegible]


Cabin carpet assy.

[illegible]


Heat insulation pad assy.

[illegible]


Floor anti vibration pad assy.

[illegible]


Wiper assy.

[illegible]

Front windshield and seals assy.


[illegible]

Face shield assy.




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	L9501020019	Radiator face shield	1		
2	L9501020039	Lower grill, radiator	1		
3	L9501020037	L. upper grill, radiator	1		
4	L9501020038	R. upper grill, radiator	1		
5	L9501020041	Decorative plate, radiator face shield (galvanized)	1		
		Face shield bracket	2		
		Clip	4		
	Q2140612	Cross recessed pan head screw	3		
6		Upper panel, face shield	1		
		Clip	2		
	Q2140620	Cross recessed pan head screw	3		
		Plain washer	3		


Side panel assy. Face shield

[illegible]

Instrument panel skeleton assy.


[illegible]

Instrument panel assy.




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	L9503010001	Main body	1		
	L9503010007	Air vent. panel	4		
	L9503010008	Cup seat	2		
	L9503010009	L. cover plate	1		
	L9503010011	R. cover plate	1		
	L9503010019	Screw cover plate, face shield	4		
	L9503010018	Radio frame	1		
	L9503010020	Air duct, face shield	1		
	L9503010021	Air duct, face blowing	1		
2	L9503010002	Instrument cover	1		
3	L9503010003	Oil reservoir cover	1		
4	L9503010004	Central fascia	1		
	L9503010012	GPS cover	1		
5	L9503010005	Glove box, central fascia	1		
6	L9503010006	Air vent.	4		
7	L9503010010	L. three-hole switch seat	1		
8	L9503010013	Toolbox cover	1		
9	L9503010014	Toolbox handle	2		
10	L9503010015	Toolbox	1		
11	L9503010016	Fuse box cover	1		


Rear window assy.

[illegible]

Side body decoration assy.


[illegible]

Roof panel decoration assy.




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	L9821020010	L. sun visor assy.	1		
2	L9821020020	R. sun visor assy.	1		
3	L9821020011	Clip, sun visor	2		
4	L9821020012	Plastic nut-sun visor	2		
	L9502990005	Snap button (big)	12		
5	L9818010001	Inner cover assy. Roof panel	1		
	Q2710540	Cross recessed semi-circular tapping screw	4		
	Q2710520	Cross recessed semi-circular tapping screw	2		
	Q40105	Plain washer	6		


Sunroof assy.

[illegible]

Seatbelt assy.


[illegible]

Door assy.




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	L9502030010	L. assist handle	1		
2	L9502030020	R. assist handle	1		
3	L9502070010	L. door inner cover	1		
4	L9502070020	R. door inner cover	1		
	Q2140612	Cross recessed round head screw	6		
	Q2710410	Cross recessed round tapping screw	2		
5	L9502050110	L. door inner decorative plate assy.	1		
6	L9502050120	R. door inner decorative plate assy.	1		
7	54T1-02035	Snap button	2		
8	L9502050030	L. screw cover	1		
9	L9502050040	R. screw cover	1		
10	L9502050050	L. door switch panel	1		
11	L9502050060	R. door switch panel	1		
12	L9502050070	L. door glove box	1		
13	L9502050080	R. door glove box	1		
14	L9502990050	Glove box bracket	2		
	Q271518	Cross recessed round tapping screw	6		
	Q40206	Plain washer	2		
15	L9502990001-A	L. door sealing film assy.	1		
16	L9502990002-A	R. door sealing film assy.	1		

Door assy.




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
17	L9502080010	L. door rocking handle	2		
18	L9502080050	L. door glass regulator assy.	1		
19	L9502080060	R. door glass regulator assy.	1		
20	L9502020010	L. door glass channel	1		
21	L9502020020	R. door glass channel	1		
22	L9502070050	L. door exterior handle assy.	1		
23	L9502070060	R. door exterior handle assy.	1		
	Q2140612	Cross recessed round head screw	4		
24	L9502070030	L. door interior handle assy.	1		
25	L9502070040	R. door interior handle assy.	1		
26	L9502990010	L. fender (Lower trim, door)	1		
27	L9502990020	R. fender (Lower trim, door)	1		
	54T1-02035	Snap button	6		
	Q2710612	Cross recessed round tapping screw	4		
	Q1000	Square plastic nut	4		


Window glass assy.

[illegible]


Door glass regulator assy.

[illegible]

Door lock assy.


[illegible]

Door seal assy.




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	L9502040050	L. door glass mud ditch	1		
	L9502040060	R. door glass mud ditch	1		
2	L9502040001	L. door lower guide rail seal	1		
	L9502040002	R. door lower guide rail seal	1		
3	L9502040010	L. door glass exterior trimming strip	1		
	L9502040020	R. door glass exterior trimming strip	1		
4	L9502040030	L. door glass interior trimming strip	1		
	L9502040040	R. door glass interior trimming strip	1		
5	L9502990030	Lwr. trimming strip assy. L. fender	1		
	L9502990040	Lwr. Trimming strip assy. R. fender	1		
6	L9502040070	Upr. Trimming strip assy. L. door	1		
	L9502040080	Upr. Trimming strip assy. R. door	1		
7	L9815010004	L. door seal (door frame)	1		
	L9815010005	R. door seal (door frame)	1		


Passenger seat

[illegible]


Driver's seat

[illegible]


Air conditioner assy.

[illegible]


Air conditioner operation mechanism

[illegible]


Inner assisting handle

[illegible]


Fr. Mudguard plate assy.

[illegible]


Fender assy. door

[illegible]

Door fender assy.


[illegible]

Bumper assy.



No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	L9501011000	Bumper assy.	1		
	L95190100001	Bumper body	1		
	Q37106	M6 welding nut	4		
2	L9519010050	Sub-assy. L. inner lining plate, bumper	1		
	L9519010005	L. inner lining plate, bumper	1		
	Q1980815	M8X15 welding bolt	4		
3	L9519010030	Sub-assy. L. Reinforce plate, bumper	1		
	L9519010003	L. reinforce plate, bumper	5		
	Q37106	M6 welding nut	3		
4	L9519010040	Sub-assy. R. Reinforce plate, bumper	1		
	L9519010004	R. reinforce plate, bumper	5		
	Q37106	M6 welding nut	3		
5	L9519010060	Sub-assy. R. inner lining plate, bumper	1		
	L9519010006	R. inner lining plate, bumper	1		
	Q1980815	M8X15 welding bolt	4		

Cabin wiring harness




Cabin wiring harness					
No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	L3374015030-F	Cabin main wiring harness	1		
2	L9375160010	SMJ plug box	1		
3	L9375160020	SMJ plug box cover	1		
	Q32006	Hexagon flange nut	4		
		(1) -connect L. fr.fog lamp			
		(2) -connect L. fr. headlamp			
		(3) -connect gearshift switch wire			
		(4) -connect L. floor wire			
		(5) -connect L. door wire			
		(6) -connect L. door wire			
		(7) -connect roof harness			
		(8) -connect combination switch (lights)			
		(9) -connect ignition lock			
		(10) -connect multifunction steering wheel			
		(11) -connect horn switch			
		(12) -connect combination switch (wiper)			
		(13) -connect dashboard			
		(14) -connect brake signal			
		(15) -connect brake switch			
		(16) -connect ABS diagnosis switch			
		(17) -connect PTC switch			
		(18) -connect danger alarm switch			
		(19) -connect dryer switch			
		(20) -connect fr. Fog lamp switch			
		(21) -connect radio switch			

		(22) -connect relay seat			
		(23) -connect wiper motor			
		(24) -connect fast charging communication			
		(25) -connect battery communication			
		(26) -connect VCU communication			
		(27) -connect air condition harness			
		(28) -connect ABS			
		(29) -connect R. door wire			
		(30) -connect R. door wire			
		(31) -connect R. front fog light			
		(32) -connect R. front headlight			
		(33) -connect water spraying motor			
		(34) -connect ground			
		(35) -connect R. floor wire			
		(36) -connect intermittent relay, wiper			
		(37) -connect window regulator relay			
		(38) -connect air condition relay			
		(39) -connect warm air relay			
		(40) -connect flasher relay			
		(41) -connect air compressor relay			
		(42) -connect fuse box			
		(43)-connect vehicle monitoring terminal			
		(44) -connect cigar lighter			
		(45) -connect headlight adjust switch			
		(46) -connect chassis harness			
		(47) -connect chassis power			
		(48) -connect electric acceleration pedal			
		(49) -connect dashboard			


		(50) -connect ground			

Fuse box assy.




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	37T1-24011	Fuse box assy.	1		
2	L9503020093	Fuse box bracket	2		
3	L9503020060	Upper bracket assy. Electrical equipment installation plate	1		
4	L9503020061	Lower bracket assy. Electrical equipment installation plate	1		

Door wiring harness




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	L9374013030	L. Door wiring harness assy.	2		
	L9374013020	R. Door wiring harness assy.			
		A-connect main harness			
		B-connect steering lamp			
		C-connect loudspeaker			

Roof wiring harness



No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	L9374012010	Roof wiring harness	1		
		A-connect height-indicator			
		B-connect reading lamp			
		C-connect height-indicator			
		D-connect main harness			


Floor wiring harness




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	L9374010010	L. floor wiring harness	1		
2	L9374011010	R. floor wiring harness			
		A-connect main wiring harness			
		B-connect door lamp			
		C-connect seat belt			
		D-connect main wiring harness			
		E-connect door lamp			

[illegible]

Alarm assy.



[illegible]

Rocker switch assy.



No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	37T3-50110	PTO switch	1	Wearing Prt.	
2	37T3-50160	PTC switch	1	Wearing Prt.	
3	35T3-50162-Y	Remote acceleration switch	1	Wearing Prt.	
4	35T3-50161-Y	Acceleration switch	1	Wearing Prt.	
5	35T3-55065	ABS diagnosis switch	1	Wearing Prt.	


Brake lamp / Clutch switch assy.




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	41T1-34010	Brake lamp switch assy.	1	Wearing Prt.	
2	16T1-02210	Clutch switch assy.	1	Wearing Prt.	

[illegible]

Front headlamp assy.


[illegible]

Combination switch




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	L9373020020	Combination switch assy.	1		
	Q2140520	Cross recessed pan head screw	3		
	Q40105	Plain washer	3		
	Q40305	Spring washer	3		

Combination instruments assy.




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	L3381010010-F2	Instruments assy.	1	Wearing Prt.	
	Q2710540	Cross recessed round tapping screw	4		
	Q40105	Plain washer	4		

L/R rear view mirror



No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	82DN14-02020	Exterior rear-view mirror assy. (L.&R. universal)	1		
2	L9828030030	Side under-view mirror assy. (L. & R. universal)	1		
3	L9828010031	L. exterior rear-view mirror bracket assy.	1		
4	L9828010041	R. exterior rear-view mirror bracket assy.	1		
	Q1840620	Hexagon flange bolt	6		


Door welding pieces




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	L9501060200	R. door assy.	1		
	L9501060100	L. door assy.	1		
2	L9502990070	Door stopper assy.	2		
	Q3200820	Hexagon flange nut	4		
	Q174B0620	Cross recessed hexagon bolt	4		
	Q400B06	Small washer	4		
	Q40306	Spring washer	4		
3	L9501060090	Door hinge assy.	4		
	L9501060001	Door hinge child piece	4		
	L9501060002	Door hinge parental piece	4		
	L9501060003	Limiting plate, door hinge	4		

[illegible]

Rear shield welding pieces


[illegible]

Bumper assy.



No.	Part No.	Part name	Qty.	Remark
1	L9501011000	Bumper assy.	1	
2	28F03-T3032-B	R. bumper bracket	1	
3	28F03-T3031-B	L. bumper bracket	1	
4	Q1841035	Bolt (bumper bracket and frame	4	
	Q32010	Nut (bumper bracket and frame)	4	
5	Q150B1040	Bolt(bumper and bumper bracket)	4	
	Q40310	Spring washer	4	
	Q40210	Plain washer	4	


Cabin tilting mechanism



No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	50F02-T3030	Front tilting mechanism assy.	1		
2	50F02-10-T3030	Shaft tube assy.	1		
3	50F02-30-T3030	R. seat assy.	1		
4	5002040LE010.1	Torsion bar assy.	1		
5	5002601LE010.1	Torsion bar	1		
6	Q1841430TF31	Fine thread bolt	1		
7	Q40114F31	Plain washer ring	1		
8	5002144E0-01	L. clip	1		
9	Q351B14	Hexagon thin nut	1		


10	50F02-20-T3030	L. seat assy.	1		

Cabin tilting mechanism




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	50F02-T3030	Single row cabin front suspension assy.	1		
2	5002511T3130	Steering motor bracket (L)	1		
3	5002512T3130	Steering motor bracket (R)	1		
4	Q1851445-0ZD	Flange bolt	6		
5	Q1841445	Flange bolt	4		
6	Q1841440	Flange bolt	2		
7	Q1841245	Flange bolt	13		
	Q32012	Flange nut	9		

Cabin rear support assy.



No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	50F16-T3A140	Rear support assy.	1		
2	50F16-10-T3A140	Welding pipe assy. Rear support	1		
3	50F16-30-T3140	Bracket assy. Cabin rear support (R)	1		
4	Q151B1490	Bolt, rear support	4		
5	Q341B14	Hexagon nut	4		
6	Q40314	Spring washer	4		
7	50F16-20-T3140	Bracket assy. Cabin rear support (L)	1		


Fr. Mudguard assy. Cabin (L)



No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	84FT3-03100	L. Fr. mudguard	1		
2	84FT3-03510	Upper press strip, L. mudguard	1		
3	84FT3-03340	Support plate, mudguard	1		
4	84FT3-03320	Lower press strip, L. mudguard	1		
5	84FT3-03810	L. mudguard flap assy. (with press strip)	1		
6	Q1841050	Flange bolt	2		
7	Q1840620	Flange bolt	4		
	Q32006	Flange nut	4		
	Q40206	Big washer	4		

8	Q1840820	Flange bolt	7		
	Q32008	Flange nut	2		
	Q40208	Big washer	2		


Fr. Mudguard assy. Cabin (R)




No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	84FT3-03200	R. Fr. mudguard	1		
2	84FT3-03610	Upper press strip, R. mudguard	1		
3	84FT3-03340	Support plate, mudguard	2		
4	84FT3-03330	Lower press strip, R. mudguard	1		
5	84FT3-03820	R. mudguard flap assy. (with press strip)	1		
6	Q1841050	Flange bolt	2		
7	Q1840620	Flange bolt	4		
	Q32006	Flange nut	4		
	Q40206	Big washer	4		

	Q1840820	Flange bolt	7		
	Q32008	Flange nut	2		
	Q40208	Big washer	2		


Battery wiring assy.



No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	Q340B08	1-type hexagon nut	4		
2	37DDC-24160	Battery wiring	1		
3	Q150B0825	Hexagon bolt	2		


Battery positive wiring					
 The diagram shows a battery positive wire assembly. A thick, flexible, braided wire is shown in a curved profile. At one end, there is a terminal with a hexagonal nut and a hexagonal bolt. Callout 1 points to the nut, callout 2 points to the bolt, and callout 3 points to the terminal. The other end of the wire has a similar terminal with a nut and bolt.					
No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	Q340B08	1-type hexagon nut	2		
2	37DDC-24140-050	Battery positive wire	1		
3	Q150B0825	Hexagon bolt	1		

Battery negative wiring





No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	Q150B0840	Hexagon bolt	2		
2	Q340B08	1-type hexagon nut	3		
3	37DDC-24150-060	Battery negative wire	1		
4	Q41212	Serrated lock washer with external teeth	1		

Reverse buzzer




No.	Part No.	Part name	Qty.	Remark
1	38C3A1-18010	Reversing buzzer	1	
2	Q150B0830	Hexagon bolt	1	
3	Q41108	Serrated lock washer with internal and external teeth	1	
4	Q401B08	Plain washer	1	
5	Q403B08	Spring washer	1	
6	Q340B08	1-type hexagon nut	1	

Chassis ground wiring				
				
No.	Part No.	Part name	Qty.	Remark
1	Q150B0825	Hexagon bolt	1	
2	Q41108	Serrated lock washer with internal and external teeth	1	
3	Q401B08	Plain washer	1	
4	Q403B08	Spring washer	1	
5	Q340B08	1-type hexagon nut	1	

Electric horn				
				
No.	Part No.	Part name	Qty.	Remark
1	37D84-21010	Electric horn assy. (Loud, 24V)	1	
	37D84-21020	Electric horn assy. (Low, 24V)	1	
2	Q150B0825	Hexagon bolt	1	
3	Q401B08	Plain washer	1	
4	Q403B08	Spring washer	1	
5	Q340B08	1-type hexagon nut	1	

L. Rr. Combination lamp assy.


[illegible]




No.	Part No.	Part name	Qty.	Remark
1	37Q75-73010-A2	L. Rr. Combination lamp	1	
2	37FT3EV-17010	Bracket, Rr. Combination lamp	1	
3	Q150B0635	Bolt	3	
	Q340B06	Nut	3	
	Q40106	Plain washer	3	
	Q40306	Spring washer	3	
4	Q1841030	Flange bolt	4	
	Q32010	Flange nut	4	

R. Rr. Combination lamp assy.


DCDC positive wire

[illegible]


DCDC negative wire

[illegible]


License plate lamp

[illegible]

Clock spring

[illegible]


Chassis wiring harness



Chassis wiring harness					
No.	Part No.	Part name	Qty.	Wearing Prt.	Remark
1	37FST4.5TLD-24570FT3-HB	Chassis main harness	1		
		(1) -connect cabin harness			
		(2) -connect PTC signal			
		(3) -connect electric horn			
		(4) -connect air conditioner pressure switch wire			
		(5) -connect air condition compressor signal			
		(6) -connect water pump motor			
		(7) -connect fan power supply			
		(8) -connect fan signal			
		(9) -connect VCU			
		(10) -connect main fuse			
		(11) -connect power switch			
		(12) -connect controller			
		(13) -connect controller CAN			
		(14) -connect slow charging			
		(15) -connect fast charging socket signal			
		(16) -connect air pressure sensor			
		(17) -connect motor signal			
		(18) -connect temp. switch of air pump			
		(19) -connect L. marker lamp			
		(20) -connect L. tail lamp			
		(21) -connect reversing alarm			
		(22) -connect dryer			
		(23) -connect license plate			


ABS wiring harness					
--------------------	--	--	--	--	--

		lamp			
		(24) -connect R. marker lamp			
		(25) -connect R. tail lamp			
		(26) -connect air pressure sensor			
		(27) -connect battery signal			
		(28) -connect S-box signal			
		(29) -connect ground wire			
		(30) -connect vehicle CAN			
		(31) -connect S-box control unit			
		(32) -connect S-box temp. sensor			



[illegible]


Front suspension system



No.	Part No.	Part name	Qty.	Remark
1	2912B8P9-010-T3	Front leaf spring assy	2	
2	2901106-FF2202	Cover plate assy. Front leaf spring	2	
3	29D16-01131-150-A	U-bolt	2	
4	29D16-01131-190-A	U-bolt	2	
5	2901117-FF2202	Lower bracket, shock absorber	1	
6	2901118-FF2202	Lower bracket, shock absorber	1	
7	Q363B16	Thick nut	8	
8	29Q01-01252-A	Pin, lifting eye	2	
9	Q150B1060	Hexagon bolt	4	
10	Q40310-X	Spring washer	4	
11	Q340B10	Hexagon nut	4	
12	Q701B45	Elbow grease mouth	2	
13	29Q01-01285	Front lifting eye	1	

14	29Q01-01286	Front lifting eye	1	
15	29Q01-01262-A	Pin, lifting eye	4	
16	Q40216	Plain washer	4	
17	Q40316-X	Spring washer	4	
18	Q340B16	Hexagon nut	4	
19	Q700B01	Straight grease mouth	4	
20	2921BC-005	Shock absorber assy.	2	
21	29FT3-01119	Lower pin, shock absorber	2	
22	Q40216	Plain washer	2	
23	Q40212	Plain washer	2	
24	Q40312-X	Spring washer	2	
25	Q341B12	Hexagon nut	2	
26	29FT3-01221	Check plate, damping block	2	
27	Q1841030	Hexagon flange bolt	4	
28	Q32010	Hexagon flange bolt	4	


Front axle and steering knuckle




No.	Part No.	Part name	Qty.	Remark
1	Q701B70	Elbow grease mouth	4	
2	30Q02-01033	Upper cover, steering knuckle	2	
	Q40306	Spring washer	6	
	Q150B0616	Bolt	6	
3	30Q02-01034	Gasket	2	
4	30Q02-01021-B	King pin	2	
5	30Q02-01019	Upper bushing	2	
6	30.61S-01017	L. steering knuckle	1	
7	30Q02-01019	Upper bushing	2	
8	30Q02-01037	King pin plug assy.	2	
9	35N-06039	Washer	2	
10	30Q02-01039-B	King pin plug screw	2	
11	30Q02-01048	Bolt, knuckle arm	6	
	30Q02-01049	Hexagon grooved flat nut	6	
	Q5004036	Cotter pin	6	
12	30.61G21S-01044	Steering longitudinal rod arm	1	
13	30Q02-01041-A	L. knuckle arm	1	
14	30Q02-01032	Steering limit bolt	2	
	Q341B14	I-type hexagon nut	2	

15	30Q02-01031	Wedge-shaped lock pin	2	
	Q40310	Spring washer	2	
	Q341B10	I-type hexagon nut	2	
	Q40110	Spring washer	2	
16	30Q57-01011	Front axle	1	
17	30Q02-01022~01029	Adjustment washer, steering knuckle	As needed	
18	30Q02-Z98906K	Thrust bearing assy.	2	
19	30Q02-01042-A	R. knuckle arm	1	
20	30.61S-01018	R. steering knuckle	1	

Tie rod assy.


[illegible]

Fr. wheel hub and brake drum



No.	Part No.	Part name	Qty.	Remark
1	31Q02-03061	Cover, front wheel hub	2	
	Q150B0814	Bolt	8	
	Q40308	Spring washer	8	
2	31Q02-03062	Gasket, front wheel hub cover	2	
3	30Q02-01061	Nut, steering knuckle	2	
	Q5005045	Cotter pin	2	
4	30Q02-01058	Baffle plate, steering knuckle	2	
5	32306	Bearing	2	
6	31.91G135-03055	Nut, wheel	12	
7	31.61G21AS-03052	Bolt, wheel	12	
	31Q02-04057	Nut, brake drum	12	
8	31.61G21AS-03015	Fr. wheel hub	2	
9	35.61G101-01075	Fr. brake drum	2	
10	33209	Inner bearing assy. Front wheel hub	2	
11	31Q02-03080-A	Oil seal assy. Front wheel hub	2	
12	31Q02-03080-A	Oil seal assy.	2	


Fr. wheel brake



No.	Part No.	Part name	Qty.	Remark
	3501.31G79S-010	Fr. L. brake assy.	1	
	3501.31G79S-020	Fr. R. brake assy.	1	
1	Q5101240	Pin	2	
	Q40112	Washer	2	
	Q5006345	Cotter pin	2	
2	3501C-046	Adjustment washer	2	
3	35D-02047	Adjustment washer	As needed	
4	3501D-050-A	Front adjustment arm assy.	2	
5	35E-01034	O-ring	4	
	3501C-044	Adjustment washer	2	
6	35.61QA-01039	Bush	2	
7	Q150B0610	Bracket bush, front air chamber	8	
	Q40306	Spring washer	8	
	Q700B01	Grease mouth	4	
8	3519.32G32-031	Bracket, Fr. L. air chamber	1	
	3519.32G32-041	Bracket, Fr. R. air	1	

		chamber		
9	3501.31G71-011	Fr. dust-proof cover	2	
	35Q68-01038	Rubber plug	8	
10	Q150B0610	Hexagon bolt	14	
	Q40306	Spring washer	14	
11	3501.80G-082	Rivet	48	
12	3501.31B-081	Brake shoe lining	8	
13	3501.31G71-085	Fr. brake shoe	4	
14	3501.61S-026	Fr. L. brake bottom plate	1	
	3501.61S-027	Fr. R. brake bottom plate	1	
15	3501.61G-108	Spring pin	2	
	Q341B10	Nut	2	
16	3501.80Q2-134	Screw, brake shoe lining	4	
17	3501Q54-052	Pin, brake shoe	2	
	3501Q54-093	Pin bush, brake shoe	2	
18	Q50512200	Steel wire	2	
19	3501.31G5-041A	Cam, Fr. L. brake	1	
	3501.31G5-042A	Cam, Fr. R. brake	1	
	Q5006345	Cotter pin	2	
20	3501.80GB-111	Trolley	2	
	3501.80G-109	Trolley shaft, brake shoe	2	
21	3501.61G-095	Return spring	2	
22	3519G-020	Air chamber assy. L. brake	1	
	3519G1-020	Air chamber assy. R. brake	1	
	Q5004025	Cotter pin	2	
	Q150B1235	Bolt	4	
	Q40312	Adjustment washer	4	


Rear suspension system



No.	Part No.	Part name	Qty.	Remark
1	2913B10P11-010-T	Rear leaf spring assy.	2	
2	2902105-E31501	Cover plate, rear leaf spring	2	
3	29F22-02131-420-B	U-bolt	4	
4	29B-02115	Bottom plate, U-bolt	2	
5	Q363B22	Thick nut	8	
6	29C-01252-C	Front pin, leaf spring	4	
7	Q150B1265-0H1	Hexagon bolt	2	
8	Q40312-X	Spring washer	2	
9	Q340B12	Hexagon nut	2	
10	Q700B01	Straight grease mouth	4	
11	29Q01-02285-A	Rear lifting eye assy.	2	
12	29Q01-02253	Pin, lifting eye	2	
13	Q40320-X	Spring washer	4	
14	Q341B20	Hexagon nut	4	
15	Q700B01	Straight grease mouth	4	


16	2921TC21-010-A	Shock absorber assy	2	
17	29FT3-01267	Upper bracket, shock absorber	2	
18	29FT3-01268	Reinforced plate, shock absorber	2	
19	Q1841235	Hexagon flange bolt	8	
20	Q32012	Hexagon flange nut	8	
21	Q40216	Plain washer	8	
22	Q40316-X	Spring washer	4	
23	Q341B16	Hexagon nut	4	
24	2902210-FF2202	Limiting block assy.	2	
25	Q1841025	Hexagon flange bolt	4	
26	Q32010	Hexagon flange nut	4	

Rear axle housing assy.



No.	Part No.	Part name	Qty.	Remark
1	Q341B12	I-type hexagon nut	16	
	Q40512	Heavy spring washer	16	
2	Q1211235	Stud	16	
3	24C-03069	Taper sleeve	16	
4	24Q-03065	Semi-shaft	2	
5	24Q-03064	Gasket	2	
6	2401Q-043	Inner oil seal ring, rear axle	2	
7	2401.61G171S-010	Rear axle housing assy. (includes item 6)	1	
8	2401Q-023B	Plug, oil level hole	1	
	Q734B1800265	O-ring	1	
9	2401Q-034B	Plug, oil-fill/release hole	1	
10	2401Q-034B	Plug, oil-fill/release hole	1	
	Q734B2240355	O-ring	2	
11	24Q-01068	Air plug assy.	1	
12	24C-01061	Gasket	1	


Main reducer and bevel gear differential assy.



No.	Part No.	Part name	Qty.	Remark
	2402Q01-010-A	Main reducer assy. Rear axle	1	
1	2402C-072	Nut, driving bevel gear	1	
2	2402C-071	Washer	1	
3	2402Q01-065-A	Flange assy.	1	
4	2402Q01-060	Oil seal assy., reducer	1	
5	2402Q01-056	Oil seal seat	1	
	Q150B1240	Hexagon bolt	6	
	Q40312	Spring washer	6	
6	24C-01061	Gasket, oil seal seat	1	
7	2402C-052	Thrust washer	1	
8	30309X2B	Fr. bearing, driving bevel gear	2	
9	2402C-151~155	Adjustment washer	As needed	
	2402C-161~174	Adjustment washer	As needed	

10	2402C-036	Bearing seat	1	
11	2402Q01-025	Driving bevel gear, rear axle	1	
	2402.5T2-020	Driving bevel gear and bearing seat assy.	1	
12	C3G532605EK	Rear bearing assy.	1	
13	2402C-081	Adjustment washer	As needed	
	2402C-082	Adjustment washer	As needed	
	2402C-083	Adjustment washer	As needed	
	2402C-084	Adjustment washer	As needed	
	2402C-085	Adjustment washer	As needed	
14	Q150B1235TF2	Hexagon bolt	12	
	Q40512	Heavy spring washer	12	
15	2402C-110	Reducer housing assy, rear axle	1	
	2402C-115	Reducer housing, rear axle	1	
16	24C-01061	Gasket	1	
	2402C-315	Differential housing assy, bevel gear	1	
17	2402C-317	L. housing, differential	1	
18	Cancel			
19	32014	Tapered roller bearing	2	
20	2402C-381	Adjustment nut	2	
21	2402C-117	Bearing cover, differential	2	
	Q150B1470TF2	Hexagon bolt	4	
22	2402C-383	Stopper plate	2	
23	Cancel			
	Q150B0814	Hexagon bolt	4	
24	Cancel			
25	2402.80-336	Gear gasket, semi axle	2	
26	2402CJ-335	Semi axle gear	2	
27	2402C-331	Planetary gear shaft	1	
28	2402CJ-345	Planetary gear	4	
29	2402Q01-346	Washer, planetary gear	4	
30	2402C-318	R. housing, differential	1	
31	2402Q01-026	Driven bevel gear, rear axle	1	
	2402C-356	Bolt, driven bevel gear	12	
	Q341B12	I-type hexagon nut	12	


Rear brake assy.



No.	Part No.	Part name	Qty.	Remark
1	3501C-046	Washer, brake cam	2	
2	35D-02047	Adjustment washer	As needed	
3	35D-02050-A	Adjusting arm assy, rear brake	2	
4	3501C-044	External adjustment washer	As needed	
5	3502.80Q-067F	Bushing, rear cam seat	2	
6	Q150B1230TF2	Hexagon bolt	4	
	Q40312	Spring washer	4	
7	35.80G-02132	Bracket, rear L. air chamber	1	
	35.80G-02133	Bracket, rear R. air chamber	1	
	35Q54-02140	0.05 thick washer, rear air chamber bracket	As needed	

	35Q54-02141	0.10 thick washer, rear air chamber bracket	As needed	
	35Q54-02143	0.50 thick washer, rear air chamber bracket	As needed	
8	3502Q54-051	Rear dustproof cover	2	
	35Q68-01038A	Rubber plug	4	
9	Q150B0610	Hexagon bolt	8	
	Q40306	Spring washer	8	
10	3501.80G-082	Rivet	48	
11	3502Q54-105	Brake shoe lining	8	
12	3502.61G-085	Fr. brake shoe	4	
	3501Q54-093	Bushing, brake shoe pin	4	
13	3502.31GS-016	Bottom plate, rear L. brake	1	
	3502.31GS-026	Bottom plate, rear R. brake	1	
14	3501.61G-108	Spring pin shaft	4	
15	3501.80Q2-134	Axle screw, brake shoe	4	
16	35.61QA-01039	Bushing, front air chamber bracket	2	
17	3501Q54-052	Pin shaft, front brake shoe	4	
18	Q50512200	Steel wire	2	
19	3502Q54-041	Rear L. brake cam	1	
	3502Q54-042	Rear R. brake cam	1	
20	Q43119	Spring washer, axle	4	
	3501.61G-111	Rolling wheel	4	
	3501.80G-109	Rolling wheel axle, brake shoe	4	
	3501.61G-095	Return spring	2	
21	3530.80RG35A-010	L. energy storage spring, brake chamber	1	
22	3530.80RG35A-020	R. energy storage spring, brake chamber	1	


Rear brake drum assy.




No.	Part No.	Part name	Qty.	Remark
1	24Q-01081B	Locking washer	2	
	Q2140512	Cross recessed pan head screw	6	
	Q40305	Spring washer	6	
2	24Q-01076	Inner nut, rear wheel hub bearing	2	
3	24T-01090	External oil seal assy. Rear wheel hub	2	
4	24Q-01084	External oil seal seat, rear wheel hub	2	
5	24.01-01083A	Bushing	2	
6	33113X2	Tapered roller bearing	2	
7	Q1211235	Stud	16	
8	31.91G135-03055	Wheel nut	6	
9				Without
10	31.61G171-04052	Bolt, rear wheel	6	

	31Q02-04057	Bolts and nuts, rear wheel	12	
11	31.61G165S-04015	Rear wheel hub	2	
12	35Q54-02075	Rear brake drum	2	
13	32214	Tapered roller bearing	2	
14	31Q02-04080-A	Inner oil seal assy. Rear wheel hub	2	

Rear brake drum assy.

[illegible]


Steering system



No.	Part No.	Part name	Qty.	Remark
1	Q72320	Seal washer	2	
2	34F23-12031	Bolt, articulated joint	1	
3	34F23-12030	Articulated joint	1	
4	34T31-10036	High pressure oil tube, steering	1	
5	Q813B12	Straight joint	1	
6	Q351B18	Hexagon thin nut	1	
7	34F03-06101	Bracket	1	
8	34F03-06002	Oil inlet tube	1	
9	Q1840840	Hexagon flange bolt, wide pole	1	
10	35D-06801	Dual-tube clip	2	
11	5002511T3130	L. Steering motor bracket	1	
12	3411010-ST01	Steering motor	1	
13	Q1841235	Hexagon flange bolt, wide pole	8	


14	5002512T3130	R. steering motor bracket	1	
15	34F15-03010	Steering pump bracket	1	
16	Q1201290	Double-headed stud	4	
17	EHPS-1010R1.5/17-2	Pad, EHPS	4	
18	EHPS-1010R1.5/16-2	EHPS	1	
19	Q1841255	Hexagon flange bolt, wide pole	6	

Steering system




No.	Part No.	Part name	Qty.	Remark
20	34F03-06001	Oil return tube	1	
21	Q1840845	Hexagon flange bolt, wide pole	3	
22	35D-06805	Single tube clip	6	
23	Q32008	Hexagon flange nut	7	
24	Q67516	A-type worm tube clip	2	
25	34F01-05010	Oil inlet—oil reservoir to steel pipe	1	
26	34F15-05003	Low pressure oil return tube	1	
27	Q67527	A-type worm tube clip	2	
28	34F03-08010	Oil reservoir, steering	1	
29	Q1840820	Hexagon flange bolt, wide pole	3	
30	34F03-12015	Bracket, oil reservoir	1	
31	Q32010	Hexagon flange nut	2	
32	Q1841025	Hexagon flange bolt, wide pole	2	

Steering system

[illegible]



Electrical system



No.	Part No.	Part name	Qty.	Remark
1	37D84-21010	Electric horn assy. (Hi)	1	
2	37FT3EV-17010	Bracket, rear combination lights	1	
3	Q1840825	Flange bolt	2	
4	Q32208	Flange nut	2	
5	81F21-03059	Compressor bracket, electric air conditioner	1	
6	Q1841035	Flange bolt	4	
7	Q32010	Flange nut	4	
8	HQA2D-27H510T-GD1	Electric air conditioner system	1	
9	6-QWLZ-60	Battery assy.	2	
10	37E14-03011	Press plate	1	
11	37ZBD-24160	Battery connection wire	1	
12	37DDC-24150-700	Negative ground wire	1	
13	37DDC-24140-2700	Wire, battery to main switch	1	
14	Q340B10	Nut	1	
15	Q41110	Saw-teeth washer	1	

16	Q150B0835	Bolt	5	
17	Q340B08	Nut	5	
18	Q40108	Washer	4	
19	Q340B12	Nut	2	
20	Q1841230	Flange bolt	8	
21	Q32012	Flange nut	8	
22	37FT3-03012-SDA	Bar retractor	2	
23	Q32208	Flange nut	4	
24	37F14-36001	Main switch bracket	1	
25	37ZB1-36010-A	Main switch	1	
26	37F14-45026	Bracket, fast charging socket	1	
27	37Q75-73010-A2	L. rear lamp assy.	1	
28	37Q75-73020-A2	R. rear lamp assy.	1	
29	38C3A1-18010	Reverse/lifting buzzer	1	
30	Q1840825	Flange bolt	1	
31	Q32208	Flange nut	1	
32	Q41108	Saw-teeth washer	5	
33	37FST4.5T-24570FT3-H B	Chassis wiring harness assy.	1	
34	37DDC-24570T3-ABS(3.3)	ABS harness assy.	1	
35	37F-24013	Harness strap	18	
36	37F5-24012	Plastic sleeve	18	
37	37F5-24016	Rubber shield	6	
38	Q1840825	Flange bolt	6	
39	Q32008	Flange nut	6	
40	37FST-24070G-D17	Controller ground harness assy.	1	
41	37FST-24070G-D16	Harness assy., controller 24V power supply to main power switch	1	


Cooling system



No.	Part No.	Part name	Qty.	Remark
1	1301-DD02-A	Motor cooling system	1	
2	13FT3-02007	Support pole, water tank	1	
3	84C-00011	Cushion	4	
4	13A22-06050	Big plain washer	4	

5	Q150B1270	Hexagon bolt	2	
6	Q340B12	Hexagon nut	4	
7	1301030-00E508	Water pump	1	
8	13DC-05011	Rubber tube	1	
9	13DC-05012	Rubber tube	1	
10	13DC-05013	Rubber tube	1	
11	13DC-05014	Rubber tube	1	
12	13DC-05015	Rubber tube	1	
13	13DC-05016	Rubber tube	1	
14	13DC-05010	Rubber tube	1	
15	13E14-00102-A	Transit steel pipe	1	
16	1301011-00E507	Auxiliary water tank	1	
17	13E14-01007	Bracket, auxiliary water tank	1	
18	Q1510630	Hexagon bolt	3	
19	Q40206	Hexagon nut	3	
20	Q40306	Spring washer	3	
21	Q67250	Double wire clamp	4	
22	Q67235	Double wire clamp	12	

Braking system



No.	Part No.	Part name	Qty.	Remark
1	RQ8501296	Nylon tube, front quick release valve to L &R ABS of front axle	2	
2	RQ85012380	Nylon tube, main valve to front air reservoir	1	
3	RQ85012203	Nylon tube, pressure retaining valve to front air reservoir	1	
4	RQ85012130	Nylon tube, pressure retaining valve to auxiliary air reservoir	1	
5	RQ85012410	Nylon tube, main valve to auxiliary air reservoir	1	
6	RQ85012285	Nylon tube, pressure retaining valve to rear air reservoir	1	
7	RQ85012320	Nylon tube, main valve to rear air reservoir, air inlet of rear brake	1	
8	RQ85012410	Nylon tube, main valve to rear quick release valve, rear brake signal	1	
9	RQ8501296	Nylon tube, rear quick release valve to L. & R. ABS of rear axle	2	
10	RQ85012490	Nylon tube, main valve to rear quick release valve, hand brake signal	1	
11	35L45-06050	Steel wire braided hose	1	
12	35A22-06050	Steel wire braided hose	1	
13	35A22-06060	Steel wire brake hose	6	
14	35A22-06035	Steel wire brake hose	1	
15	35A22-06045	Steel wire brake hose	3	
16	3506206-K57C0	Spiral iron pipe	1	
17	3543010-KCJ01	Dryer	1	
18	3550B-0010	ABS valve	4	
19	3513B2LH-010	Air reservoir assy.	1	
20	3513C3A1LH-030	Air reservoir assy.	1	
21	3533N1-010	Quick release valve	3	
22	35FX-06060	Nylon tube	2	
23	3513D-040	Water drainage valve	3	
24	35F22-55001	Dryer bracket	1	
25	35090660470	Air compressor assy.	1	

26	35F21-09022-A	Bracket, air compressor	1	
27	35F21-55027	Bracket, L. rear axle ABS bracket	1	
28	35F21-55028	Bracket, R. rear axle ABS bracket	1	
29	35T38-03006	Spiral iron tube bracket	2	
30	35F21-16103	Front quick release valve bracket	1	
31	35N-06038	Plug	5	
32	35DR10-06020	M22 straight joint (to connect with air tube of Ø18)	6	
33	35.6B2-06027	M22 elbow joint (to connect with air tube of Ø18)	4	
34	35F4-06031	Elbow joint	3	
35	Q81312	Air tube joint	6	
36	35.6B2-06071-B	M18 elbow joint (to connect with air tube of Ø16)	2	
37	35X.6B2-06090	Elbow joint	4	
38	35XB14-06004Y	Elbow joint	2	
39	35XB14-06001	Straight joint	3	
40	35XB14-06002	Straight joint	5	
41	QX63012	Straight joint	1	
42	Q351B18	Hexagon nut	7	
43	35N-06048-Y	M18 straight joint (to connect with air tube of Ø16)	4	
44	Q150B0880	M8 bolt	8	
45	Q1840825	M8 flange bolt	2	
46	Q1841230	M12 flange bolt	21	
47	Q1841260	M12 flange bolt	4	
48	Q32012	M12 flange nut	25	
49	Q1840835	M8 flange bolt	5	
50	Q32008	M8 flange nut	15	
51	35.6B2-06046	Wiring shield	2	
52	ZD250X7.5	Strap	5	
53	7243	Thread sealing glue	1	
54	Q68420	Dual tube clip	10	
55	3846A01-010	Air pressure sensor	2	
56	35Q02-28001	Elbow joint	1	
57	35X.6B2-06027	Straight joint	1	

Air compressor assy.



No.	Part No.	Part name	Qty.	Remark
1	35090662058	Fan		
2		Oil dipstick		
3		Safety valve		
4		Valve plate component		
5		Cylinder head		
6		Cylinder head gasket		
7		Outlet connector		
8		Inlet connector		
9		Valve plate gasket		
10		Coupling		
11		Bolt		
12		Oil pump		
13		Crankshaft		
14		Oil pipe		
15		Cushion block		
16		Cylinder body		
17		Oil filter		
18		Check valve		

19	35090800698	Damping pad		
20		Support		
21		Motor		
22	35090900548	Silencer		
23	35090100668	Element, silencer		
24	35090900038	Air filter		
25	35090101968	Element, air filter		