

Leoncino 800

MANUAL DE **PARTES**



SISTEMA DE ENCENDIDO AUTOMÁTICO DE LUCES

Para mayor información sobre este sistema consulte el manual de usuario.



SISTEMA ANTIBLOQUEO DE FRENOS

Para mayor información sobre este sistema consulte el manual de usuario.



LUCES DE CIRCULACIÓN DIURNA

Para mayor información sobre este sistema consulte el manual de usuario.

PREFACIO

Es nuestro placer presentarles a ustedes el Catálogo de Partes.

Este Catálogo ha sido especialmente diseñado para ayudarle en la selección de las partes correctas con el fin de mantener el vehículo en las mejores condiciones.

Los repuestos originales están sujetos a un exigente estándar de control de calidad, por lo tanto es necesario que usted sólo use repuestos originales.

En nuestro constante esfuerzo para mejorar la eficiencia y desempeño de su vehículo, las especificaciones, diagramas y número de partes pueden cambiar sin previo aviso. Consecuentemente las descripciones de los repuestos en este Catálogo pueden no ser las finales y definitivas.

Las alteraciones y modificaciones que ocurren en la impresión de este Catálogo, serán informadas a nuestra red, a través de circulares de Servicio o en nuestra página web: www.autecomobility.com accediendo al link repuestos. Es requisito que usted actualice su Catálogo y haga las correcciones necesarias, una vez reciba dichas circulares. Lo anterior le asegurará un rápido y adecuado despacho de sus partes, pues las órdenes están siendo diligenciadas con las referencias más actualizadas.







En caso de necesitar asistencia técnica, comunicarse con el Distribuidor Autorizado o llamar al Departamento de Servicios Auteco Mobility.







REVISADO ABRIL 2025







INDICE







FIG. Nº	DESCRIPCIÓN	PAG. Nº
FIG. Nº 1	TAPA CULATA	1
FIG. Nº 2	CULATA	(2-3-4)
FIG. Nº 3	CILINDRO	5
FIG. Nº 4	EJE DE LEVAS	6
FIG. Nº 5	CIGÜEÑAL - PISTON	7
FIG. Nº 6	PARTES DEL MOTOR	(8-9-10)
FIG. Nº 7	TRANSMISIÓN	(11-12)
FIG. Nº 8	SELECTOR DE CAMBIOS	(13-14)
FIG. Nº 9	CARCASA MOTOR DERECHA	15
FIG. Nº 10	ARRANQUE ELÉCTRICO	16
FIG. Nº 11	SISTEMA DE CLUTCH	(17-18)
FIG. Nº 12	CUBIERTA VOLANTE	19
FIG. Nº 13	CUBIERTA CARCASA CLUTCH	20
FIG. Nº 14	SISTEMA DE REFRIGERACIÓN	(21-22)
FIG. Nº 15	BOMBA DE ACEITE	23
FIG. Nº 16	MANUBRIO - COMANDOS	(25-26)
FIG. Nº 17	SUSPENSIÓN DELANTERA	(27-28)
FIG. Nº 18	RUEDA DELANTERA	29
FIG. Nº 19	SISTEMA DE FRENOS	(30-31)
FIG. Nº 20	SISTEMA DE ESCAPE	(32-33)
FIG. Nº 21	CAJA FILTRO DE AIRE	(34-35)
FIG. Nº 22	TANQUE DE COMBUSTIBLE	(36-37)
FIG. Nº 23	SUSPENSIÓN TRASERA	(38-39)
FIG. Nº 24	RUEDA TRASERA	40
FIG. Nº 25	PARTES DEL CHASIS	41
FIG. Nº 26	CUBIERTAS CHASIS	42
FIG. Nº 27	COMPLEMENTOS TANQUE DE COMBUSTIBLE	43
FIG. Nº 28	SOPORTE LATERAL	44
FIG. Nº 29	SOPORTE REPOSAPIE TRASERO-DELANTERO IZQUIERDO	45
FIG. Nº 30	SOPORTE REPOSAPIE TRASERO-DELANTERO DERECHO	46
FIG. Nº 31	FAROLA-VELOCÍMETRO	(47-48)
FIG. Nº 32	GUARDABARRO DELANTERO	49

FIG. Nº	DESCRIPCIÓN	PAG. Nº
FIG. Nº 33	CUBIERTAS LATERALES	50
FIG. Nº 34	GUARDABARRO TRASERO - SILLÍN	51
FIG. Nº 35	DIRECCIONALES TRASERAS	52
FIG. Nº 36	RADIADOR	(53-54)
FIG. Nº 37	PARTES ELÉCTRICAS	(55-56)
FIG. Nº 38	RAMAL ELÉCTRICO	(57-58)
FIG. Nº 39	CUERPO DE INYECCIÓN	59

					
FIG. Nº 1 TAPA CULATA	PAG. Nº 1	FIG. Nº 2 CULATA	PAG. Nº 2-3	FIG. Nº 3 CILINDRO	PAG. Nº 5
					
FIG. Nº4 EJE DE LEVAS	PAG. Nº 6	FIG. Nº5 CIGÜEÑAL - PISTON	PAG. Nº 7	FIG. Nº 6 PARTES DEL MOTOR	PAG. Nº 8-9-10

					
FIG. Nº 7: TRANSMISIÓN		PAG. Nº 11-12		FIG. Nº 8 SELECTOR DE CAMBIOS	
		PAG. Nº 13		FIG. Nº 9 CARCASA MOTOR DERECHA	
				PAG. Nº 15	
					
FIG. Nº 10 : ARRANQUE ELÉCTRICO		PAG. Nº 16		FIG. Nº 11 11: SISTEMA DE CLUTCH	
		PAG. Nº 17-18		FIG. Nº 12 CUBIERTA VOLANTE	
				PAG. Nº 19	

					
FIG. Nº 13 CUBIERTA CARCASA CLUTCH	PAG. Nº 20	FIG. Nº 14 SISTEMA DE REFRIGERACIÓN	PAG. Nº 21-22	FIG. Nº 15 BOMBA DE ACEITE	PAG. Nº 23
					
FIG. Nº 16 MANUBRIO - COMANDOS	PAG. Nº 25-26	FIG. Nº 17 SUSPENSIÓN DELANTERA	PAG. Nº 27-28	FIG. Nº 18 RUEDA DELANTERA	PAG. Nº 29

					
FIG. Nº 19 SISTEMA DE FRENOS	PAG. Nº 30-31	FIG. Nº 20 SISTEMA DE ESCAPE	PAG. Nº 32-33	FIG. Nº 21 CAJA FILTRO DE AIRE	PAG. Nº 34-35
					
FIG. Nº 22 TANQUE DE COMBUSTIBLE	PAG. Nº 36-37	FIG. Nº 23 SUSPENSIÓN TRASERA	PAG. Nº 38-39	FIG. Nº 24 RUEDA TRASERA	PAG. Nº 40










	FIG. Nº 25 PARTES DEL CHASI PAG. Nº 41		FIG. Nº 26 CUBIERTAS CHASIS PAG. Nº 42		FIG. Nº 27 COMPLEMENTOS TANQUE DE COMBUSTIBLE PAG. Nº 43
	FIG. Nº 28 SOPORTE LATERAL PAG. Nº 44		FIG. Nº 29 SOPORTE REPOSAPIE TRASERO-DELANTERO IZQUIERDO PAG. Nº 45		FIG. Nº 30 SOPORTE REPOSAPIE TRASERO-DELANTERO DERECHO PAG. Nº 46

	FIG. Nº 31 FAROLA-VELOCÍMETRO	PAG. Nº 47-48		FIG. Nº 32 GUARDABARRO DELANTERO	PAG. Nº 49		FIG. Nº 33 CUBIERTAS LATERALES	PAG. Nº 50
	FIG. Nº 34 GUARDABARRO TRASERO - SILLÍN	PAG. Nº 51		FIG. Nº 35 DIRECCIONALES TRASERAS	PAG. Nº 52		FIG. Nº 36 RADIADOR	PAG. Nº 53-54

					
FIG. Nº 37 PARTES ELÉCTRICAS		PAG. Nº 55-56		FIG. Nº 38 RAMAL ELÉCTRICO	
				PAG. Nº 57-58	
				FIG. Nº 39 CUERPO DE INYECCIÓN	
				PAG. Nº 59	

This exploded view diagram illustrates the assembly of a power tool head. The components are numbered as follows:

- 1**: The main housing or base plate.
- 2**: The upper protective guard or cover.
- 3**: A small pin or screw used for securing the guard.
- 4**: A larger pin or screw used for mounting the guard.
- 5**: A bracket or mounting plate.
- 6**: A long, thin shaft or pin.
- 7**: A small washer or spacer.
- 8**: A small pin or screw.
- 9**: A small washer or spacer.
- 10**: A small washer or spacer.
- 11**: A long, thin shaft or pin.
- 12**: A small washer or spacer.
- 13**: A small pin or screw.
- 14**: A small pin or screw.
- 15**: A small pin or screw.

The diagram shows the relative positions and assembly sequence of these parts, with dashed lines indicating the alignment and fit of the components.

1

FIGURA N° 2: CULATA




FIGURA N° 2: CULATA

FIG. No.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	JIN47600A0B01	Tapa Valvula # 5.5	8	11077631
	JIN47611A0B01	Tapa Valvula # 5.525	8	11077632
	JIN47622A0B01	Tapa Valvula # 5.55	8	11077633
	JJA47370A1B01	Tapa Valvula # 5.575	8	11077634
	JJA47371A0B01	Tapa Valvula # 5.6	8	11077635
	JJA55500A1B03	Tapa Valvula # 5.625	8	11077636
	JJA55581A0N03	Tapa Valvula # 5.65	8	11077637
	JJA56761A0B01	Tapa Valvula # 5.675	8	11077638
	JJM46350A0A00	Tapa Valvula # 5.7	8	11077639
	JLC16810A0N03	Tapa Valvula # 5.725	8	11077640
	Q710D233707	Tapa Valvula # 5.75	8	11077641
	JLC54283A0A00	Tapa Valvula # 5.775	8	11077642
	JLD18972A0A00	Tapa Valvula # 5.8	8	11077643
	MIA13222A0A00	Tapa Valvula # 5.825	8	11077644
	MIY31311A0Z01	Tapa Valvula # 5.85	8	11077645
	MIY31312A0N04	Tapa Valvula # 5.875	8	11077646
	NIK47183A0A00	Tapa Valvula # 5.9	8	11077647
	NIX33810A1A00	Tapa Valvula # 5.925	8	11077648
	NIX33810A0A00	Tapa Valvula # 5.95	8	11077649
	NIX43951A2A00	Tapa Valvula # 5.975	8	11077650
	NIX46971A0A00	Tapa Valvula # 6	8	11077651
	NIX93121A2N07	Tapa Valvula # 6.025	8	11077652
	NIX93121A2N04	Tapa Valvula # 6.05	8	11077653
	PGA11212A0N01	Tapa Valvula # 6.075	8	11077654
2	37T3-50140	Cuna Valvula	16	11064531

FIG. No.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
4	/440080032KX	Arandela Superior Valvula	8	11064530
5	L9501020041	Resorte Externo Valvula	8	11064552
6	44071-0431-22S	Resorte Interno Valvula	8	11064551
7	L9501020038	Arandela Inferior Valvula	8	11064550
8	L9501020037	Valvula Admision	4	11064548
9	35004-0304-15S	Tapon Conico 14X1.5X10	3	11050925
10	44008-0032-KX	Reten Valvula	8	11064529
11	GIA20540A1A00	Culata - Negro Mate	1	11077606
12	340281437	Arandela	2	11049941
13	34028-0054-6Z	Tornillo 6X10	2	11049747
14	C2201114000	Esparrago M8	4	11049894
15	91523-I006-00000E	Tornillo 6X30	2	11050029
16	37T3-50150	Conector Culata	2	11064528
17	L9825990001	Anillo Retenedor 47X2.5	1	11064515
18	92150-1481	Termostato	1	11064724
19	92033-I006-00000E	Tornillo 6X25	2	11050028
20	39007-0379	Sensor Temperatura Agua	1	11064748
21	S-Y046-0043	Tapon Conico M6	2	11050994
22	49033-0016	Buje Culata	1	11064564
23	44029-0010-KX	Valvula Escape	1	11064549
24	37T3-50130	Empaque Culata	1	11064526
25	JIN32911A0A00	Tapa Termostato	1	11077630
26	/7704919472684	Tornillo 6X20	4	11064947
27	PGZ22151A0A00	Valvula Sai	1	11077661
28	GIA24711C5A00	Lengueta Valvula Sai	2	11077612

FIGURA N° 2: CULATA

[illegible]

This diagram illustrates the exploded view of a 780CC engine block and cylinder head assembly. The components are labeled as follows:

- 1**: Two small cylindrical pins or dowels.
- 2**: A small cylindrical pin or dowel.
- 3**: The main engine block, featuring a large central opening and a smaller side opening. The text "780CC" is visible on the side.
- 4**: A long, thin cylindrical pin or dowel.
- 5**: Two small cylindrical pins or dowels.
- 6**: A gasket or seal plate with a complex, irregular shape and multiple mounting points.

A grey arrow points towards the assembly, indicating the direction of assembly.

5

This diagram illustrates the exploded view of a mechanical assembly, likely a timing belt drive system. The components are numbered 1 through 15:

- 1**: A small rectangular component, possibly a sensor or a plug.
- 2**: A small cylindrical pin or bolt.
- 3**: A small cylindrical pin or bolt.
- 4**: A gear wheel with a central hub.
- 5**: A curved timing belt.
- 6**: A small cylindrical pin or bolt.
- 7**: A small cylindrical pin or bolt.
- 8**: A small cylindrical pin or bolt.
- 9**: A long, thin, curved component, possibly a guide or a support arm.
- 10**: A long, thin, curved component, possibly a guide or a support arm.
- 11**: A small cylindrical pin or bolt.
- 12**: A small cylindrical pin or bolt.
- 13**: A small cylindrical pin or bolt.
- 14**: A small cylindrical pin or bolt.
- 15**: A long, thin, curved component, possibly a guide or a support arm.

6

This exploded view diagram illustrates the assembly of a mechanical component, likely a pump or motor. The parts are numbered as follows:

- 1**: A bracket grouping two cylindrical components with internal threads.
- 2**: Two small circular washers or spacers.
- 3**: Two small cylindrical pins or spacers.
- 4**: A larger cylindrical component with a flange.
- 5**: A bracket grouping two identical lever arms or connecting rods.
- 6**: A small circular component, possibly a bush or washer.
- 7**: A small cylindrical pin or screw.
- 8**: A small cylindrical pin or screw.
- 9**: A small circular component, possibly a bush or washer.
- 10**: A bracket grouping a large cylindrical component with a gear and a smaller cylindrical component.
- 11**: A small cylindrical pin or screw.
- 12**: A small circular component, possibly a bush or washer.
- 17**: A small cylindrical pin or screw.

The diagram shows the relative positions and assembly sequence of these parts, with arrows indicating the direction of assembly.

7

This diagram illustrates the assembly of a mechanical component, likely a pump or motor housing, shown in an exploded view. The main housing (1) is the central component, with various internal and external parts numbered 1 through 84. The parts are organized into several groups:

- Top Section:** Includes a mounting bracket (4, 5, 65, 66), a cover plate (3), a gasket (2), and a base plate (64). There are also several long screws (8, 9, 10) and a small pin (73).
- Internal Components:** A series of gears or impellers (12, 13, 14, 15, 16) are shown in a row, along with a shaft (17) and a pulley (19). Other parts include a bearing (20), a seal (21), and a cover (22).
- Bottom Section:** Features a large housing (1) with various internal parts like a pump body (23), a motor (24), and a base (25). There are also several screws (26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84).

A 3D arrow icon is located at the bottom left of the diagram, pointing towards the right.

FIGURA N° 6: PARTES DEL MOTOR

FIG. No.	PORTE N°	DESCRIPCIÓN	CANT.	SAP
1	FJA27111A0A00	Bloque Motor	1	11077573
2	56075-3944	Empaque Tapa Valvula Desfogue	1	11064614
3	GIA15620A1A00	Cubierta Respiradero	1	11077602
4	49135-5025	Platina Soporte Abs	1	11064869
5	921401064	Tornillo 6X65	2	11049756
6	510440855	Esparrago Carcasa	6	11064583
7	HE3960EAKKXL	Arandela 10.5X19.8X2	6	11064968
8	44013-0090-458	Tuerca M10X1	6	11064532
9	L9823100030	Tapon	2	11064570
10	HE3960EYKKS	Pin Guia 6X10X16	5	11064969
11	140/70-17M143TLM	Tornillo 8X40	3	11064943
12	49132-5452-25M	Tornillo 8X85	2	11064574
13	L9828010050	Casquete Carcasa Amarillo	6	11064585
14	L9828010060	Casquete Balanceador Amarillo	6	11064587
15	921431595	Arandela De Sellado 11X18X3	1	11050126
16	32340-2047-0000	Swiche Presion De Aceite	1	11050125
17	L7030000246	Filtro De Aceite	1	11050138
18	L3381010010-F	Arandela	1	11064580
19	S-Y053-0060	Arandela 25X35X0.5	1	11052039
20	ECANPRO	Union Filtro De Aceite	1	11064700
21	CATL5.0+6.0	Acople Filtro De Aceite	1	11064702
22	920921062	Conector Acople Filtro De Aceite	1	11064705
23	92033-JG03-0001	Anillo Retenedor	1	11050154
24	7704919306408	Tornillo 6X45	7	11064974
25	530200-00002	Sensor De Neutra	1	11064642

FIG. No.	PORTE N°	DESCRIPCIÓN	CANT.	SAP
26	350040007260	Tornillo 5X20	1	11050514
27	L9502990020	Tapon Cilindrico	2	11064575
28	L9823100010	Arandela 16X22X1.5	2	11064573
29	HE3960EYKKM	Tornillo 6X60	2	11064973
30	91523-I006-00000E	Tornillo 6X30	10	11050029
31	L95190100010	Tapon	1	11064577
32	49116-1168	Pin Guia 6.4X8X9	2	11064571
33	7704919299335	Arandela 10.5X16.5X1.5	6	11064970
34	140/70-17M147TLM	Tornillo 10X1.25X102	1	11064949
35	7704919441673	Tornillo 10X1.25X165	1	11064951
36	92192-0778	Platina Soporte	1	11064882
37	53066-0453-MW	Valvula De Desbordamiento	1	11064588
38	/7704919441673	Tornillo 10X1.25X119	4	11064950
39	63763-I853-C00065	Tornillo 6X40	1	11050013
40	L9519010010	Tornillo 8X115	1	11064578
41	92033-I006-00000E	Tornillo 6X25	2	11050028
42	8108STEW-010	Filtro Centrifugo Aceite	1	11064710
43	33310-N938-0300	Tornillo Drenaje Aceite	1	11050139
44	FJA34700A2B03	Cubierta Carter	1	11077592
45	L9502010020	Anillo Retenedor 20.63X2.62	1	11064600
46	HE3956EAKBL	Tornillo 10X1.25X90	1	11064948
47	49132-5454-25M	Tornillo 8X90	1	11064576
48	HE3956EAKBM	Tornillo 8X60	1	11064944
49	34024-0088-458	Tapon Carcasa Derecha	1	11049320
50	35023-5248-H8	Tornillo 8X65	3	11052246

FIG. No.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
51	56075-3943	Empaque Carter Aceite	1	11064612
52	350040028290	Tornillo 6X35	1	11050528
53	/49040-0767	Rodamiento Aguja 18X40X17	1	11064568
54	HE3956EAKBXL	Tornillo 6X12	2	11064952
55	490330016	Platina De Ajuste	1	11064565
56	550252-00974	Tornillo 10X1X12	1	11064644
57	L9825990002	Arandela 13.5X18X1.5	1	11064516
58	35010-LCA5-90B	Tornillo 6X16	2	11051339
59	410140-00008	Platina Tope	1	11064639
60	53044-1209	Rodamiento Bolas 25X52X18	1	11064586
61	7704919373899	Tornillo 6X14	1	11050492
62	92005-1379	Guía Cable Clutch	1	11064623
63	92143-1459	Arandela 12.5X18X1.5	1	11064711
64	GIA24700C5B01	Laberinto Respiradero	1	11077611
65	3402801466Z	Tornillo 6X12	1	11049748
66	HE3956EAKBS	Tornillo 6X85	1	11064940
67	490400767	Guía Cable Sensor De Neutra	1	11064569
68	S-Y053-0028	Tornillo 6X35	2	11051701
69	921441752	Arandela 8 Mm.	6	11050555
70	55028-0443	Arandela De Sellado	1	11057830
71	PGA17318A0A00	Tornillo	1	11077657
72	FJA28190A0A00	Clip	1	11077584
73	GJA20152A0A00	Soporte Respiradero	1	11077624
74	GIA31600C5A00	Platina	1	11077617
	ZZ36-BA-GR-S-O-M-S			

10

FIGURA N° 7: TRANSMISIÓN




FIGURA N° 7: TRANSMISIÓN

FIG. No.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	920550184	Eje Salida Completo	1	11064676
2	860000-00003	Eje Clutch Completo	1	11064671
3	38240-2872-0000	Anillo Retenedor 25X2.5	1	11050105
4	550252-01122	Buje Pinon 2Da. Eje Salida	1	11064647
5	90/90-17MR143TLN	Reten 35-47-7	1	11064967
6	920271885	Pinon Salida Z16	1	11064648
7	FJA27100A0N01	Arandela Caja	1	11077572
8	92143-1416	Tuerca M18	1	11050095
9	92055-0184	Pinon 6Ta. Eje Clutch	1	11064675
10	HE3960EAKKS	Pin De Seguridad 25X2	1	11064956
11	92015-1839	Rodamiento Agujas K25X29X10	1	11064641
12	92055-1255	Pinon 1Ra. Eje Salida	1	11064678
13	92022-1781	Arandela	2	11064643
14	92055-1502	Pinon 5Ta. Eje Salida	1	11064682
15	920551502	Pinon 4Ta. Eje Salida	1	11064681
16	NUP210EN	Pinon 2Da. Eje Clutch	1	11064673
17	RN2304X2-YA	Pinon 3Ra. Eje Salida	1	11064680
18	920151839	Arandela 18X26X1.5	1	11064640
19	92027-1670	Anillo Retenedor 30X1.5	3	11064645
20	41201172	Pinon 6Ta. Eje Salida	1	11064683
21	92015-1770	Anillo Retenedor 18X1.2	1	11064638
22	920661411	Arandela Especial	3	11064689
23	920551255	Pinon 2Da. Eje Salida	1	11064679
24	92058-1070	Rodamiento Agujas Ks26X30X13Tn	3	11064685
25	K56X62X34	Eje Salida (Solo)	1	11064677

[illegible]

FIGURA N° 8: SELECTOR DE CAMBIOS




FIG. NO.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	800121-00029	Horquilla Cambios li	2	11064659
2	920491426	Eje Horquilla Cambios	2	11064669
3	920151770	Pin Eje Selector Cambios	2	11064637
4	92150-1446	Resorte Eje Selector Cambios	2	11064720
5	GIA35740A5A00	Selector De Cambios	1	11077623
6	92037-1860	Arandela 25X30Xsp	1	11064658
7	92049-1426	Horquilla Cambios l	1	11064670
8	130/70-17M139TLMAX	Rodamiento Agujas Hk1212B	2	11064963
9	92045036	Arandela 12.8X22X1	1	11064663
10	39062-0650	Arandela 16X223	1	11064757
11	92045-036	Resorte Eje Cambios	1	11064664
12	920371064	Eje Cambios	1	11064654
13	92153-0020	Arandela 14X22X0.8	1	11064758
14	920451041	Reten 12-22-6/6.5	1	11064666
15	92027-1958	Leva Eje Cambios	1	11064651
16	920431508	Pasador Leva Eje Cambios	1	11064660
17	92037-1142	Pin 4X12.8	1	11064656
18	921501446	Resorte Leva Eje Cambios	1	11064721
19	/35004-0331 20A	Resorte Estrella Eje Selector	2	11051096
20	7704919519679	Rodamiento Bolas 16005	1	11064961
21	550280252234	Estrella Eje Selector Cambios	1	11051078
22	800126-00027	Bloque Superior Eje Selector	1	11064665
23	921450591	Pin Separador	2	11051083
24	35004-0322-660	Pin Estrella Eje Selector	2	11051085
25	92045-1041	Tornillo 6X14	2	11064667

This exploded view diagram illustrates the assembly of a mechanical component, likely a pump or engine housing. The parts are numbered as follows:

- 1:** Main housing or pump body.
- 2:** Small circular component, possibly a seal or gasket.
- 3:** Bolts or screws used for assembly.
- 4:** Small cylindrical component.
- 5:** Central shaft or rotor assembly.
- 6:** Multiple small bolts or screws.
- 7:** Circular component, possibly a cover or end plate.
- 8:** Small cylindrical component.
- 9:** Large, irregularly shaped cover or housing part.
- 10:** Small cylindrical component.
- 11:** Flange or mounting bracket.
- 12:** Small circular component.
- 13:** Small cylindrical component.
- 14:** Small rectangular component.
- 15:** Small cylindrical component.
- 16:** Small cylindrical component.
- 17:** Small rectangular component.

The diagram shows the spatial relationship between these parts, indicating how they fit together to form the complete assembly.

15

This exploded view diagram illustrates the assembly of a mechanical component, likely a motor or actuator. The parts are numbered 1 through 15. The assembly sequence is as follows:

- Part 1** (Large gear) is the main output component.
- Part 9** (Intermediate gear) meshes with Part 1.
- Part 13** (Intermediate gear) meshes with Part 9.
- Part 6** (Shaft) is the central drive shaft.
- Part 10** (Large gear) is mounted on the shaft.
- Part 14** (Intermediate gear) meshes with Part 10.
- Part 11** (Small gear) meshes with Part 14.
- Part 12** (Shaft) is the input shaft.
- Part 5** (Small gear) is mounted on the input shaft.
- Part 7** (Shaft) is the output shaft.
- Part 4** (Motor) is the power source.
- Part 2** (Screw) and **Part 3** (Screw) are used to secure the motor.
- Part 15** (Bracket) is the mounting base.

The diagram shows the relative positions and assembly order of these components. A small grey arrow in the bottom left corner points towards the assembly.

16

FIGURA N° 11: SISTEMA DE CLUTCH




FIGURA N° 11: SISTEMA DE CLUTCH

FIG. No.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	1434310108	Buje Clutch	1	11064617
2	920331335	Tornillo 6X25	3	11049765
3	702A0770	Corona Clutch (Sola)	1	11064616
4	920021674	Buje Clutch	1	11064619
5	92002-1674	Arandela Clutch Especial	1	11064618
6	92009-1605	Clutch Completo	1	11064625
7	92009-1753	Corona Interna Clutch	1	11064628
8	1424320101	Arandela Clutch	1	11064611
9	1434330103	Tuerca M20X1	1	11064622
10	1424320109	Disco Separador Clutch Especial	1	11064620
11	340440-00057	Arandela Anti-Brinco	1	11064634
12	92009-1844	Disco Clutch Especial	4	11064630
13	92009-1984	Arandela Anti-Brinco	1	11064633
14	92015-1546	Disco Separador Clutch	8	11064635
15	92004-0050	Disco Clutch	7	11064621
16	320742-00013	Disco Separador Clutch Especial	2	11064629
17	GIA24700C5A00	Empujador Clutch	1	11077610
18	35004031135D	Pin De Seguridad 35 Mm.	1	11050881
19	/7704919519679	Rodamiento Bolas 6003	1	11064962
20	330540-00003	Porta Resorte Clutch	1	11064632
21	380220-00012	Resortes Clutch	3	11064636
22	920091844	Platina Ajuste Porta Resorte Clutch	1	11064631
	ZZ36-BA-GR-S-O-M-S			
	ZZ36-BA-GR-S-O-M-S			
	ZZ36-BA-GR-S-O-M-S			

[illegible]

This technical drawing is an exploded view of a mechanical assembly, likely a pump or a valve. The central component is a circular housing (3) with a flange (2) and a central opening. Various bolts (1) and pins (4, 5, 6) are shown in their respective positions. A bracket (7) is attached to the side, and a lever (9) is shown in its operating position. The diagram includes the following numbered parts:

- 1: Bolts
- 2: Flange
- 3: Housing
- 4: Pins
- 5: Pins
- 6: Pins
- 7: Bracket
- 8: Bracket
- 9: Lever
- 10: Bolts

19

This exploded view diagram illustrates the assembly of a motorcycle headlight. The main components are the headlight housing (2), the headlight lens (3), and the headlight bezel (17). The diagram shows the following parts and their assembly sequence:

- Headlight Housing (2):** The main outer casing.
- Headlight Lens (3):** The protective glass lens.
- Headlight Bezel (17):** The decorative front ring.
- Mounting Hardware:** Includes various screws (1, 14, 15, 16), washers (12, 13), and spacers (18) used to secure the lens and bezel to the housing.
- Internal Components:** Includes the headlight bulb (4), the bulb socket (5), and the bulb base (6, 7, 8, 9, 10).
- Accessories:** Includes a headlight guard (11) and a headlight cover (12).

The diagram is labeled with numbers 1 through 18, corresponding to the parts listed in the table below.

Part Number	Part Name
1	Screw
2	Headlight Housing
3	Headlight Lens
4	Headlight Bulb
5	Bulb Socket
6	Washer
7	Washer
8	Washer
9	Washer
10	Washer
11	Headlight Guard
12	Headlight Cover
13	Washer
14	Screw
15	Screw
16	Washer
17	Headlight Bezel
18	Spacer

20

FIGURA N° 14: SISTEMA DE REFRIGERACIÓN




FIGURA N° 14: SISTEMA DE REFRIGERACIÓN

FIG. No.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
2	49047-0044	Buje	1	11064719
3	92150-1708	Eje Bomba De Agua	1	11064729
4	/7704919399974	Reten 15-26-7	1	11064966
5	92145-1574	Anillo Retenedor	1	11064722
6	FJA35710A7A00	Cubierta Interna Bomba Agua	1	11077595
7	92152-0134	Empaque Cuerpo Bomba De Agua	1	11064743
8	921390722	Sello Mecanico	1	11049453
9	921501708	Turbina Bomba De Agua	1	11064728
10	FJA31213A0A00	Cubierta Bomba De Agua	1	11077590
11	161630840	Tornillo 6X32	2	11050495
12	3411B-I111-0000	Arandela	1	11050161
13	41460-I853-C10065	Tornillo 6X12	1	11050027
14	HE3960EAKKM	Rodamiento Bolas 16002	2	11064960
15	13310-0038	Abrazadera 17 Mm.	1	11064735
16	921511154	Manguera De Salida I	1	11064738
17	55028-0234-15Z	Tornillo 6X20	9	11050158
18	13227-0032	Abrazadera 21 Mm.	2	11064733
19	92152-0528	Manguera De Salida Ii	1	11064745
20	/7704919299335	Conector	1	11064971
21	390610182	Abrazadera Negra 32 Mm.	1	11064474
22	27010-0839	Manguera De Entrada	1	11064744
23	921450774	Tornillo 6X50	1	11051324
24	GIA20153A0N01	Cubierta Sup Balanceador	1	11077604
25	26031-2152	Empaque Sup. Cubierta Protectora	1	11064742
26	FJA34890A2A00	Cubierta Inf Balanceador	1	11077594

[illegible]

23

FIGURA N° 16: MANUBRIO - COMANDOS




FIGURA N° 16: MANUBRIO - COMANDOS

[illegible][illegible]

FIGURA N° 17: SUSPENSIÓN DELANTERA




FIGURA N° 17: SUSPENSIÓN DELANTERA

FIG. No.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	L3080000110	Tornillo 8X25	4	11049785
2	L3351040010	Abrazadera Superior Manubrio	1	11064459
3	350150028	Abrazadera Inferior Manubrio	2	11051451
4	92050-0000043	Caucho Cabeza Espiga	4	11049545
5	42101-N0C6-0000	Tornillo Vástago Dirección	1	11050243
6	34025-M954-00000	Eje Abrazadera Inferior Manubrio	2	11049484
7	6C0000041	Soporte Sup Suspensión Delantera	1	11073862
8	550280236	Tornillo 8X1.25X25	2	11050531
9	32102-M954-00000	Arandela 10.2X24.9X2.5	2	11049485
10	350040046	Tuerca M10	2	11050546
11	92143-1968	Tuerca Cabeza Espiga	1	11050238
12	7704919301465	Cuna Cabeza Espiga	1	11050239
13	44100-20R5-0000	Guardapolvo	2	11050236
14	92143-2010	Rodamiento Direccion	2	11050246
15	88110-2642-0000	Guardapolvo Tubo Telescopico	2	11050257
16	34212-I000-0000	Anillo Retenedor	1	11050245
17	L3080000110	Tornillo 8X25	4	11049785
18	6D0000099	Platina Inferior	1	11073863
19	6D000425	Suspensión Delantera Izquierda	1	11073864
20	6D000427	Suspensión Delantera Derecha	1	11073865
21	S-Y600-0004	Tornillo 6X30	2	11050527
22	31500-ALC8-E60	Reflectivo Frontal Lateral	2	11064928
23	6D000428	Tornillo M10X1.25X57	4	11073866
24	6D000429	Sensor De Velocidad (Del-Tras)	1	11073867
25	35004-0024-726	Tornillo 6X1X16	1	11050526

[illegible]

This exploded view diagram illustrates the assembly of a motorcycle wheel. The components are numbered as follows:

- 1**: Axle
- 2**: Axle nut
- 3**: Brake disc
- 4**: Tire
- 5**: Wheel rim
- 6**: Wheel hub
- 7**: Brake disc
- 8**: Axle nut
- 9**: Axle
- 10**: Axle nut

The diagram shows the relative positions of these parts for assembly. An inset box provides a detailed view of the wheel rim (5) and the axle nut (10) being tightened onto the axle (9).

29

FIGURA N° 19: SISTEMA DE FRENOS




FIGURA N° 19: SISTEMA DE FRENOS

FIG. No.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	829593	Bomba De Freno Delantero	1	11073871
2	34240-I111-0000	Arandela De Sellado	19	11050280
3	92145-1615	Tornillo Iii Manguera Freno 10X1.0	2	11064841
4	1A016737	Manguera De Freno Del I	1	11073872
5	843000500	Manguera De Freno Del Ii	1	11073873
6	843000809	Manguera De Freno Del	1	11073874
7	921441082	Capuchon Tornillo De Sangrado	2	11050273
8	83105-N447-0300	Tornillo De Sangrado	2	11050271
9	92033-Y011	Tornillo Manguera Freno	1	11050278
10	L9510000073	Tornillo Manguera Freno	1	11050277
11	55028-0235-15Q	Caliper Delantero Izquierdo	1	11050288
12	34901-KFA6-900	Caliper Delantero Derecho	1	11050289
13	921441107	Juego Pastas Freno Delantero	1	11050281
14	T1201045000	Tornillo 6X20	1	11049797
15	340280077458	Platina Soporte	1	11049624
16	844719	Bomba De Freno Trasero	1	11073875
17	921441385	Swiche Freno Trasero	1	11050373
18	920088	Manguera De Freno Tras Ii	1	11073876
19	940066	Manguera De Freno Tras I	1	11073877
20	34905-LCA5-E00	Tornillo Manguera Freno	4	11050364
21	39156-0478	Caliper Trasero Izquierdo	1	11064490
22	E2030700003	Juego Pastas Freno Trasero	1	11065542
23	L9510000072	Leva Freno	1	11050272
24	/10013803	Tuerca M6	1	11049805
25	92145-1344	Tornillo 4X12	1	11051667

[illegible]

FIGURA N° 20: SISTEMA DE ESCAPE




FIGURA N° 20: SISTEMA DE ESCAPE

[illegible][illegible]

FIGURA N° 21: CAJA FILTRO DE AIRE




FIGURA N° 21: CAJA FILTRO DE AIRE

FIG. No.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	B001402	Caja Filtro Completa	1	11073885
2	68546-2562-0000	Tornillo 6X25	2	11049798
3	B001423	Buje Superior Radiador	2	11073886
4	921441580	Antivibrante	2	11050450
5	92139-0728	Sensor De Temperatura	2	11049474
6	L8070000008	Abrazadera	2	11050188
7	54005-0039	Abrazadera	2	11064807
8	B002208	Tabo	1	11073887
9	34903-KPCP-900	Canister	1	11050316
10	3501900336Z	Abrazadera 8 Mm.	4	11051487
11	B002486	Manguera I Canister	1	11073888
12	34905-KHC4-9000	Valvula One-Way	1	11050325
13	B003008	Manguera li Canister	1	11073889
14	11065-0866-50Y	Abrazadera	2	11071503
15	B003012	Manguera	1	11073890
16	921390784	Valvula Selenoide	1	11049559
17	B003282	Manguera	1	11073891
18	B003300	Filtro De Aire	1	11073892
19	B003328	Manguera	1	11073893
20	350040007260	Tornillo 5X20	2	11050514
21	B006853	Válvula De Control Electrónico	1	11073894
22	B015598	Soporte Montaje	1	11073895
23	B016192	Platina li	1	11073896
24	34028-0304	Tornillo 6X12	1	11049762
25	B016368	Cubierta Decorativa	1	11073897

[illegible]

FIGURA N° 22: TANQUE DE COMBUSTIBLE




FIGURA N° 22: TANQUE DE COMBUSTIBLE

FIG. No.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	921411054	Tornillo 5X14	3	11049790
2	92141-1054	Tornillo 5X30	3	11049791
3	350040028290	Tornillo 6X35	2	11050528
4	35019-0033-6Z	Soporte Sillin	1	11051486
5	52117-N447-0000	Pin Guia	2	11050323
6	34905-KHC4-900	Buje	2	11050324
7	B017323	Tanque De Combustible Café	1	11073902
	B017336	Tanque De Combustible Verde	1	11073903
	B017431	Tanque De Combustible Gris	1	11073904
8	921441245	Antivibrante Trasero Tanque Gasolina	1	11050319
9	7704919003079	Sello Tanque Gasolina	1	11064892
10	C2201108000	Calcomania Cubierta Tanque Gasolina	2	11049860
11	99994-0766	Antivibrante	1	11065515
12	B017456	Platina Inferior Tanque	1	11073905
13	10603-2420-0000	Antivibrante	3	11049568
14	92050-0000045	Espaciador	3	11049245
15	92033-Y022	Tuerca M6	3	11050544
16	35019-0654	Tornillo 5X20	14	11051657
17	B018262	Sensor De Combustible	1	11073906
18	34905-KPCP-900	Empaque Medidor Tanque Gasolina	2	11050334
19	B018464	Sensor De Combustible	1	11073907
20	92170-1785	Bomba Gasolina	1	11064822
21	B018718	Manguera Flujo Combustible I	1	11073908
22	92144-1289	Filtro Gasolina	1	11050327
23	3402800556Z	Caucho Filtro Gasolina	1	11049582

[illegible]

FIGURA N° 23: SUSPENSIÓN TRASERA




FIGURA N° 23: SUSPENSIÓN TRASERA

FIG. No.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	B019047	Eje Brazo Oscilante	1	11073912
2	B019220	Retenedor	2	11073913
3	B019420	Rodamiento De Agujas	2	11073914
4	B023786	Buje Central	1	11073915
5	B023976	Buje Externo	2	11073916
6	B024169	Rodamiento 6005-2Rs	1	11073917
7	B041392	Buje	1	11073918
8	921431020	Tuerca M20	1	11049883
9	B041397	Brazo Oscilante	1	11073919
10	B041398	Deslizador De Cadena	1	11073920
11	/34028-0334	Tornillo 6X15.2	3	11049796
12	B041853	Tensor De Cadena Derecho	1	11073921
13	921431016	Tornillo 8 Mm.	2	11049876
14	35004-0045-20A	Tuerca M8	2	11050540
15	B042063	Tensor De Cadena Izquierdo	1	11073922
16	B042317	Protector Cadena	1	11073923
17	B042438	Protector Cadena Pequeño	1	11073924
18	L9240000009	Tornillo 4.2X13	4	11049812
19	L1040000031	Tuerca M12	2	11049807
20	L9502070050	Tornillo 12X1.25X63	2	11064505
21	B042693	Amortiguador Trasero	1	11073925
22	S-Y600-0004	Tornillo 6X30	2	11050527
23	L1200000242	Caucho Brazo Oscilante	2	11049592
24	88120-D084-0000	Pin De Seguridad 47 Mm.	1	11052252
25	92145-0936	Tapon Eje Brazo Oscilante	1	11051501

[illegible]

FIGURA N° 24: RUEDA TRASERA




FIG. NO.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	RID43221A0A00	Eje Rueda Trasero 24X1.5X309	1	11065537
2	7704919421538	Buje Porta Sprocket	1	11064983
3	35004-0047-839	Pin De Seguridad 62 Mm.	1	11050560
4	92144-1345	Rodamiento Bolas 30X62X23.8	1	11050360
5	350040046	Tuerca M10	5	11050546
6	7704919003291	Sprocket 46T	1	11065357
7	92144-1854	Cadena 525Sx-1X112	1	11050629
8	7704919146370	Porta Sprocket	1	11064987
9	34908-MKB9-C00	Tornillo 10X1.25X41	5	11050425
10	921441345	Caucho Porta Sprocket	5	11050361
11	90/90-18MR144TLN	Valvula Tubeless	1	11064978
12	120/80-17M140TLN	Buje Izquierdo Rueda Trasera	1	11064982
13	HE4902EAMAS	Rin Trasero	1	11064985
14			1	
15	92139-0230	Buje Derecho Rueda Trasera	1	11064839
16	92055-0000007	Disco Freno Trasero	1	11050363
17	B042794	Perno M6X20	6	11073926
18	92171-1839	Buje Soporte Caliper Trasero	2	11064838
19	L9811030010	Anillo Retenedor 36.5X1.8	2	11064478
20	B073441	Soporte Caliper Trasero	1	11073927
21	6D000429	Sensor De Velocidad (Del-Tras)	1	11073867
22	35001-0025	Tornillo 6X14	1	11050497
23	B073538	Perno 8X1.25X20	2	11073928
24	/7704919421538	Tuerca M24X1.5	1	11064984
25	B073601	Rodamiento Bolas 6006-2Rs	2	11073929

FIGURA N° 25: PARTES DEL CHASIS




FIG. NO.	PORTE N°	DESCRIPCIÓN	CANT.	SAP
1	B077358	Eje Inferior	1	11074951
3	350040046	Tuerca M10	7	11050546
4	39062-0697	Buje	2	11064760
5	B077559	Perno Montaje Motor Del	2	11074952
6	B077597	Perno Montaje Motor Tras	1	11074953
7	B077736	Buje Eje Montaje Motor	1	11074954
8	B077742	Buje Montaje Motor	1	11074955
9	L1040000031	Tuerca M12	1	11049807
10	51044-0722	Tornillo 10X1.25X45	1	11050499
11	92154-1328	Tapon Chasis	2	11064850
13	550280237	Remache 3X2.7	2	11050567
14	92140-Y001	Tornillo 10X1.25X30	2	11049771
15	34908-LDC8-E00	Caucho	2	11050408
16	34028-0318	Tornillo 10X1.25X40	2	11049772
17	B077742R	Platina Montaje Caliper	1	11074956
19	34028-0334	Tornillo 6X14	2	11049795
20	B077762	Cable Seguro Sillín	1	11074957
21	KIT96047R	Perno M616	4	11074958
22	B078043	Tapon Chasis	2	11074959
23	B078865	Guia Metálica	1	11074960
24	92145-1319	Tornillo 10X1.25X50	1	11051663
25	B078870	Guia Metálica	1	11074961
26	34028-0304	Tornillo 6X12	1	11049762

This technical drawing is an exploded view of a mechanical assembly, likely a suspension or steering component. It shows the main frame and various sub-components with numbered callouts (1 through 11) indicating their positions and assembly points. The components include a central frame, a lower control arm, a steering knuckle, and various bushings and bolts. The diagram is oriented horizontally, with the main frame on the left and the lower control arm and steering knuckle on the right.

42

This exploded view diagram illustrates the assembly of a motorcycle helmet. The central component is the helmet shell (1), which is shown with its internal structure. Surrounding it are various parts: 2 (chin strap), 3 (earrings), 4 (cheek pads), 5 (top pad), 6 (top pad attachment), 7 (top pad), 8 (earrings), 9 (cheek pads), 10 (earrings), and 11 (cheek pads). Dashed lines indicate the assembly path for each part.

43

This diagram illustrates the assembly of a mechanical component, likely a hinge or joint. The parts are numbered as follows:

- 1**: A small cylindrical pin or bush.
- 2**: A small ring or washer.
- 3**: A complex metal bracket or housing.
- 4**: A long cylindrical sleeve or bush.
- 5**: A coiled spring.
- 6**: A coiled spring.
- 7**: A small cylindrical pin or bush.
- 8**: A large metal housing or bracket.
- 9**: A small metal pin or bush.
- 10**: A small metal pin or bush.

The diagram shows the relative positions of these parts, with dashed lines indicating the assembly path. The main assembly is shown in a perspective view, with the parts numbered 1 through 10. The parts are arranged in a way that shows their relationship to each other and to the main assembly. The parts are numbered 1 through 10, and the diagram shows the assembly path for each part.

44

[illegible]45

This technical diagram illustrates the assembly of a mechanical component, likely a bracket or arm, with various fasteners and sub-assemblies. The parts are numbered as follows:

- 1**: The main structural bracket or arm.
- 2**: A small pin or screw used for the sub-assembly in the dashed box.
- 3**: A sub-assembly, possibly a hinge or connector, shown in a dashed box.
- 4**: A vertical rod or pin passing through the bracket.
- 5**: A bracket or plate that fits onto the main assembly.
- 6**: A washer or spacer ring.
- 7**: A base plate or mounting flange.
- 8**: A pin or screw for the base plate.
- 9**: A pin or screw for the base plate.
- 10**: A small pin or screw at the bottom right.
- 11**: A pin or screw at the bottom right.
- 12**: A pin or screw at the bottom right.
- 13**: A pin or screw for the vertical rod.
- 14**: A vertical rod or pin.
- 15**: A bracket or plate for the vertical rod.
- 16**: A pin or screw for the bracket.
- 17**: A pin or screw for the base plate.
- 19**: A small pin or screw at the bottom right.

46

FIGURA N° 31: FAROLA-VELOCÍMETRO




FIGURA N° 31: FAROLA-VELOCÍMETRO

FIG. No.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	HE4902EAMAM	Tornillo 6X70	1	11064989
2	34024-0036-458	Buje	2	11049259
3	E105324008	Buje Farola	1	11074977
4	E10A010006	Soporte Farola	1	11074978
5	T2200001000	Tornillo 6X16	2	11049763
6	E10A020002	Farola	1	11074979
7	92033-Y022	Tuerca M6	1	11050544
8	E10A110001	Direccional Delantera Izquierda	1	11074980
9	E10B120002	Direccional Delantera Derecha	1	11074981
10	E10G090002	Tornillo Sujeción Farola	2	11074982
11	E10G110020	Buje Farola	2	11074983
12	E10G110026	Soporte Superior Farola	1	11074984
13	/10013802	Tornillo 6X1X20	2	11049792
14	92033-Y022	Tuerca M6	2	11050544
15	34024-0024	Tornillo 5X12	2	11049234
16	39007-0100	Platina Soporte Iii	1	11064466
17	L9502080050	Platina Soporte Iv	1	11064467
18	E10G120003	Cubierta Farola Café	1	11074985
	E10G120012	Cubierta Farola Gris	1	11074986
	E10G120070	Cubierta Farola Verde	1	11074987
19	E10G140041	Antivibrante Farola	1	11074988
20	68546-2562-0000	Tornillo 6X25	3	11049798
21	55028-0235-H8	Buje	6	11050466
22	FX5920P	Caucho Cabeza Espiga	3	11050456
23	E10M030002	Soporte Tablero Instrumentos	1	11074989

[illegible]

FIGURA N° 32: GUARDABARRO DELANTERO




FIG. NO.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	E10M110005	Guardabarro Delantero Negro	1	11074991
2	/34028-0334	Tornillo 6X15.2	6	11049796
3	92139-0783	Antivibrante	6	11049553
4	34019-0001	Tornillo 5X0.8X12	4	11049216
5	350190075	Soporte Guardabarro Delantero	2	11051561
6	92144-1559	Soporte Trasero Guardabarro Delantero	2	11050433
7	35001-1111-0200	Tornillo 3X6	2	11050508
8	92144-1752	Arandela 4 Mm.	4	11050554
9	E10M120001	Cubierta Guardabarro Del Café	1	11074992
	E10M120019	Cubierta Guardabarro Del Verde	1	11074993
		Cubierta Guardabarro Del Gris	1	11074994
10	921501301	Logo Benelli	1	11052041
11	92144-1875	Abrazadera	1	11050634
12	E10T120016	Guardabarro Delantero Parte Trasera	1	11074995
13	E11770004	Perno St4.213	4	11074996
14		Tuerca De Ajuste M4.2	4	11065637
15	350040007260	Tornillo 5X20	4	11050514
16	AC1500P	Guia	1	11065149

This technical drawing is an exploded view of a mechanical assembly, likely a hinge or bracket system. It consists of several main components and their associated fasteners, each labeled with a number:

- Part 1:** The main curved bracket on the right.
- Part 2:** Multiple small circular fasteners (possibly rivets or washers) used throughout the assembly.
- Part 3:** A small pin or screw at the top of the main bracket.
- Part 4:** A small circular fastener below part 3.
- Part 5:** A larger circular fastener below part 4.
- Part 6:** A small circular fastener at the bottom of the main bracket.
- Part 7:** A small rectangular component below the main bracket.
- Part 8:** A small rectangular component above part 7.
- Part 9:** A small rectangular component above part 8.
- Part 10:** A small circular fastener at the bottom of the main bracket.
- Part 11:** A small circular fastener at the bottom of the main bracket.
- Part 12:** A small circular fastener at the bottom of the main bracket.
- Part 13:** A small circular fastener at the bottom of the main bracket.
- Part 14:** A small circular fastener at the bottom of the main bracket.
- Part 15:** A small circular fastener at the bottom of the main bracket.
- Part 16:** A small circular fastener at the bottom of the main bracket.
- Part 17:** A small circular fastener at the bottom of the main bracket.

The diagram shows the relative positions and assembly sequence of these parts, with dashed lines indicating the alignment of the fasteners.

50

FIGURA N° 34: GUARDABARRO TRASERO - SILLÍN




FIG. NO.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	E268120034	Guardabarro Trasero Interno	1	11075018
2	L9240000009	Tornillo 4.2X13	4	11049812
3	92139-1069	Tuerca De Ajuste M5	8	11049693
4	E270973010	Cubierta Peq Guardabarro Tras Int	1	11075019
5	34028-0334	Tornillo 6X14	2	11049795
6	E271678054	Caja Bateria	1	11075020
7	E276176034	Stop	1	11075021
8	68546-2562-0000	Tornillo 6X25	2	11049798
9	350040107826	Buje	2	11050786
10	53250-2109-0000	Antivibrante	2	11049690
11	E276843023	Cubierta Superior Stop	1	11075022
12	921390248	Tornillo 5X16	2	11049236
13	E276846055	Cubierta Inferior Stop	1	11075023
14	34024-0024	Tornillo 5X12	4	11049234
15	E27762505	Sillin	1	11075024
16	E3124017	Antivibrante Sillin	4	11075025
17	E3824509	Hebilla Plastica	2	11075026
18	34028-0128	Tuerca De Ajuste M6	2	11049694
19	350191147	Tornillo 6X12	2	11051679

This exploded view diagram illustrates the assembly of a mechanical component. The parts are numbered as follows:

- 1**: A rectangular base plate with four mounting holes.
- 2**: A long, cylindrical bolt with a hexagonal head.
- 3**: A shorter cylindrical bolt with a hexagonal head.
- 4**: A small, rectangular plate with a central hole.
- 5**: A small, rectangular plate with a central hole.
- 6**: A rectangular plate with a central hole and a small protrusion.
- 7**: A small, rectangular plate with a central hole.
- 8**: A small, rectangular plate with a central hole.
- 9**: A small, rectangular plate with a central hole.
- 10**: A small, rectangular plate with a central hole.
- 11**: A small, rectangular plate with a central hole.
- 12**: A large, irregularly shaped plate with multiple holes and a central rectangular cutout.
- 13**: A small, rectangular plate with a central hole.
- 14**: A small, rectangular plate with a central hole.
- 15**: A small, rectangular plate with a central hole.

The diagram shows the relative positions and assembly sequence of these components, with dashed lines indicating the alignment of the parts.

52

FIGURA N° 36: RADIADOR




FIGURA N° 36: RADIADOR

FIG. No.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	/320000361	Tornillo 6X25	1	11049793
2	92144-1847	Buje	2	11050421
3	921441580	Antivibrante	3	11050450
4	E1177001	Soporte Inferior Radiador	1	11074997
5	50222J000001	Sensor De Temperatura	1	11086114
6	E1324010	Radiador	1	11074998
7	350191147	Tornillo 6X12	4	11051679
8	E1756504	Cubierta Radiador Izquierda	1	11074999
9	E1756507	Cubierta Radiador Derecha	1	11075000
10	390610182	Abrazadera Negra 32 Mm.	4	11064474
11	E1762507	Manguera Salida Refrigerante	1	11075001
12	E1965140021	Manguera Entrada Refrigerante	1	11075002
13	10604-N0Q6-0300	Abrazadera 13.3 Mm.	2	11049579
14	E1965755128	Manguera De Sobre Flujo	1	11075003
15	340240079458	Union	1	11049307
16	34024-0067-458	Tapa Tanque Liquido Refrigerante	1	11049306
17	34028-0005	Antivibrante	1	11049509
18	921390247	Tornillo 6X19	2	11049231
19	E1967980064	Tanque Reservorio	1	11075004
20	E1969695019	Cubierta Tanque Reservorio	1	11075005
21	B017230	Manguera	1	11073901
22	350220029	Protector Termico	1	11051757
23	34019-1054	Manguera De Drenaje	1	11049228
24	921501481	Ventilador Radiador I	1	11064723
25	51049-0021	Ventilador Radiador li	1	11064725

[illegible]

FIGURA N° 37: PARTES ELÉCTRICAS




FIGURA N° 37: PARTES ELÉCTRICAS

FIG. No.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	34910H23400H000	Pito	1	11050486
2	S-Y053-0023	Tornillo 6X14	3	11051678
3	KSS-L101 - RED	Sensor Roll Over	1	11050477
4	92150-1255	Caucho Sensor Roll Over	1	11052024
5	Q430100F19	Modulo De Corriente	1	11065660
6	35023-5185-28G	Caucho Flasher	2	11052237
7	34028-0304	Tornillo 6X12	2	11049762
8	E40020135	Platina Modulo Abs	1	11075049
9	1615600004800	Módulo Abs (Desconectable)	1	11051472
10	34019-0001	Tornillo 5X0.8X12	2	11049216
11	35019-0585	Tornillo 6X30	2	11051658
12	92033-Y001	Regulador	1	11050210
13	E40020417	Cubierta Caucho	1	11075050
14	L9300000045	Diodo De Arranque	2	11049742
15	E40031732	Ecu	1	11075051
15	E40031733	Ecu 35Kw	1	11075052
16	7704919022353	Modulo De Potencia	1	11064937
17	MT808-SU033	Relay Arranque	1	11050485
18	340280334	Tornillo 6X8	2	11049794
19	E422973030	Platina Bateria	1	11075053
20	E43500539	Platina Sujeción Bateria	1	11075054
21	35023-0121-6Z	Antivibrante	2	11051967
22	ZZ36-BA-GR-S-O-M-S		1	
23	34028-0095	Adhesivo	5	11049650
24	E43500540	Banda Batería	1	11075055

[illegible]

FIGURA N° 38: RAMAL ELÉCTRICO




FIGURA N° 38: RAMAL ELÉCTRICO

FIG. No.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	E43502767	Ramal Eléctrico	1	11075059
2	E43502768	Ramal Auxiliar	1	11075060
3	E43502770	Ramal Motor Eléctrico	1	11075061
4	/7704919156812	Cable Tierra	1	11064934
5	92015-0000195	Abrazadera 3X150	13	11049486
6	921450773	Abrazadera 5X210	10	11051315
7	VZ16031PCHRTU	Abrazadera	1	11050452
8	921501624	Abrazadera	5	11052213
9	35700-N033-0000	Platina Guía	5	11049643
10	E43502817	Fusible 40A	1	11075062
11	E43502821	Seguro Set	1	11075063
12	E43502822	Cubierta Switch Principal	1	11075064
13	34028-0110	Tornillo 8X20	2	11049787
14	340280139	Abrazadera	5	11049735
15	92139-1109	Abrazadera	6	11049737
16	E43506639	Controlador	1	11075065
17	55028-0245-IG	Pin De Ajuste	2	11052240
18	E3824509	Hebilla Plastica	2	11075026
19	92150-1423	Pin De Ajuste	2	11052382
20	VZ16030PCHRTU	Abrazadera	2	11050453
21	E43507331	Banda	1	11075066
22	350190595	Abrazadera	5	11051652
23	MT808-SU004	Conector E.C.U	2	11050481
24	E43507784	Ramal Switch Freno Del	1	11075067
25	E43509046	Tapa Tanque Gasolina	1	11075068

[illegible]

This technical diagram illustrates the assembly of a 4-cylinder engine. The central component is the engine block (1). Key parts shown in an exploded view include:

- 2**: Carburetor assembly at the top.
- 3**: Two circular components, likely valve covers or gaskets, positioned above the cylinder heads.
- 4**: A large, curved component, possibly a water pump or timing cover, located on the right side.
- 5**: A series of small fasteners (screws or bolts) used for securing various covers and components.
- 6**: A circular gasket or seal located between the engine block and the water pump/timing cover.
- 7**: A component on the left side, possibly a fan or pulley, with associated fasteners.
- 8**: A circular component, likely a timing belt or pulley, located at the bottom of the engine assembly.
- 9**: A small circular component, possibly a pulley or seal, located near the bottom right.
- 10**, **11**, **12**: Various small fasteners and components located along the bottom and left side of the engine.
- 13**: A component on the left side, possibly a fan or pulley, with associated fasteners.
- 14**: A small component, possibly a bolt or screw, located at the top right.
- 15**: A component, possibly a valve or plug, located at the top right.
- 16**: A small component, possibly a bolt or screw, located at the top right.

59