



CATÁLOGO DE PARTES



CERONTE 200



SISTEMA DE ENCENDIDO AUTOMÁTICO DE LUZES
Para mayor seguridad al conducir, el sistema de iluminación se activa automáticamente cuando el motor está encendido.



SISTEMA ANTIBLOQUEO DE FRENOS NO INCLUIDO



LUZES DE CIRCULACIÓN DIURNA NO INCLUIDO

Para mayor información, consulte el manual de usuario o contacte a su distribuidor autorizado.

Mobil Super
4T Ultra



www.autecomobility.com | contactanos@autecomobility.com
Línea gratuita nacional 018000 413 812



ANEXO INFORMACIÓN DE SEGURIDAD

Verifique la carátula de este manual para conocer cuál de los siguientes dispositivos de seguridad posee su vehículo.



SISTEMA ANTIBLOQUEO DE FRENOS

Sistema diseñado para evitar que las ruedas se bloqueen al frenar de forma brusca mientras se circula en línea recta, el sistema regula automáticamente la fuerza de frenado.

Aunque el sistema ABS proporciona estabilidad al detenerse, recuerde las siguientes características:

- * Para frenar de forma eficaz, deje de acelerar y utilice la leva de freno delantero y el pedal de freno trasero simultáneamente, de la misma manera que en el sistema de frenos de una motocicleta convencional
- * El ABS no puede compensar las condiciones adversas de la carretera, un error de juicio o un uso incorrecto de los frenos.



SISTEMA DE ENCENDIDO AUTOMÁTICO DE LUCES (AHO)

Sistema diseñado para que una vez se ponga el motor en marcha, la luz principal de la farola se encienda automáticamente.

Este sistema garantiza una mayor visibilidad del vehículo para los demás actores viales.



SISTEMA DE LUCES DE CIRCULACIÓN DIURNA (DRL)

Sistema de iluminación LED, el cual se enciende automáticamente al girar el interruptor de encendido a "ON".

Mientras la farola principal esté apagada, la luz LED alumbrará intensamente, si se enciende la farola principal, la luz LED se atenuará automáticamente.

No se recomienda dejar el interruptor de encendido en "ON" mientras el motor no esté en funcionamiento porque la batería se drenará prematuramente.

PREFACIO

Es nuestro placer presentarles a ustedes el Catálogo de Partes.

Este Catálogo ha sido especialmente diseñado para ayudarle en la selección de las partes correctas con el fin de mantener el vehículo en las mejores condiciones.

Los repuestos originales están sujetos a un exigente estándar de control de calidad, por lo tanto es necesario que usted sólo use repuestos originales.

En nuestro constante esfuerzo para mejorar la eficiencia y desempeño de su vehículo, las especificaciones, diagramas y número de partes pueden cambiar sin previo aviso. Consecuentemente las descripciones de los repuestos en este Catálogo pueden no ser las finales y definitivas.

Las alteraciones y modificaciones que ocurren en la impresión de este Catálogo, serán informadas a nuestra red, a través de circulares de Servicio o en nuestra página web: www.autecomobility.com accediendo al link repuestos. Es requisito que usted actualice su Catálogo y haga las correcciones necesarias, una vez reciba dichas circulares. Lo anterior le asegurará un rápido y adecuado despacho de sus partes, pues las órdenes están siendo diligenciadas con las referencias más actualizadas.

En caso de necesitar asistencia técnica, comunicarse con el Distribuidor Autorizado o llamar al Departamento de Servicios Auteco Mobility.

REVISADO NOVIEMBRE 2024

Advierta lo que le dicen las llantas mientras conduce:

- Si su respuesta a la dirección es lenta o si en las curvas y en el frenado la respuesta es pesada, es muy probable que sus llantas estén desinfladas.
- Vibración o tambaleo durante la conducción, puede significar que la presión en las llantas es mayor a la recomendada, o que ha ocurrido un daño en la llanta y la falla es inminente.
- La llanta puede vibrar a ciertas velocidades debido al desbalanceo, en este caso su desgaste será muy acelerado.

**RECUERDE SIEMPRE REVISAR LA PRESIÓN DE AIRE EN SUS LLANTAS
ANTES DE COMENZAR A RODAR**



**¡POR DESEMPEÑO,
CALIDAD Y PRECIO!**
ELIGE LLANTAS QUEEN

SCOOTER

MOTOCARRO

STREET

DOBLE
PROPÓSITO

PISTERA



Encuétralos en todos los agentes y concesionarios autorizados por AUTECO del país



MEGA**BAT**
BATTERIES



EL **EQUIPO ORIGINAL**
DE LAS MOTOCICLETAS


auteco[®]
mobility









*Una garantía de respaldo,
calidad y experiencia.*

INDICE

FIG. Nº	DESCRIPCIÓN	PAG. Nº
FIG. Nº 1	CULATA	1
FIG. Nº 2	EJE LEVAS	2
FIG. Nº 3	CUBIERTA CLUTCH - CUBIERTA VOLANTE	3-4
FIG. Nº 4	CLUTCH	5
FIG. Nº 5	FILTRO ACEITE - FILTRO CENTRIFUGO ACEITE	6
FIG. Nº 6	CARCASAS MOTOR	7-8
FIG. Nº 7	CIGÜEÑAL - PISTÓN	9
FIG. Nº 8	TRANSMISIÓN	10-11
FIG. Nº 9	EJE SELECTOR CAMBIOS	12
FIG. Nº 10	VOLANTE - PLATO BOBINAS	13
FIG. Nº 11	MOTOR ARRANQUE	14
FIG. Nº 12	SISTEMA CIIRCULACION GASES	15
FIG. Nº 13	PEDAL CAMBIOS - PEDAL CRANK	16
FIG. Nº 14	CARBURADOR	17
FIG. Nº 15	CAJA FILTRO AIRE	18
FIG. Nº 16	SILENCIADOR	19
FIG. Nº 17	SOPORTES MOTOR	20
FIG. Nº 18	LLANTAS - RINES	21
FIG. Nº 19	FRENO DELANTERO	22
FIG. Nº 20	STOP	23
FIG. Nº 21	GUARDABARRO DELANTERO - GUARDABARRO TRASERO	24
FIG. Nº 22	INSTALACIÓN ELECTRICA	25
FIG. Nº 23	SUSPENSIÓN DELANTERA	26
FIG. Nº 24	FAROLA - DIRECCIONALES DELANTERAS	27
FIG. Nº 25	VELOCÍMETRO - SWICHE ENCENDIDO	28
FIG. Nº 26	PEDAL FRENO - VARILLA FRENO TRASERA	29
FIG. Nº 27	CAUCHO REPOSAPIE	30
FIG. Nº 28	SILLÍN	31
FIG. Nº 29	TANQUE COMBUSTIBLE	32
FIG. Nº 30	MANUBRIO	33
FIG. Nº 31	CABLES	34
FIG. Nº 32	PALANCA REVERSA	35

FIG. Nº	DESCRIPCIÓN	PAG. Nº
FIG. Nº 33	PALANCA CONTROL TRACCIÓN	36
FIG. Nº 34	TAPAS LATERALES	37
FIG. Nº 35	CHASIS	38
FIG. Nº 36	CARROCERÍA	39
FIG. Nº 37	COMPLEMENTOS CARROCERÍA	40
FIG. Nº 38	SUSPENSIÓN TRASERA	41
FIG. Nº 39	CAJA HERRAMIENTAS - HERRAMIENTAS	42
FIG. Nº 40	CARDAN	43
FIG. Nº 41	EJE TRANSMISIÓN	44
FIG. Nº 42	VENTILADOR	45
FIG. Nº 38	RADIADOR	46
FIG. Nº 39	BATERÍA	47
FIG. Nº 40	COMPLEMENTOS FRENO TRASERO	48-51
FIG. Nº 41	CAJA REVERSA	52-53
FIG. Nº 42	CALCOMANÍAS	54

					
FIG. Nº 1 CULATA	PAG. Nº 1	FIG. Nº 2 EJE LEVAS	PAG. Nº 2	FIG. Nº 3 CUBIERTA CLUTCH - CUBIERTA VOLANTE	PAG. Nº 3-4
					
FIG. Nº 4 CLUTCH	PAG. Nº 5	FIG. Nº 5 FILTRO ACEITE - FILTRO CENTRIFUGO ACEITE	PAG. Nº 6	FIG. Nº 6 CARCASAS MOTOR	PAG. Nº 7-8




FIG. Nº 7 CIGÜEÑAL - PISTÓN

PAG. Nº 9




FIG. Nº 7 CIGÜÑAL - PISTÓN	PAG. Nº 9	FIG. Nº 8 TRANSMISIÓN
----------------------------	-----------	-----------------------

PAG. Nº	10-
	11




FIG. Nº 9 EJE SELECTOR CAMBIOS

PAG. N° 12




FIG. N° 10 VOLANTE - PLATO BOBINAS

PAG. N° 13




FIG. N° 10 VOLANTE - PLATO BOBINAS	PAG. N° 13	FIG. N° 11 MOTOR ARRANQUE
------------------------------------	------------	---------------------------

PAG. N° 14










FIG. N° 12 SISTEMA CIIRCULACION GASES

PAG. N° 15

					
FIG. Nº 13 PEDAL CAMBIOS - PEDAL CRANK	PAG. Nº 16	FIG. Nº 14 CARBURADOR	PAG. Nº 17	FIG. Nº 15 CAJA FILTRO AIRE	PAG. Nº 18
					
FIG. Nº 16 SILENCIADOR	PAG. Nº 19	FIG. Nº 17 SOPORTES MOTOR	PAG. Nº 20	FIG. Nº 18 LLANTAS - RINES	PAG. Nº 21




FIG. Nº 19 FRENO DELANTERO

PAG. Nº 22




FIG. Nº 20 STOP

PAG. Nº 23




FIG. Nº 21 GUARDABARRO DELANTERO -
GUARDABARRO TRASERO

PAG. Nº 24




FIG. Nº 22 INSTALACIÓN ELECTRICA

PAG. Nº 25




FIG. Nº 23 SUSPENSIÓN DELANTERA

PAG. Nº 26





















FIG. Nº 24 FAROLA - DIRECCIONALES
DELANTERAS

PAG. Nº 27

								
FIG. Nº 25 VELOCÍMETRO - SWICHE ENCENDIDO		PAG. Nº 28	FIG. Nº 26 PEDAL FRENO - VARILLA FRENO TRASERA		PAG. Nº 29	FIG. Nº 27 CAUCHO REPOSAPIE		PAG. Nº 30
								
FIG. Nº 28 SILLÍN		PAG. Nº 31	FIG. Nº 29 TANQUE COMBUSTIBLE		PAG. Nº 32	FIG. Nº 30 MANUBRIO		PAG. Nº 33

					
FIG. N° 31 CABLES	PAG. N° 34	FIG. N° 32 PALANCA REVERSA	PAG. N° 35	FIG. N° 33 PALANCA CONTROL TRACCIÓN	PAG. N° 36
					
FIG. N° 34 TAPAS LATERALES	PAG. N° 37	FIG. N° 35 CHASIS	PAG. N° 38	FIG. N° 36 CARROCERÍA	PAG. N° 39

					
FIG. Nº 37 COMPLEMENTOS CARROCERÍA	PAG. Nº 40	FIG. Nº 38 SUSPENSIÓN TRASERA	PAG. Nº 41	FIG. Nº 39 CAJA HERRAMIENTAS - HERRAMIENTAS	PAG. Nº 42
					
FIG. Nº 40 CARDAN	PAG. Nº 43	FIG. Nº 41 EJE TRANSMISIÓN	PAG. Nº 44	FIG. Nº 42 VENTILADOR	PAG. Nº 45





				
FIG. Nº 43 RADIADOR	PAG. Nº 46	FIG. Nº 44 BATERÍA	PAG. Nº 47	FIG. Nº 45 COMPLEMENTOS FRENO TRASERO PAG. Nº 48-51
				
FIG. Nº 46 CAJA REVERSA	PAG. Nº 52-53	FIG. Nº 46 CALCOMANÍAS	PAG. Nº 54	

FIGURA N°1 CULATA




FIG. NO.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	100102855-0017	TAPA CULATA	1	11047797
2	100011269-0003	TORNILLO 6X28	4	11047744
3	100011261-0004	TORNILLO 6X12	1	11042029
4	100106538	ARANDELA 6 MM	1	11042149
5	100104525	EMPAQUE TAPA CULATA	1	11041616
6	100011421-0003	TUERCA M6	2	11047745
7	100055588-0006	TORNILLO 6X20	2	11042225
8	100107759	ANILLO RETÉNEDOR 33.5X3	1	11047878
9	100711156	MULTIPLE ADMISIÓN	1	11047906
10	100140997-0002	CULATA	1	11047885
11	100104140	BUJÍA	1	11041608
11A	DR8EA	BUJIA NGK DR8EA	1	21007476
12	100105336	RETÉN VALVULA	2	11041594
13	100100440-0001	ESPARRAGO 10X40	2	11047777
14	100107796	ANILLO RETENEDOR 6.4X3	1	11047880
15	100208882	EMPAQUE CULATA	1	11041617
16	100100338-0005	TORNILLO 8X78	1	11047774
17	100106576	ARANDELA 8.5X2X18	1	11047874
18	100031687	PIN GUÍA 10X20	2	11047748
19	100140416-0002	CILINDRO (SOLO)	1	11047884
20	100011267-0003	TORNILLO 6X22	2	11047743
21	100204385-0005	PLATINA GUÍA CABLE	1	
22	100108519	EMPAQUE CILINDRO	1	11041618
23	100201145	EMPAQUE MULTIPLE ADMISIÓN	1	22000905
24	100208769	BAQUELA CARBURADOR	1	11047901

This exploded view diagram illustrates the assembly of a mechanical device, likely a pump or actuator. The components are numbered 1 through 25. The main assembly consists of a base plate (10) with a central housing (15) and two side plates (6, 7). The side plates are secured by screws (13, 14) and washers (11, 12). A central shaft (1) is connected to a lever arm (2) and a piston rod (3). The piston rod is connected to a piston (4) and a piston ring (5). The piston ring is connected to a piston rod (6) and a piston ring (7). The piston rod (6) is connected to a piston ring (5) and a piston rod (4). The piston rod (4) is connected to a piston ring (3) and a piston rod (2). The piston rod (2) is connected to a piston ring (1) and a piston rod (16). The piston rod (16) is connected to a piston ring (17) and a piston rod (18). The piston rod (18) is connected to a piston ring (19) and a piston rod (20). The piston rod (20) is connected to a piston ring (21) and a piston rod (22). The piston rod (22) is connected to a piston ring (23) and a piston rod (24). The piston rod (24) is connected to a piston ring (25) and a piston rod (26).

2

This exploded view diagram illustrates the assembly of a mechanical unit, possibly a pump or motor housing. The components are numbered as follows:

- 1**: Two views of a circular end plate or cover.
- 2**: A small circular component, possibly a seal or gasket.
- 3**: A small cylindrical component.
- 4**: A long, thin rod or pin.
- 5**: A small circular component.
- 6**: A small rectangular component.
- 7**: A small circular component.
- 8**: The main housing or pump body.
- 9**: A long, thin rod or pin.
- 10**: A small rectangular component.
- 11**: A small circular component.
- 12**: A large, irregularly shaped gasket or seal.
- 13**: Two small circular components.
- 14**: A small rectangular component.
- 15**: A small circular component.
- 16**: A small rectangular component.
- 17**: The main housing or pump body, shown from a different angle.
- 18**: A small circular component.
- 19**: A small circular component.
- 20**: A small circular component.
- 21**: A small rectangular component.
- 22**: A small circular component.
- 23**: A small circular component.
- 24**: A small rectangular component.
- 25**: A small circular component.
- 26**: A small circular component.
- 27**: A small rectangular component.
- 28**: A small circular component.

3

This exploded view diagram illustrates the assembly of a mechanical component, likely a pump or motor housing. The parts are numbered as follows:

- 1:** Two identical circular end plates or covers.
- 2:** A central shaft or pin.
- 3:** A small circular component, possibly a seal or gasket.
- 4:** A long, thin rod or pin.
- 5:** A small circular component, possibly a seal or gasket.
- 6:** A small circular component, possibly a seal or gasket.
- 7:** A small circular component, possibly a seal or gasket.
- 8:** The main housing or body of the assembly.
- 9:** A long, thin rod or pin.
- 10:** A small circular component, possibly a seal or gasket.
- 11:** A small circular component, possibly a seal or gasket.
- 12:** A large, irregularly shaped gasket or seal.
- 13:** Two screws or bolts.
- 14:** A small circular component, possibly a seal or gasket.
- 15:** A small circular component, possibly a seal or gasket.
- 16:** A small circular component, possibly a seal or gasket.
- 17:** A small circular component, possibly a seal or gasket.
- 18:** A small circular component, possibly a seal or gasket.
- 19:** A small circular component, possibly a seal or gasket.
- 20:** A small circular component, possibly a seal or gasket.
- 21:** A small circular component, possibly a seal or gasket.
- 22:** A small circular component, possibly a seal or gasket.
- 23:** A small circular component, possibly a seal or gasket.
- 24:** A small circular component, possibly a seal or gasket.
- 25:** A small circular component, possibly a seal or gasket.
- 26:** A small circular component, possibly a seal or gasket.
- 27:** A small circular component, possibly a seal or gasket.
- 28:** A small circular component, possibly a seal or gasket.

4

FIGURA N°5 FILTRO ACEITE - FILTRO CENTRIFUGO ACEITE




FIG. NO.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	100065230	FILTRO CENTRIFUGO ACEITE	1	
2	100066392	CONDUCTO FILTRO CENTRIFUGO ACEITE	1	
3	100010978-0001	TORNILLO 5X12	3	11042209
4	100104844	RESORTE FILTRO CENTRIFUGO ACEITE	1	11042126
5	100200027	CUBIERTA FILTRO CENTRIFUGO ACEITE	1	11047908
6	100104850	PIN SEGURIDAD	1	11042128
7	100104599	EMPAQUE FILTRO ACEITE	1	11041621
8	100100523	TUERCA	1	11047780
9	100103345	ARANDELA 16.5X2X27	1	11047807
10	100200024	CAMPANA FILTRO CENTRIFUGO ACEITE	1	11047907
11	100103486	PIÑON PRIMARIO	1	11047808
12	100107842	ANILLO RETÉNEDOR 9.4X2.4	2	11047882
13	100010946-0003	TORNILLO 4X10	2	11047737
14	100100166	ACOPLE CUERPO BOMBA ACEITE	1	11047766
15	100100195	ROTOR INTERNO BOMBA ACEITE	1	11047769
16	100100206	ROTOR EXTERNO BOMBA ACEITE	1	11047770
17	100100187	CUERPO BOMBA ACEITE	1	11047768
18	100032890	PIN PASADOR 2.5X10	1	11042037
19	100100156	EJE BOMBA ACEITE	1	11047765
20	100100176	PIÑÓN BOMBA ACEITE	1	11047767
21	100011111	PIN SEGURIDAD	1	11042035
22	100123472-0002	TORNILLO 6X32	2	11047883
23	100100071	BOMBA ACEITE	1	11047764

FIGURA N°6 CARCASAS MOTOR (1/2)




FIG. NO.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	100031958-0007	TORNILLO 6X55	1	11047749
2	100106281-0006	GUÍA CABLE CLUTCH	1	11047859
3	100100263	ESPARRAGO CARCASA A	1	11047771
4	100100264	ESPARRAGO CARCASA A	1	11047772
5	100106609	ARANDELA 12.5X2X22	4	11042151
6	100100532-0002	TORNILLO TAPON 8X32	4	11047781
7	100011269-0003	TORNILLO 6X28	2	11047744
8	100105484	ABRAZADERA	1	11047851
9	100206023	MANGUERA ENTRADA FILTRO	1	
10	100100316	ESPARRAGO CARCASA B	2	11047773
11	100104589	EMPAQUE CARCASA	1	11041622
12	100102960-0083	CARCASA IZQUIERDA	1	11047800
13	100102901	PLATINA GUÍA	1	11047799
14	100055591-0006	TORNILLO 6X12	1	11042227
15	100101202	RODAMIENTO AGUJAS	1	11047790
16	100011540-0007	TORNILLO 6X50	9	11047747
17	100031961-0007	TORNILLO 6X95	1	11047750
18	100102871-0002	TAPON CEDAZO FILTRO ACEITE	1	11047798
19	100107766	ANILLO RETÉNEDOR 35X3	1	11047879
20	100104866	RESORTE TAPON CEDAZO FILTRO ACEITE	1	11047836
21	100104943	CEDAZO FILTRO ACEITE	1	11047837
22	100104652	RETÉN 14X28X7	1	11041623
23	100103008	INYECTOR	1	11047801
24	100011534-0002	TORNILLO 6X25	1	11047746
25	100100331-0006	TAPON DRENAJE ACEITE	1	11042228

This exploded view diagram illustrates the assembly of a 125cc engine head and cylinder. The main components are shown in their relative positions for assembly. The cylinder block is at the bottom, with the cylinder head above it. The head is secured by four bolts (1) and washers (2). The head gasket (3) is positioned between the head and the cylinder block. The head is also secured by four bolts (4) and washers (5). The head is connected to the cylinder block by two studs (6) and nuts (7). The head is also secured by two bolts (8) and washers (9). The head is connected to the cylinder block by two studs (10) and nuts (11). The head is also secured by two bolts (12) and washers (13). The head is connected to the cylinder block by two studs (14) and nuts (15). The head is also secured by two bolts (16) and washers (17). The head is connected to the cylinder block by two studs (18) and nuts (19). The head is also secured by two bolts (20) and washers (21). The head is connected to the cylinder block by two studs (22) and nuts (23). The head is also secured by two bolts (24) and washers (25). The head is connected to the cylinder block by two studs (26) and nuts (27). The head is also secured by two bolts (28) and washers (29). The head is connected to the cylinder block by two studs (30) and nuts (31). The head is also secured by two bolts (32) and washers (33). The head is connected to the cylinder block by two studs (34) and nuts (35). The head is also secured by two bolts (36) and washers (37). The head is connected to the cylinder block by two studs (38) and nuts (39). The head is also secured by two bolts (40) and washers (41).

8

This diagram illustrates the assembly of a mechanical device, likely a pump or actuator, with 15 numbered components. The main assembly is shown on a base plate (1). A central shaft (2) passes through a housing (6) and a flange (4). A gear (5) is mounted on the shaft, and a pin (14) is used to secure it. A spring (10) is shown in an exploded view, along with a piston rod (12) and a piston (13). The piston rod is secured with a nut (11) and a washer (11). The piston is secured with a pin (11) and a washer (11). The spring is shown in an exploded view, along with a piston rod (12) and a piston (13). The piston rod is secured with a nut (11) and a washer (11). The piston is secured with a pin (11) and a washer (11).

9

FIGURA N°8 TRANSMISIÓN (1/2)




FIG. NO.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	100106510	ARANDELA 15.2X1X25	1	11047870
2	100103633	PIÑON 2DA. EJE CLUTCH	1	11047811
3	100103636	PIÑON 5TA. EJE CLUTCH	1	11047814
4	100103647	ARANDELA 17.3X1.6X26	3	11047815
5	100100596	PIN SEGURIDAD	3	11047783
6	100103635	PIÑON 4TA. EJE CLUTCH	1	11047813
7	100103634	PIÑON 3RA. EJE CLUTCH	1	11047812
8	100052667	EJE CLUTCH (SOLO)	1	11047756
9	100106525	ARANDELA 20.2X0.5X27	1	11047873
10	100053061	PIÑON EJE CLUTCH	1	11047757
11	100106511	ARANDELA 15.2X1X30	1	11047871
12	100103778	PIÑON EJE SALIDA	1	11047822
13	100103565	BUJE PIÑON EJE SALIDA	1	11047810
14	100106434	ARANDELA 16.5X0.5X24	1	11047868
15	100103743	PIÑON 1RA. EJE SALIDA	1	11047817
16	100103564	BUJE PIÑON 1RA. EJE SALIDA	1	11047809
17	100103748	PIÑON 3RA. EJE SALIDA	1	11047821
18	100103746	PIÑON 4TA. EJE SALIDA	1	11047819
19	100055424	EJE SALIDA (SOLO)	1	
20	100103747	PIÑON 5TA. EJE SALIDA	1	11047820
21	100103744	PIÑON 2DA. EJE SALIDA	1	11047818
22	100106511	ARANDELA 15.2X1X30	1	11047871
23	100106396	ARANDELA 12.1X1X18	1	11047863
24	100011098	PIN SEGURIDAD	1	11042033
25	100105793	LEVA EJE CRANK	1	11047858

Exploded view diagram of a mechanical assembly 3, showing three sub-assemblies 38, 39, and 40. Sub-assembly 38 (top) includes parts 1-10. Sub-assembly 39 (middle) includes parts 11-22. Sub-assembly 40 (bottom) includes parts 23-36. A central shaft 41 is shown passing through the middle of the three sub-assemblies.

11

FIGURA N°9 EJE SELECTOR CAMBIOS




FIG. NO.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	100011095	PIN SEGURIDAD	1	11047740
2	100103978	RESORTE EJE CAMBIOS	1	11047828
3	100103999	PLATINA EJE CAMBIOS	1	11076844
5	100203926	RESORTE EJE CAMBIOS	1	11047898
6	100106402	ARANDELA 14X0.5X20	2	11047864
7	100011096	PIN SEGURIDAD	1	11042032
8	100106303-0002	EJE CAMBIOS	1	11047860
9	100104492-0035	SWICHE NEUTRA	1	11047832
10	100010979-0003	TORNILLO 6X20	1	11047739
11	100103914	EJE HORQUILLA CAMBIOS	1	11047826
12	100103895	HORQUILLA CAMBIOS	1	11047823
13	100103904	HORQUILLA CAMBIOS	1	11047825
14	100103899	HORQUILLA CAMBIOS	1	11047824
15	100100420-0002	TORNILLO EJE SELECTOR CAMBIOS	1	11047776
16	100010886-0004	ARANDELA	1	
17	100103944	ESTRELLA EJE SELECTOR CAMBIOS	1	11047827
18	100032886	PIN 4X10	1	11047751
19	100203832	EJE SELECTOR CAMBIOS	1	11047897
20	100103981	RESORTE LEVA EJE SELECTOR CAMBIO	1	11047829
21	100059045	LEVA EJE SELECTOR CAMBIOS	1	11047759
22	100100387-0002	TORNILLO LEVA EJE SELECTOR CAMBIO	1	11047775
23	100104487	UNIÓN SWICHE NEUTRA	1	11047831

This diagram illustrates the assembly of a mechanical component, likely a pump or motor. The components are numbered as follows:

- 1:** A large, cylindrical housing or bellows assembly.
- 2:** A small, rectangular electronic or control module.
- 3:** Two screws used to secure the control module.
- 4:** Three screws used to secure the main housing.
- 5:** Three screws used to secure the front flange.
- 6:** A circular flange or mounting plate.
- 7:** A small, circular seal or gasket.

The diagram shows the control module (2) connected to the main housing (1) via a cable. The housing (1) is shown in an exploded view, revealing its internal components and the mounting points for the screws (3, 4, 5). The front flange (6) and seal (7) are also shown in an exploded view, indicating their position relative to the main housing.

13

This diagram illustrates the assembly of a motorized gear system. The components are numbered as follows:

- 1**: The electric motor, shown with its power cord.
- 2**: A small pin or shaft component.
- 3**: Two small circular washers or spacers.
- 4**: A rectangular plate or base.
- 5**: A small gear or pinion.
- 6**: A large gear or flywheel.

The assembly process is shown in an exploded view, indicating the relative positions and alignment of the parts. The motor (1) is positioned to drive the small gear (5), which in turn meshes with the large gear (6). The rectangular plate (4) and the pin (2) are also shown in their relative positions.

14

This diagram illustrates the assembly of a mechanical component, likely a pump or valve. The parts are numbered 1 through 15:

- 1**: A long, straight metal rod or shaft.
- 2**: A small, cylindrical component, possibly a pin or a small valve.
- 3**: A long, curved metal rod or shaft.
- 4**: A complex, multi-ported metal casting, likely the main body or housing.
- 5**: A rectangular metal plate or cover.
- 6**: A small, cylindrical component, similar to part 2.
- 7**: A long, curved metal rod or shaft, similar to part 3.
- 8**: A small, curved metal component, possibly a lever or a pin.
- 9**: A small, circular metal washer or gasket.
- 10**: A small, curved metal component, similar to part 8.
- 11**: A small, rectangular metal plate or bracket.
- 12**: A small, rectangular metal plate or bracket, similar to part 11.
- 13**: A long, threaded metal bolt or screw.
- 14**: A small, circular metal washer or gasket, similar to part 9.
- 15**: A small, circular metal washer or gasket, similar to part 9.

The assembly is shown in an exploded view, with the components arranged to show their relative positions and how they fit together. The main body (4) is the central component, with the rod (1) and the curved rod (3) passing through it. The cover (5) is shown below the main body, and the various pins, washers, and bolts (6, 9, 13, 14, 15) are shown in their respective assembly positions.

15

The diagram illustrates the components of a motorcycle footpeg assembly. The left view shows the footpeg (1) with two footrests (2) attached via a bracket (3). The right view shows the footpeg (1) with a footrest (4) attached via a bracket (3). The numbered callouts are: 1. Footpeg, 2. Footrest, 3. Bracket, 4. Footrest, 5. Washer, 6. Nut, 7. Washer.

16

An exploded view diagram of a fuel system component assembly. The main component is a fuel pump or solenoid assembly on the right. To its left are various parts labeled with numbers in boxes:

- 1**: A curved black hose or cable.
- 2**: A small cylindrical component, possibly a filter or plug.
- 3**: A T-shaped metal bracket or connector.
- 4**: A small metal bracket or clip.
- 5**: A bracket pointing to the main assembly, indicating a connection point.
- 6**: A bracket pointing to four small circular components, likely O-rings or seals.

17

#N/D

This exploded view diagram illustrates the components of a bicycle seat assembly. The parts are numbered as follows:

- 1**: Main seat rail
- 2**: Seat post
- 3**: Seat clamp
- 4**: Small circular spacers
- 5**: Small circular spacers
- 6**: Large circular spacers
- 7**: Small circular spacers
- 8**: Small circular spacers
- 9**: Seat saddle
- 10**: Small circular spacer
- 11**: Small circular spacers
- 12**: Small circular spacers
- 13**: Seat saddle mounting bracket
- 14**: Small circular spacers
- 15**: Seat saddle mounting bracket
- 16**: Small circular spacers
- 17**: Small circular spacers
- 18**: Small circular spacers
- 19**: Small circular spacers
- 20**: Seat saddle mounting bracket
- 21**: Seat saddle mounting bracket

19

This diagram illustrates the components of the 1000 Series LED Light Fixture. The parts are numbered as follows:

- 1**: Main light fixture housing.
- 2**: Mounting bracket.
- 3**: Screws for mounting the fixture.
- 4**: Screws for mounting the fixture.
- 5**: Screws for mounting the fixture.
- 6**: Screws for mounting the fixture.
- 7**: Screws for mounting the fixture.
- 8**: Screws for mounting the fixture.
- 9**: Screws for mounting the fixture.
- 10**: Screws for mounting the fixture.
- 11**: LED light module.
- 12**: Screws for mounting the LED module.
- 13**: Screws for mounting the LED module.
- 14**: Screws for mounting the LED module.
- 15**: Screws for mounting the LED module.
- 16**: Screws for mounting the LED module.

20

The diagram illustrates the assembly of a wheel in four columns. Each column contains four components, each with a label in a box below it:

- Column 1:** A hub (labeled 4), a rim (labeled 1), a tire (labeled 2), and a fender (labeled 3).
- Column 2:** A hub (labeled 4), a rim (labeled 1), a tire (labeled 2), and a fender (labeled 3).
- Column 3:** A hub (labeled 4), a rim (labeled 1), a tire (labeled 2), and a fender (labeled 3).
- Column 4:** A hub (labeled 4), a rim (labeled 1), a tire (labeled 2), and a fender (labeled 3).

[illegible]

This diagram illustrates the components of a vehicle brake system, numbered 1 through 18. The parts are as follows:

- 1**: The entire brake assembly, shown in an exploded view.
- 2**: The brake master cylinder.
- 3**: Two brake pads.
- 4**: The brake caliper housing.
- 5**: The brake disc.
- 6**: The brake caliper bracket.
- 7**: The brake caliper piston.
- 8**: A small pin or bolt.
- 9**: A small washer or spacer.
- 10**: A flexible brake hose.
- 11**: A pair of brake lines.
- 12**: A pair of brake line fittings.
- 13**: A pair of brake line fittings.
- 14**: A pair of brake line fittings.
- 15**: A pair of brake line fittings.
- 16**: The brake flange.
- 17**: A set of four brake pins.
- 18**: A set of four brake pins.

[illegible]

23

This diagram illustrates the components of a mechanical assembly, numbered 1 through 14. The parts are as follows:

- 1:** A central bracket or frame component.
- 2:** Three large, dark, trapezoidal plates or covers.
- 3:** A curved, dark, semi-circular component.
- 4:** A small, L-shaped bracket.
- 5:** A set of five vertical pins or screws.
- 6:** A set of five small circular washers or spacers.
- 7:** A set of five small circular washers or spacers.
- 8:** A set of five small circular washers or spacers.
- 9:** A small, L-shaped bracket, similar to part 4.
- 10:** A small, L-shaped bracket, similar to part 4.
- 11:** A set of five vertical pins or screws.
- 12:** A set of five small circular washers or spacers.
- 13:** A set of five small circular washers or spacers.
- 14:** A set of four small rectangular components, arranged in two pairs.

[illegible]

This image displays a collection of 19 numbered components for a car stereo installation kit. The items are arranged on a white background and include:

- 1**: A large, coiled black cable with multiple connectors.
- 2**: A set of 10 parallel metal strips, likely for mounting the stereo unit.
- 3**: A small black rectangular component, possibly a fuse or relay.
- 4**: A small metal ring or washer.
- 5**: A small metal screw or bolt.
- 6**: A circular component, possibly a speaker or a gauge.
- 7**: A small black rectangular component, similar to item 3.
- 8**: A small metal ring or washer.
- 9**: A small metal ring or washer.
- 10**: A small metal ring or washer.
- 11**: A small metal ring or washer.
- 12**: A small black rectangular component, similar to item 3.
- 13**: A small black rectangular component, similar to item 3.
- 14**: A small black cable with a connector.
- 15**: A small black cable with a connector.
- 16**: A small black component, possibly a speaker or a gauge.
- 17**: A small metal ring or washer.
- 18**: A small metal ring or washer.
- 19**: A small black cable with a connector.

[illegible]

FIGURA N°23 SUSPENSIÓN DELANTERA




FIG. NO.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	37000-L3L6-0000	SUSPENSIÓN DELANTERA COMPLETA	1	11062715
2	51181-L3L6-0100	EJE RUEDA DELANTERA 310MM	1	11069974
3	B0578900080035T1X	TORNILLO M8X35	1	11084868
4	34200-L1A8-020001	AMORTIGUADOR DELANTERO DERECHO	1	22000238
5	34100-L1A8-020001	AMORTIGUADOR DELANTERO IZQUIERDO	1	22000823
6	86196-L1A8-0100	BUJE SOPORTE FARO 7MM	4	22000210
7	8619G-L1A8-0100	SOPORTE FAROLA DERECHO	1	22000208
8	8619F-L1A8-0100	SOPORTE FAROLA IZQUIERDO	1	22000209
9	B057830010005571C	TORNILLO M10X55	2	
10	B061700010000061C	TUERCA M10	2	11048215
11	B057830010004071C	TORNILLO 10X40	2	11048207
12	B0009300100000U1C	ARANDELA PRESIÓN 10 MM.	2	11048158
13	B0009500100000K1C	ARANDELA PLANA M10	2	22000874
14	71101-L1A8-00001C	ACOPLE SUPERIOR COLUMNA DIRECCION	1	22000134
15	7110A-L1A8-00001C	COLUMNA DIRECCION	1	22000129
16	71104-L1A8-0000	TUERCA DIRECCION	1	22000130
17	71106-L1A8-00001C	TUERCA AJUSTE DIRECCION	1	22000131
18	71123-L1A8-00001C	ARANDELA PLANA DIRECCION D22X36	1	22000132
19	71105-L1A8-00001C	TUERCA AJUSTE VASTA DIRECCION M22	1	22000133
20	71200-30205	RODAMIENTO 30205	2	22000163
21	34107-L1A8-0000	RETÉN TUBO TELESCOPICO 63-50-11	1	11040627
22	85850-H259-C100	REFLECTOR LATERAL	2	22000180
23	7111A-L3L6-0000	ABRAZADERA SUPERIOR MANUBRIO	2	11061998

This diagram illustrates the components of a fog light assembly. The parts are labeled as follows:

- 1**: The fog light housing, which is a circular, metallic-looking component with a central mounting point.
- 2**: The fog light bulb, a small, cylindrical component with a glass lens and a metal base.
- 3**: The fog light bezel, a rectangular component with a black rubber seal and a mounting bracket.
- 4**: The fog light wiring harness, which includes a black plastic relay, a fuse, and a power wire connected to a battery terminal.

27

This diagram illustrates the components of a vehicle's instrument cluster and ignition switch assembly. The parts are numbered as follows:

- 1:** Instrument cluster assembly, including the speedometer, tachometer, and fuel gauge.
- 2:** Four O-rings for the instrument cluster.
- 3:** Two screws for the ignition switch plate.
- 4:** The ignition switch assembly, including the switch body and the ignition cylinder.
- 5:** The ignition key.
- 6:** Two screws for the instrument cluster mounting plate.
- 7:** Two spacers for the instrument cluster.
- 8:** Three screws for the ignition switch plate.
- 9:** Two screws for the ignition switch plate.
- 10:** Four O-rings for the ignition switch.
- 11:** Two screws for the ignition switch plate.

[illegible]

FIGURA N°26 PEDAL FRENO - VARILLA FRENO TRASERA




FIG. NO.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	52131-L3L6-00000C	CONJUNTO VARILLA DE FRENO	1	22000256
2	24430-0000-00000C	ACOPLE VARILLA FRENO	1	11047933
3	B0009500100000K1C	ARANDELA PLANA M10	1	22000874
4	B000910002502501C	PIN SEGURIDAD 2.5X30	2	22000906
5	85720-L1A8-0000	CABLE 350 MM SWITCH REVERSA	1	22000213
6	B0009300080000U1C	ARANDELA PRESIÓN 8 MM.	3	11048157
7	B061700008000061C	TUERCA M8	3	11048213
8	52106-0000-00000C	REGULADOR RESORTE FRENO TRASERO	1	22000165
9	52120-L3L6-0000	PEDAL FRENO	1	11048028
10	91301-91702023421C	ARANDELA 17 MM.	1	11048143
11	84701-L1A8-00000C	INTERRUPTOR RESORTE	2	22000166
12	52104-0000-01000C	RESORTE FRENO TRASERO	1	22000164
13	31013-L1A8-000001	SOPORTE SWITCH STOP	1	11084870
14	B057830006001671C	TORNILLO 6X16	2	11048187
15	B0009602060000K1C	ARANDELA 6 MM.	4	22000902
16	B0009300060000U1C	ARANDELA DE PRESIÓN 6 MM.	2	11048155
17	B061700006000061C	TUERCA M6	2	11048211
18	B0009500080000K1C	ARANDELA 8 MM.	2	11048166
19	B0088200080020T1C	PIN PASADOR 8X20	1	22000845
20	52101-J1A4-0000	EJE PEDAL FRENO	1	22000121
21	84600-L1A8-030001	SWITCH STOP	1	11084869
22	10015-L1D5-0000	SOPORTE	1	

The diagram illustrates the components for assembling a footplate. It features two main plates, labeled 1 and 2, and four sets of hardware labeled 3, 4, 5, and 6.

- Plate 1:** A dark, rectangular plate with a textured surface.
- Plate 2:** A dark, rectangular plate with a textured surface and a grid of small holes.
- Hardware 3:** Four screws.
- Hardware 4:** Eight washers arranged in two rows of four.
- Hardware 5:** Four small circular spacers or washers.
- Hardware 6:** Four hex nuts.

30

1

2

3

4

5

6

7

8

31

This diagram shows the components of a motorcycle fuel tank assembly. The main fuel tank (1) is a large, dark, teardrop-shaped component. It features a circular filler neck on the left side and a mounting bracket on the right. The assembly includes various fasteners and hardware: two sets of screws (2 and 13) for the filler neck, two gaskets (3), four O-rings (4), two sets of screws (11 and 12) for the mounting bracket, and two sets of screws (5 and 6) for the fuel petcocks. The fuel petcocks (7) are connected to fuel lines (8) which lead to fuel valves (9). A fuel filter (10) is also shown. The fuel lines are secured with clamps (14).

32

This diagram illustrates the components of a motorcycle handlebar assembly, numbered 1 through 9:

- 1**: Left handlebar grip.
- 2**: Left handlebar clamp/bush.
- 3**: Left handlebar control switch (brake/shift).
- 4**: Right handlebar grip.
- 5**: Left handlebar control switch (brake/shift).
- 6**: Right handlebar control switch (brake/shift).
- 7**: Left handlebar end cap.
- 8**: Main handlebar.
- 9**: Right handlebar end cap.

33

34

An exploded view diagram of a mechanical assembly. The components are labeled with numbers in boxes:

- 1**: A large, dark, T-shaped metal plate with a central rectangular cutout and two circular holes on the vertical stem.
- 2**: A dark, curved metal bracket with a serrated edge and a circular hole.
- 3**: Three long screws.
- 4**: Two screws.
- 5**: Six washers, arranged in two columns of three.
- 6**: Three small circular spacers or washers.
- 7**: Three small circular spacers or washers, arranged in two columns (two on the left, one on the right).

35

This diagram illustrates the components of a rear suspension assembly, including a control arm, a coil spring, and various fasteners. The parts are numbered as follows:

- 1**: Control arm assembly, including the lower control arm and the upper control arm.
- 2**: Coil spring assembly, including the coil spring and the shock absorber.
- 3**: Two long screws for the control arm.
- 4**: Four washers for the control arm.
- 5**: Two small circular components, likely bushings or spacers.
- 6**: Two small circular components, likely bushings or spacers.
- 7**: A large washer for the control arm.
- 8**: A small washer for the control arm.
- 9**: A small washer for the control arm.
- 10**: A small pin or clip for the control arm.

36

This diagram illustrates the components for assembling a motorcycle bodywork piece. The parts are numbered as follows:

- 1**: Main bodywork panel (left and right views shown).
- 2**: Secondary bodywork panel (left and right views shown).
- 3**: Long horizontal trim piece.
- 4**: Small vertical pin or clip.
- 5**: Small circular fastener or pin.
- 6**: Small circular fastener or pin.
- 7**: Small circular fastener or pin.
- 8**: Set of 8 screws.
- 9**: Set of 3 screws.
- 10**: Set of 5 screws.
- 11**: Set of 8 screws.
- 12**: Set of 5 small rectangular clips or fasteners.

37

The diagram shows an exploded view of a mechanical assembly. The main assembly is shown in a grey rectangular frame. The components are numbered as follows:

- 1**: The main frame or housing.
- 2**: A small orange component, likely a pin or clip.
- 3**: A small orange component, likely a pin or clip.
- 4**: A small orange component, likely a pin or clip.
- 5**: A small orange component, likely a pin or clip.
- 6**: A black component, likely a cover or plate.
- 7**: A small orange component, likely a pin or clip.
- 8**: A small orange component, likely a pin or clip.
- 9**: A set of 8 small orange components, likely pins or clips.
- 10**: A set of 16 small orange components, likely pins or clips.
- 11**: A set of 8 small orange components, likely pins or clips.
- 12**: A set of 8 small orange components, likely pins or clips.

38

This diagram illustrates the exploded view of the bed frame assembly. The components are labeled as follows:

- 1**: Side rail assembly.
- 2**: Headboard.
- 3**: Top rail.
- 4**: Bed base.
- 5**: Bottom rail.
- 6**: Casters (four shown).
- 7**: Spacers (two sets shown).
- 8**: Screws (four shown).
- 9**: Screws (one set shown).
- 10**: Footboard.
- 11**: Screws (two sets shown).
- 12**: Screws (one set shown).
- 13**: Screws (one set shown).
- 14**: Lock pin.

39

The icons are numbered 1 through 14 and represent the following types of evidence:

- 1: A rectangular card with four circular fingerprints arranged in a 2x2 grid.
- 2: A rectangular card with two sets of parallel horizontal lines, representing footprints or tire tracks.
- 3: A rectangular card with four vertical rectangular shapes, representing fingerprints or other impressions.
- 4: Two small, rectangular, textured items, possibly fibers or small pieces of evidence.
- 5: A white card with a black, wavy, U-shaped line, representing a fingerprint or a specific type of mark.
- 6: A white card with eight small, dark, circular dots arranged in two rows of four, representing fingerprints or other small marks.
- 7: A white card with four small, dark, circular dots arranged in a horizontal row, representing fingerprints or other small marks.
- 8: A white card with four small, dark, circular dots arranged in a horizontal row, representing fingerprints or other small marks.
- 9: A white card with three vertical lines, representing fingerprints or other marks.
- 10: A white card with six small, dark, circular dots arranged in a horizontal row, representing fingerprints or other small marks.
- 11: A white card with two vertical lines, representing fingerprints or other marks.
- 12: A white card with six small, dark, circular dots arranged in a horizontal row, representing fingerprints or other small marks.
- 13: A white card with six small, dark, circular dots arranged in a horizontal row, representing fingerprints or other small marks.
- 14: A small, dark, rectangular object, possibly a piece of evidence or a tool.

[illegible]

This diagram illustrates the assembly of a vehicle chassis, showing various components and their relative positions. The components are numbered as follows:

- 1**: A set of four rectangular components, likely brake pads or shoes, arranged in a 2x2 grid.
- 2**: A set of four rectangular components, likely brake pads or shoes, arranged in a 2x2 grid.
- 3**: A set of eight long, thin, curved components, likely brake pads or shoes, arranged in a single row.
- 4**: A set of eight small, circular components, likely bolts or nuts, arranged in a single row.
- 5**: A set of four U-shaped components, likely shock absorbers or struts, arranged in a single row.
- 6**: Two square components with circular openings, likely brake calipers or hubs.
- 7**: A set of four long, thin, curved components, likely brake pads or shoes, arranged in a single row.
- 8**: A set of eight small, circular components, likely bolts or nuts, arranged in a single row.
- 9**: A set of eight small, circular components, likely bolts or nuts, arranged in a single row.
- 10**: A set of eight small, circular components, likely bolts or nuts, arranged in a single row.
- 11**: A set of four rectangular components, likely brake pads or shoes, arranged in a single row.
- 12**: A set of four U-shaped components, likely shock absorbers or struts, arranged in a single row.

41

The diagram shows the components for a car battery terminal assembly. The main assembly includes:

- 1**: Battery terminal housing
- 2**: Two screws for the terminal housing
- 3**: A bag of terminal paste
- 4**: A curved terminal bracket
- 5**: Two screws for the bracket
- 6**: Six washers (two for each terminal)
- 7**: Two nuts for the bracket
- 8**: Two nuts for the terminal posts

A separate box lists the tools required for the installation:

- Terminal paste bag
- Wrench
- Wrench
- Screwdriver
- Pliers

42

FIGURA N°40 CARDAN




FIG. NO.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	56300-L3L6-0300	CONJUNTO EJE TRASERO	1	22000271
2	B0009602080000K1C	ARANDELA 8 MM.	1	11048172
3	B061700008000061C	TUERCA M8	1	11048213
4	3824F-L1A8-0000	CABLE PARQUEO	1	11048013
5	52177-L3L6-0200	TUBO COBRE 555MM	1	22000268
6	52177-L3L6-0100	TUBO COBRE 1550MM	1	22000270
7	52177-L3L6-040001	CONDUCTO 750 MM	1	11085449
8	52175-L3L6-0000	TUBO ALTA PRESIÓN ACEITE 500 MM	1	22000228
10	61143-0000-0300	TUBO 3 VIA	1	22000229
11	52160-L3L6-00001C	BOMBA FRENO TRASERO TRI 200	1	22000225
12	52177-L3L6-050001	CONDUCTO 460 MM	1	11085450
13	B057830010006071C	TORNILLO 10X60	2	11048208
14	B0009602100000K1C	ARANDELA M10	2	
15	B0009500100000K1C	ARANDELA PLANA M10	2	22000874
16	B0009300100000U1C	ARANDELA PRESIÓN 10 MM.	2	11048158
17	B061700010000061C	TUERCA M10	2	11048215
18	6155Q-R0D4-0000	RESERVORIO LIQUIDO FRENO	1	22000231
19	52176-L3L6-0000	SOPORTE COPA ACEITE	1	22000232
20	B057830008002071C	TORNILLO 8X20	2	11048197
21	B0009500080000K1C	ARANDELA 8 MM.	2	11048166
22	B061700008000061C	TUERCA M8	2	11048213
23	53070-L3L6-010001	TUBO ACEITE 300 MM	2	22000230
24	19410-L3L6-0000	ABRAZADERA TUBO ACEITE	4	22000233

An exploded view diagram of a mechanical assembly. The components are numbered 1 through 10. A large rectangular box at the top contains the main shaft assembly, which includes a long shaft (1), a coupling or pulley at one end (3), and a motor or actuator at the other end (4). Below the box, various other components are shown: a small pin or screw (1), a complex bracket or housing (2), a set of four screws (5), a set of four small circular components (6), a set of four screws (7), a set of three small circular components (8), a small cross-shaped component (9), and a set of three small circular components (10).

44

45

This diagram illustrates the components of a vehicle's rear suspension system, specifically a multi-link rear suspension. The components are numbered as follows:

- 1:** Rear suspension cross member (a large, black, rectangular frame).
- 2:** Upper control arm (two).
- 3:** Upper control arm ball joint (two).
- 4:** Lower control arm (two).
- 5:** Lower control arm ball joint (two).
- 6:** Rear suspension cross member (a large, black, rectangular frame).
- 7:** Rear suspension cross member (a large, black, rectangular frame).
- 8:** Upper control arm (two).
- 9:** Upper control arm ball joint (two).
- 10:** Lower control arm (two).
- 11:** Lower control arm ball joint (two).
- 12:** Rear suspension cross member (a large, black, rectangular frame).
- 13:** Rear suspension cross member (a large, black, rectangular frame).
- 14:** Rear suspension cross member (a large, black, rectangular frame).
- 15:** Rear suspension cross member (a large, black, rectangular frame).

46

Diagram illustrating the components of a battery assembly, numbered 1 through 6:

- 1: Battery unit (top view).
- 2: Battery unit (bottom view).
- 3: Four screws.
- 4: Four washers.
- 5: Four washers.
- 6: Four washers.

47

FIGURA N°45 COMPLEMENTOS FRENO TRASERO




FIGURA N°45 COMPLEMENTOS FRENO TRASERO (1/1)

FIG. NO.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	B057830008003070C	TORNILLO 8 X 30	6	11048201
1	B0009300080000UOC	ARANDELA 8 MM.	6	11048156
2	B0089401200000NOE	ANILLO RETÉNEDOR	1	11048181
3	3823Y-L1A8-0000	PIN SEGURIDAD	1	11047998
4	71200-6004-RS	RODAMIENTO BOLAS 6004-RS	1	11048083
5	3822Y-L1A8-0000	TAPA CAJA CAMBIOS	1	11047977
7	3823B-L1A8-0000	EMPAQUE TAPA CAJA CAMBIOS	1	11041604
7	B057830010004070C	TORNILLO 10X40	4	11048206
8	B0009300100000UOC	ARANDELA PRESIÓN 10 MM.	4	11048158
9	3823C-L1A8-0000	SOPORTE CAJA CAMBIOS	1	11047979
9	B0009300060000UOC	ARANDELA PRESIÓN 6 MM.	4	11048154
10	3823Z-L1A8-0000	ANILLO RETÉNEDOR	2	11047999
11	3823D-L1A8-0000	PIÑÓN SATELITE CAJA CAMBIOS	2	11047980
12	3820V-L1A8-0000	ARANDELA COBRE	2	11047964
13	3820R-L1A8-0000	PIÑÓN PLANETARIO CAJA CAMBIOS	2	11047961
14	3820T-L1A8-0000	EJE PIÑÓN PLANETARIO	1	11047963
15	3820G-L1A8-0000	TAPA ACOPLA EJE RUEDA TRASERO	1	11047957
16	B057830008002070C	TORNILLO 8X20	6	11048196
16	38241-L1A8-0000	ARANDELA 8 MM.	6	11048001
17	71200-6008	RODAMIENTO 6008	1	11048084
18	38246-L1A8-0000	TORNILLO EJE TRANSMISIÓN DERECHO	4	11048005
19	B061700008000060C	TUERCA M8	1	11048212
19	B0009300080000UOC	ARANDELA 8 MM.	1	11048156
20	3821F-L1A8-0000	CAMPANA TRASERA	2	11047966

FIG. NO.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
21	38247-L1A8-0000	TUERCA TAPON CAMPANA TRASERA	4	11048006
22	3822R-L1A8-0000	TORNILLO AJUSTE	1	11047975
23	3822N-L1A8-0000	RESORTE CORTO	1	11047972
24	3824E-L1A8-0000	PLATINA SOPORTE	1	11048012
24	3822T-L1A8-0000	PLATINA SOPORTE	1	11047976
25	3822J-L1A8-0000	CUÑA COMPRESOR	1	11047970
25	3822G-L1A8-0000	RESORTE COMPRESOR	1	11047968
25	3822H-L1A8-0000	ARANDELA COMPRESOR	1	11047969
26	3824C-L1A8-0000	PLATINA SOPORTE	1	11048010
27	3823H-L1A8-0000	BUJE	2	11047984
28	B000910003201620C	PIN SEGURIDAD 3.2X16	1	11048153
29	B008820008001420C	PIN PASADOR 8X14	1	11048177
30	3822K-L1A8-0000	RESORTE LARGO	1	11047971
31	3821J-L1A8-010001	BANDAS FRENO	2	22000852
32	B057830008002570C	TORNILLO 8X25	8	11048198
33	3823E-L1A8-0000	GUARDAPOLVO PLATO RUEDA TRASERA	2	11047981
34	3822E-L1A8-0000	CILINDRO FRENO TRASERO	1	11047967
34	3824N-L3L6-0000	PERNO DRENAJE BOMBA FRENO	1	
35	3823G-L1A8-0000	PLATO RUEDA DERECHA	1	11047983
36	B057830006001270C	TORNILLO 6X12	1	11048186
36	B0009300060000UOC	ARANDELA PRESIÓN 6 MM.	1	11048154
37	71200-6206	RODAMIENTO BOLAS 6206	1	11048087
38	3823J-L1A8-0000	BUJE	2	11047985
39	B061700008000060C	TUERCA M8	8	11048212
40	B0009300080000UOC	ARANDELA 8 MM.	8	11048156

FIGURA N°45 COMPLEMENTOS FRENO TRASERO




FIGURA N°45 COMPLEMENTOS FRENO TRASERO (2/2)

FIG. NO.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
41	3820P-L1A8-0000	EJE TRANSMISIÓN DERECHO	1	11047960
42	3820D-L3L6-0000	CARDAN (SOLO)	1	11047955
43	3823F-L1A8-0000	PLATO RUEDA IZQUIERDA	1	11047982
44	38249-L1A8-0000	TUERCA TAPON CAMPANA TRASERA	5	11048008
45	3820X-L1A8-0000	EJE TRANSMISIÓN IZQUIERDO	1	11047965
46	38248-L1A8-0000	TORNILLO EJE TRANSMISIÓN IZQ.	5	11048007
47	3820F-L1A8-0000	PIN SEGURIDAD 5X40	1	11047956
48	3820S-L1A8-0000	ACOPLE DIFERENCIAL	1	11047962
49	B001190208001800P		2	
50	3823K-L1A8-0000	EMPAQUE ACOPLE EJES TRASEROS	1	11040628
51	3820H-L1A8-0000	ACOPLE EJES TRASEROS	1	11047958
52	B057830008002070C	TORNILLO 8X20	8	11048196
52	B0009300080000UOC	ARANDELA 8 MM.	8	11048156
53	38260-L1A8-0000	EMPAQUE CAJA CAMBIOS	1	11041605
54	B057830008001270C	TORNILLO 8X12	1	11048194
54	B000950008000002	ARANDELA 8 MM.	1	11048164
55	3823L-L1A8-0000	CINTA DE PROTECCION	1	11047986
56	3823M-L1A8-0000	TAPON NIVEL ACEITE	1	11047987
56	15822-M4E3-000001	ANILLO RETÉNEDOR	1	22000892
57	3822Z-L1A8-0000	CAJA DE CAMBIOS TRAS.	1	11047978
58	3823N-L1A8-0000	PIÑÓN CAJA CAMBIOS TRAS.	1	11047988
59	71200-6004	RODAMIENTO BOLAS 6004	1	11048082
60	3820L-L1A8-0000	PIÑÓN CAJA CAMBIOS TRAS.	1	11047959
61	3823P-L1A8-0000	PIÑÓN HELICOIDAL CAJA CAMBIOS TR	1	11047989
62	3823Q-L1A8-0000	HORQUILLA CAJA CAMBIOS TRAS.	1	11047990

FIG. NO.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
63	3823R-L1A8-0000	EJE HORQUILLA CAJA CAMBIOS TRAS.	1	11047991
64	3823S-L1A8-0000	EJE CAJA CAMBIOS TRAS.	1	11047992
65	3823T-L1A8-0000	PIÑÓN HELICOIDAL CAJA CAMBIOS TR	1	11047993
66	71200-30304	RODAMIENTO BOLAS 30304	1	11048079
67	71200-32006	RODAMIENTO BOLAS 32006	1	11048080
68	3823U-L1A8-0000	PIÑÓN DOBLE CAJA CAMBIOS TRAS.	1	11047994
69	38242-L1A8-0000	ARANDELA 12 MM.	1	11048002
70	B008120012000060E	PIN 8X18	1	
71	71200-6003	RODAMIENTO BOLAS 6003	1	11048081
72	38243-L1A8-0000	ARANDELA SELLADO	1	11048003
73	3820B-L1A8-0000	EJE CAJA CAMBIOS TRASERO	1	11047954
74	38244-L1A8-0000	ARANDELA SELLADO	1	11048004
75	3823V-L1A8-0000	BUJE CAJA CAMBIOS TRASERO	1	11047995
76	73517-20357	RETÉN 20X35X7	2	11048113
77	3823W-L1A8-0000	PIÑÓN HELICOIDAL CAJA CAMBIOS TRAS.	1	11047996
78	3823W-L1A8-0000	PIÑÓN HELICOIDAL CAJA CAMBIOS TRAS.	1	11047996
79	3822Q-L1A8-0000	VALVULA AIRE	2	11047974
80	3822P-L1A8-0000	TAPA VALVULA AIRE	2	11047973
81	3824B-L1A8-0000	PLATINA SOPORTE	1	11048009
82	3824D-L1A8-0000	PLATINA SOPORTE	1	11048011
82	3822T-L1A8-0000	PLATINA SOPORTE	1	11047976

FIGURA N°45 CAJA REVERSA (1/2)




FIG. NO.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
1	B057830008002070C	TORNILLO 8X20	4	11048196
2	3823Z-L3L6-0000	PLATINA AJUSTE	1	11048000
3	7350S-L1A8-0000	SOPORTE CAJA REVERSA	1	11048104
4	7351Y-L3L6-0000	GUARDAPOLVO	1	11041606
5	71200-6205-2RS	RODAMIENTO BOLAS 6205-2RS	1	11048086
6	7350N-L3L6-0000	PIÑÓN REVERSA (12T)	1	11048103
7	43109-L3L6-0000	TAPON	1	11048020
8	B061700006000060C	TUERCA M6	1	11048210
9	B0009300060000U0C	ARANDELA PRESIÓN 6 MM.	1	11048154
10	B000950006000020C	ARANDELA 6 MM.	1	11048162
11	7351E-L3L6-0000	PLATINA	1	11048117
12	23258-L3L6-0000	ANILLO RETÉNEDOR	1	11047930
13	7351B-L3L6-0000	HORQUILLA CAMBIO MARCHA	1	11048116
14	7351A-L3L6-0000	EMPAQUE TAPA CAJA REVERSA	1	11048115
15	7350V-L3L6-0000	TAPA CAJA REVERSA	1	11048106
16	B166740105001270C	TORNILLO 5X12	4	11048220
17	7350W-L3L6-0000	ABRAZADERA	1	11048107
18	7350X-L3L6-0000	MANGUERA RESPIRACION	1	11048108
19	7351J-L3L6-0000	LEVA REVERSA	1	11048119
20	7351K-L3L6-0000	RESORTE LEVA REVERSA	1	11048120
21	71200-16003	RODAMIENTO BOLAS	1	11048078
22	7350K-L3L6-0000	PIÑÓN SATELITE (15T)	1	11048101
23	7350J-L3L6-0000	PIÑÓN PLANETARIO (10T)	1	11048100
24	7350H-L3L6-0000	PIÑÓN SATELITE (15T)	1	11048099
25	71200-6205	RODAMIENTO BOLAS 6205	1	11048085

FIGURA N°45 CAJA REVERSA (2/2)




FIG. NO.	PARTE N°	DESCRIPCIÓN	CANT.	SAP
26	7351H-L3L6-0000	EJE REVERSA	1	11048118
27	71200-6004	RODAMIENTO BOLAS 6004	1	11048082
28	7350G-L3L6-0000	EMPAQUE COMPLEMENTO CAJA REV	1	11041607
29	7350F-L3L6-0000	COMPLEMENTO CAJA REVERSA	1	11048098
30	73517-L3L6-0000	RETÉN	1	11048114
31	7350Y-L3L6-0000	ABRAZADERA	1	11048109
32	7351T-L3L6-0000	ARANDELA NYLON	1	11048122
33	B166740108002570C	TORNILLO 8X25	1	11048223
34	B166740108002070C	TORNILLO 8X20	3	11048222
35	B166740106001870C	TORNILLO 6X18	2	11048221
36	7351Q-L3L6-0000	EJE ACCIONADOR REVERSA	1	11048121
37	B000950012000020C	ARANDELA 12 MM.	1	11048169
38	B094580012000060C	TUERCA M12	1	11048219
39	B000910003002520C	PIN SEGURIDAD 3X25	1	11048152
40				
41	73517-10164	ANILLO RETÉNEDOR	1	11048112
42	7350Z-L3L6-0000	ARANDELA 10 MM.	1	11048110
43	7350E-L3L6-0000	EJE REVERSA	1	11048097
44	73511-L3L6-0000	PEDAL REVERSA	1	11048111
45	B057830006002070C	TORNILLO 6X20	1	11048188
46	7350U-L3L6-0000	TAPÓN NIVEL ACEITE	1	11048105
47	15822-M4E3-000001	ANILLO RETÉNEDOR	1	22000892
48	7350L-L3L6-0000	CAJA REVERSA	1	11048102

1

2

3

4

5

6

7

8

9

54